



[Manuals.plus](#) /

> [VISWIN](#) /

> VISWIN Inclinable A-Frame Easel (Model ELAF_W09BW_V) Instruction Manual

VISWIN ELAF_W09BW_V

VISWIN Inclinable A-Frame Easel Instruction Manual

Model: ELAF_W09BW_V

1. INTRODUCTION

Thank you for choosing the VISWIN Inclinable A-Frame Easel. This easel is crafted from premium beech wood, designed for artists of all levels. It features an inclinable mast, adjustable height, a double-layer storage tray, and a foldable design for convenience. This manual provides detailed instructions for assembly, operation, maintenance, and safety to ensure optimal use of your easel.

2. SAFETY INFORMATION

- Ensure all components are securely fastened before use.
- Do not exceed the maximum loading capacity of 22 lbs (10 kg).
- Keep hands clear of moving parts during height and tilt adjustments to prevent pinching.
- Place the easel on a stable, level surface to prevent tipping.
- Supervise children when they are using or near the easel.

3. PACKAGE CONTENTS

Before assembly, verify that all parts are present and undamaged. The package should include:

- Beech wood easel components (labeled with easy-peel number stickers)
- Hardware kit (individually packed screws, bolts, nuts, and two screwdrivers)
- Instruction manual

4. ASSEMBLY INSTRUCTIONS

Assembly is required. Follow the clear step-by-step instructions provided in the included manual. All wooden parts and hardware are labeled for easy identification. An assembly video is also available for additional guidance.

Assembly Tips:

- Lay out all components on a clean, flat surface before starting.
- Refer to the detailed drawings in the manual to ensure correct orientation of parts.
- Do not overtighten screws until all components are in place.
- An extra set of hands may be helpful for certain steps.

Your browser does not support the video tag.

Video: Official product video demonstrating the assembly, adjustment, and usage of the VISWIN Inclinable A-Frame Easel. This video provides a visual guide to setting up the easel, adjusting its height and tilt, and placing a canvas. It showcases the metal ratchet mechanism, the double-layer tray, and the flexible slider in action.

5. OPERATING INSTRUCTIONS

5.1 Adjusting Easel Height

The easel's height can be adjusted to accommodate both seated and standing painting positions. Use the metal ratchet mechanism located on the central mast to raise or lower the canvas tray. The tray can be adjusted up to 38 inches from the ground.




Image: This image illustrates the key dimensions of the easel, including its adjustable height range from 65 to 89 inches, a

maximum canvas capacity of 49 inches, and the tray's adjustable height from 13 to 38 inches. The overall footprint is 32 inches wide by 26 inches deep.

5.2 Tilting the Easel

The central mast can be tilted forward by up to 10 degrees. This feature helps reduce glare on your artwork and improves visibility, especially useful for pastels or glare-sensitive work. Locate the adjustment knob on the side of the mast, loosen it, adjust to the desired angle, and then tighten securely.



Image: This image displays two key features: the easel's ability to tilt forward by up to 10 degrees to reduce glare, and its foldable design for convenient transport and compact storage.

5.3 Placing a Canvas

The easel accommodates canvases up to 49 inches in height. Place the bottom edge of your canvas on the adjustable tray. Use the flexible slider at the top of the mast to secure the canvas in place. Adjust the slider by loosening the knob, positioning it firmly against the top edge of the canvas, and then tightening the knob.

Flexible slider

Max canvas height: 49" (1245 mm)

Accommodate various sizes of canvas




Image: This visual highlights the easel's flexible slider, which allows for secure placement of canvases up to 49 inches tall. Examples of different canvas sizes (16x20, 24x31, 31x39 inches) are shown to demonstrate versatility.



Inclinable A-Frame Artist Easel

Creative Art Maker



Image: This image shows the easel in action, with an artist comfortably painting on a canvas. It highlights the easel's stability and ergonomic design for creative work.

5.4 Using the Storage Tray

The easel features a double-layer tray with a 75mm (approximately 3 inches) depth. This tray is designed to keep your art supplies organized and within reach while you work.

Double-layer tray

- Raised edge
- Adjustable height
- Keep organized



Image: A detailed view of the easel's double-layer tray, which is 75mm (approximately 3 inches) deep, providing ample space to organize and store various art supplies like paints and brushes.

6. MAINTENANCE

- Regularly inspect all screws and bolts for tightness. Tighten as needed to maintain stability.
- Clean the beech wood surface with a soft, dry cloth. Avoid abrasive cleaners or excessive moisture.
- Store the easel in a dry environment to prevent wood warping or damage.
- If the easel becomes dirty with paint, clean immediately with appropriate art cleaning solutions, being careful not to damage the wood finish.

7. TROUBLESHOOTING

7.1 Easel feels unstable:

- Ensure all assembly hardware is securely tightened.
- Verify the easel is placed on a flat, level surface.
- Check that the legs are fully extended and locked into position.

7.2 Canvas not holding securely:

- Ensure the flexible slider at the top is firmly tightened against the canvas.
- Check that the canvas tray is properly engaged with the metal ratchet mechanism.

7.3 Difficulty adjusting height or tilt:

- Loosen the adjustment knobs sufficiently before attempting to move components.
- Ensure no debris is obstructing the ratchet mechanism or slider tracks.

8. SPECIFICATIONS

Feature	Specification
Model Name	ELAF_W09BW_V
Color	Walnut
Material	Beech Wood
Product Dimensions (D x W x H)	26" x 32" x 65" (Minimum Height)
Adjustable Height Range	65" - 89" H
Max Canvas Height	49"
Tray Height Adjustment	13" - 38" from ground
Item Weight	16.5 Pounds
Max Loading Capacity	22 lbs (10 kg)
Easel Type	A-Frame Easel
Tilt Feature	Forward tilt up to 10°

9. WARRANTY AND SUPPORT

VISWIN offers a **Lifetime Guarantee** on this product. We are committed to providing high-quality products and ensuring customer satisfaction. If you encounter any issues or have questions regarding your easel, please contact VISWIN customer support. Our team is available to assist you.

For support, please refer to the contact information provided with your purchase or visit the official VISWIN website.