

[Manuals.plus](#) /

› [Hampton Bay Lighting](#) /

› Hampton Bay Flaxmere 11.8 in. Brushed Nickel LED Flush Mount Ceiling Light (Model HB1023C-35) User Manual

## Hampton Bay Lighting HB1023C-35

# Hampton Bay Flaxmere 11.8 in. Brushed Nickel LED Flush Mount Ceiling Light

MODEL: HB1023C-35

### Introduction

---

This manual provides instructions for the installation, operation, and maintenance of the Hampton Bay Flaxmere 11.8 inch Brushed Nickel LED Flush Mount Ceiling Light, model HB1023C-35. This fixture is designed for indoor use and features an integrated LED lighting source.



## 12 in LED Flush Mount

Brushed Nickel Finish

# Flaxmere

11.8 in DIA x 3.1 in H  
(Assembled Dimensions)



Frosted White Shade



Dimmable†



Figure 1: Hampton Bay Flaxmere 11.8 inch LED Flush Mount Ceiling Light.

## Safety Information

**WARNING:** Risk of electric shock. Disconnect power at the fuse or circuit breaker before installation or servicing.

- Read all instructions carefully before beginning installation.
- Ensure all electrical connections comply with local codes and ordinances, as well as the National Electric Code (NEC).
- If you are unfamiliar with electrical wiring, consult a qualified electrician.
- Do not install this fixture in wet or damp locations. It is rated for indoor use only.
- Do not attempt to modify the fixture. Any modifications may void the warranty and create a safety hazard.
- Handle the glass shade with care to prevent breakage.

## Package Contents

Verify that all components are present before beginning installation:

- LED Flush Mount Ceiling Light Fixture
- Remote Control
- White Glass Shade
- Mounting Hardware (typically includes screws, wire nuts, and a mounting bracket)

## Setup and Installation

---

Follow these steps to install your LED flush mount ceiling light:

1. **Turn Off Power:** Locate the circuit breaker or fuse box that controls the power to the light fixture location. Turn off the power completely before proceeding.
2. **Prepare Mounting Surface:** Ensure the ceiling surface is clean, dry, and structurally sound to support the fixture's weight.
3. **Install Mounting Bracket:** Attach the mounting bracket (if separate from the fixture) to the junction box in the ceiling using the provided screws. Ensure it is securely fastened.
4. **Make Electrical Connections:** Connect the fixture's wires to the household electrical wires. Typically, connect the black wire from the fixture to the black (live) wire from the ceiling, the white wire from the fixture to the white (neutral) wire from the ceiling, and the bare copper or green wire from the fixture to the bare copper or green (ground) wire from the ceiling. Secure connections with wire nuts.
5. **Mount the Fixture:** Carefully align the fixture with the mounting bracket and secure it to the ceiling using the provided screws. Ensure the fixture is flush against the ceiling.
6. **Install Glass Shade:** Attach the white glass shade to the fixture according to the specific design. This usually involves twisting or securing it with small screws or clips.
7. **Restore Power:** Once the fixture is securely installed and all connections are made, restore power at the circuit breaker or fuse box.



Figure 2: Dimensions of the Flaxmere LED Flush Mount Ceiling Light (11.81 inches diameter, 3.18 inches height).

## Operating Instructions

This LED flush mount light is operated via a standard wall switch or the included remote control.

- **Wall Switch Operation:** Flip the wall switch to the 'ON' position to turn on the light. Flip to 'OFF' to turn off.
- **Remote Control Operation:** The remote control allows for convenient operation. Refer to the remote control's specific instructions for pairing and function details, which typically include ON/OFF, dimming, and potentially color temperature adjustments if applicable.

## Maintenance

The Hampton Bay Flaxmere LED Flush Mount Ceiling Light requires minimal maintenance.

- **Cleaning:** To clean the fixture, ensure power is off. Wipe the exterior surfaces with a soft, dry, or slightly damp cloth. Do not use abrasive cleaners or solvents, as these may damage the finish or electrical components.
- **LED Lifespan:** The integrated LED light source is designed for long-term use, with an estimated lifespan of 45 years based on 3 hours of daily operation. The LEDs are not replaceable.

## Troubleshooting

If you encounter issues with your light fixture, refer to the following troubleshooting guide:

Problem	Possible Cause	Solution
Light does not turn on.	No power to the fixture.	Check circuit breaker or fuse. Ensure wall switch is ON.
	Loose wire connections.	Turn off power. Check and secure all wire connections.
Light flickers or dims unexpectedly.	Incompatible dimmer switch.	Ensure a compatible LED dimmer switch is used. Consult a qualified electrician if unsure.
	Loose wire connections.	Turn off power. Check and secure all wire connections.
Remote control not working.	Dead batteries.	Replace batteries in the remote control.
	Remote not paired.	Refer to remote control instructions for pairing procedure.

## Specifications

Feature	Detail
Model Name	HB1023C-35
Brand	Hampton Bay Lighting
Light Fixture Form	Ceiling

Feature	Detail
Installation Type	Flush Mount
Material	Alloy Steel (Fixture), Glass (Shade)
Finish Type	Brushed Nickel
Shade Color	White
Light Source Type	LED (Integrated)
Brightness	1261 Lumens
Wattage	20 Watts (LED equivalent to 100W incandescent)
Voltage	120 Volts (AC)
Light Color	Warm White
Control Method	Remote Control, Wall Switch
Indoor/Outdoor Usage	Indoor
Item Weight	1.52 pounds (0.69 Kilograms)
Package Dimensions	13.82 x 13.43 x 4.88 inches
Assembly Required	Yes
UPC	046335084339

## Warranty and Support

Specific warranty information for the Hampton Bay Flaxmere LED Flush Mount Ceiling Light (Model HB1023C-35) was not provided in the product details. For warranty claims or technical support, please contact Hampton Bay Lighting directly or refer to the documentation included with your purchase.