

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [tectake](#) /

> [TecTake 800089 Double Garden Lounger with Sunshade and Cushions Instruction Manual](#)

tectake 403882-1

TecTake 800089 Double Garden Lounger with Sunshade and Cushions

Model: 403882-1 | Brand: tectake

1. INTRODUCTION AND PRODUCT OVERVIEW

The TecTake 800089 Double Garden Lounger is designed for comfortable relaxation in your garden or outdoor space. This versatile lounger features a robust metal frame, a retractable sunshade, and includes two cushions for enhanced comfort. It is suitable for both indoor and outdoor use and can accommodate up to two people.

Key Features:

- Robust metal frame, designed to support up to two individuals.
- Retractable protective sunshade for adjustable shade.
- Quick and straightforward assembly process.
- Suitable for use in both indoor and outdoor environments.
- Water-repellent coating on fabric for easy cleaning and maintenance.
- Equipped with two wheels for convenient relocation.
- Maximum load capacity: 200 kg.



Image 1.1: The TecTake 800089 Double Garden Lounger with its sunshade extended, shown in an outdoor setting.

2. SAFETY INSTRUCTIONS

Please read and understand all safety instructions before assembling and using the product. Failure to follow these instructions may result in injury or damage to the product.

- Ensure all components are securely fastened before use.
- Do not exceed the maximum weight capacity of 200 kg.
- Keep children and pets away during assembly.
- Avoid using the lounger in strong winds or extreme weather conditions.
- Periodically check all bolts and connections for tightness.
- Do not stand on the lounger.

3. PACKAGE CONTENTS

Verify that all parts are present before beginning assembly. If any parts are missing or damaged, please contact customer

support.

- 1 x Main Frame
- 1 x Lying Surface Fabric
- 2 x Cushions
- 1 x Sunshade Canopy
- 1 x Assembly Manual
- Required Assembly Hardware (screws, bolts, etc.)

4. SETUP AND ASSEMBLY

Assembly of the TecTake 800089 Double Garden Lounger is designed to be quick and easy. Follow the detailed steps provided in the included assembly manual. Ensure you have adequate space and all components laid out before starting.

1. Unpack all components and verify against the package contents list.
2. Assemble the main frame structure according to the diagrams in the separate assembly manual. Ensure all connections are finger-tight initially.
3. Attach the lying surface fabric to the frame.
4. Install the sunshade canopy mechanism and fabric.
5. Securely tighten all bolts and screws using the provided tools. Do not overtighten.
6. Place the two cushions on the lying surface.



Image 4.1: Side view of the lounger showing the wheels, feet, and sunshade attachment points, relevant for assembly.

5. OPERATING INSTRUCTIONS

Using your TecTake 800089 Double Garden Lounger is straightforward.

- **Using the Sunshade:** The sunshade canopy is retractable. Gently push or pull the canopy to adjust its position for optimal sun protection or exposure. Ensure it locks into place if applicable.
- **Moving the Lounger:** The lounger is equipped with two wheels for easy movement. To move, slightly lift the end without wheels and roll the lounger to your desired location. Ensure the path is clear of obstacles.
- **Relaxation:** The lounger is designed for comfortable reclining. The included cushions provide additional comfort.



Image 5.1: A couple enjoying the TecTake Double Garden Lounger with the sunshade providing comfort.

6. MAINTENANCE

Proper maintenance will extend the life of your garden lounger.

- **Cleaning:** The fabric is water-repellent. Clean the lying surface and sunshade with a damp cloth and mild soap. Rinse thoroughly with clean water and allow to air dry completely before storage or next use. Do not use harsh chemicals or abrasive cleaners.
- **Frame Care:** Wipe the metal frame with a damp cloth. If rust appears, clean it immediately and apply a rust-inhibiting paint if necessary.
- **Storage:** During periods of non-use, especially in adverse weather conditions (rain, snow, strong sun), it is recommended to cover the lounger or store it indoors to protect it from the elements and prolong its lifespan.
- **Inspection:** Periodically inspect all parts for wear and tear, especially the fabric, frame connections, and wheels. Replace any worn or damaged parts promptly.

7. TROUBLESHOOTING

If you encounter any issues with your TecTake 800089 Double Garden Lounger, refer to the following common solutions:

- **Instability/Wobbling:** Ensure all bolts and screws are securely tightened. Re-check the assembly steps to confirm all parts are correctly installed.
- **Sunshade not retracting/extending smoothly:** Check for any obstructions in the mechanism. Ensure the fabric is not caught. Clean any dirt or debris from the tracks.
- **Fabric sagging or tearing:** Ensure the weight limit is not exceeded. For significant damage, contact customer support for potential replacement parts.
- **Difficulty moving:** Check if the wheels are clean and free of debris. Ensure the ground surface is even.

If problems persist after attempting these solutions, please contact customer support.

8. SPECIFICATIONS

Model Number	403882-1
Brand	tectake
Overall Dimensions (L x W x H)	Approx. 200 cm x 185 cm x 154 cm
Sleeping Surface (L x W)	Approx. 190 cm x 134 cm
Sleeping Height from Ground	Approx. 45-54 cm
Sunshade Dimensions (L x W)	Approx. 121 cm x 185 cm
Weight	18 kg
Maximum Load Capacity	200 kg
Frame Material	Coated Metal
Fabric Material	100% Polyester
Special Features	Cushions included, Inclinable (sunshade)

9. WARRANTY AND SUPPORT

For any questions, concerns, or issues regarding your TecTake 800089 Double Garden Lounger, please contact tectake customer support. While specific warranty details are not provided in this manual, tectake offers specialized customer support to assist you.

Please have your model number (403882-1) and purchase information ready when contacting support.