

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Hinkley](#) /

› [Hinkley Atlantis Extra Large Wall Mount Outdoor Lantern Instruction Manual](#)

Hinkley 1639BZ-LL

Hinkley Atlantis Extra Large Wall Mount Outdoor Lantern Instruction Manual

Model: 1639BZ-LL

INTRODUCTION

Thank you for purchasing the Hinkley Atlantis Extra Large Wall Mount Outdoor Lantern. This manual provides essential information for the safe installation, operation, and maintenance of your new lighting fixture. Please read all instructions carefully before beginning installation and retain this manual for future reference.



Image: Hinkley Atlantis Extra Large Wall Mount Outdoor Lantern (Model 1639BZ-LL).

SAFETY INFORMATION

- **WARNING:** Risk of electric shock. Disconnect power at the fuse box or circuit breaker before installation or servicing.
- All electrical connections must be in accordance with local codes, ordinances, or the National Electric Code (NEC) and Canadian Electrical Code (CEC). Consult a qualified electrician if you are unfamiliar with proper electrical wiring.

- This fixture is suitable for wet locations. Ensure all connections are properly sealed to prevent water intrusion.
- Do not install any fixture assembly closer than 6 inches from any combustible material.
- Always wear safety glasses and appropriate protective gear during installation.
- Handle the fixture and glass components with care to avoid breakage.

PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- Hinkley Atlantis Extra Large Wall Mount Outdoor Lantern Fixture
- Mounting Hardware Kit (crossbar, mounting screws, wire nuts)
- (3) GU10 LED Bulbs
- Instruction Manual (this document)

SETUP AND INSTALLATION

Professional installation is recommended. Ensure power is disconnected at the circuit breaker before proceeding.

1. **Prepare the Mounting Surface:** Ensure the electrical box is securely mounted and capable of supporting the fixture's weight (16 lbs).
2. **Attach Mounting Crossbar:** Secure the mounting crossbar to the electrical box using the provided screws.
3. **Make Electrical Connections:**
 - Connect the fixture's **black** wire to the supply circuit's **black** (hot) wire.
 - Connect the fixture's **white** wire to the supply circuit's **white** (neutral) wire.
 - Connect the fixture's **ground** wire (bare copper or green) to the supply circuit's **ground** wire and to the mounting crossbar.
 - Secure all connections with approved wire nuts and wrap with electrical tape for added safety.
4. **Mount the Fixture:** Carefully align the fixture with the mounting screws on the crossbar. Secure the fixture to the mounting surface using the provided cap nuts or screws.
5. **Install Bulbs:** Insert the three (3) GU10 LED bulbs into their respective sockets. Ensure they are fully seated.
6. **Restore Power:** Once installation is complete and all connections are secure, restore power at the circuit breaker.



36" H



Image: Product dimensions for installation planning.



Images: Details of the light openings and etched glass lenses.

OPERATING INSTRUCTIONS

This fixture is designed for standard wall switch operation. It is also dimmable when used with compatible dimming switches (sold separately).

- **Turning On/Off:** Use the wall switch connected to the fixture to turn the light on or off.
- **Dimming Function:** If a compatible dimmer switch is installed, adjust the dimmer to control the light intensity. Ensure the GU10 LED bulbs used are dimmable.

MAINTENANCE

Regular maintenance will help preserve the appearance and functionality of your fixture.

- **Cleaning:** Clean the fixture with a soft, damp cloth. Do not use abrasive cleaners or solvents, as these may damage the finish or etched glass.
- **Bulb Replacement:**
 - a. Disconnect power to the fixture at the circuit breaker.
 - b. Allow bulbs to cool completely before handling.
 - c. Carefully remove the old GU10 LED bulb by twisting it counter-clockwise.
 - d. Insert a new 6.5W GU10 LED bulb by aligning the pins and twisting clockwise until secure.
 - e. Restore power to the fixture.
- **Inspection:** Periodically inspect the wiring and connections for any signs of wear or damage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Light does not turn on.	No power to the fixture. Loose wire connections. Faulty bulb.	Check circuit breaker and wall switch. Verify all wire connections are secure (power off). Replace bulb with a known good one.
Light flickers.	Loose bulb. Incompatible dimmer switch. Faulty bulb.	Ensure bulb is fully seated. Use a dimmer switch compatible with LED bulbs. Replace bulb.
Water inside fixture.	Improper sealing during installation. Damaged fixture component.	Disconnect power. Inspect and re-seal all connections and mounting points. Contact customer support if damage is suspected.

SPECIFICATIONS

Model Number	1639BZ-LL
Brand	Hinkley
Dimensions (L x W x H)	4" x 12" x 36"
Weight	16 lbs
Material	Aluminum
Finish	Bronze
Light Source	(3) GU10 LED Bulbs (included)
Wattage (Total)	22.5 Watts (3 x 6.5W)
Voltage	120 Volts
Brightness	1500 Lumens
Indoor/Outdoor Use	Outdoor (Wet Location Rated)
Special Features	Dimmable, Hardwired, Water Resistant
Certifications	UL & CSA Product Safety Standards

OFFICIAL PRODUCT VIDEO



Video: An overview of Hinkley outdoor lighting, showcasing thoughtful design and quality craftsmanship. This video provides a general look at the brand's outdoor lighting philosophy.

WARRANTY AND SUPPORT

Hinkley products are manufactured to the highest standards and are backed by a limited warranty. For specific warranty details, please refer to the warranty card included with your purchase or visit the official Hinkley website.

If you require technical assistance, replacement parts, or have questions regarding your Hinkley Atlantis fixture, please contact Hinkley Customer Support:

- **Website:** www.hinkley.com
- **Phone:** Refer to the Hinkley website for current contact numbers.
- **Email:** Refer to the Hinkley website for current contact email.

Please have your model number (1639BZ-LL) and purchase date available when contacting support.

© 2024 Hinkley. All rights reserved.