ONN 100012584

Onn 43" Class 4K UHD LED Smart TV HDR (Model 100012584) - Instruction Manual

Your complete guide to setting up, operating, and maintaining your Onn Smart TV.

Introduction

Welcome to the world of immersive entertainment with your new Onn 43" Class 4K UHD LED Smart TV HDR. This manual provides detailed instructions to help you set up, operate, and troubleshoot your television, ensuring you get the most out of its advanced features and stunning picture quality.

Important Safety Information

Please read all safety and operating instructions carefully before using your television. Keep these instructions for future reference. Always follow basic safety precautions to reduce the risk of fire, electric shock, and injury to persons.

- Do not block ventilation openings.
- Do not install near any heat sources.
- Protect the power cord from being walked on or pinched.
- Only use attachments/accessories specified by the manufacturer.
- Unplug this apparatus during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified service personnel.

What's in the Box

Carefully unpack the box and ensure all items are present:

- Onn 43" Class 4K UHD LED Smart TV HDR
- TV Stand (2 pieces)
- Remote Control
- Quick Start Guide (not included in this manual)
- Screws for stand attachment



Figure 1: Front view of the Onn 43" Smart TV displaying the Roku TV home screen.

Setup Guide

1. Attaching the TV Stand

Place the TV screen-down on a soft, clean surface to prevent scratches. Align the stand pieces with the screw holes on the bottom of the TV and secure them with the provided screws.



Figure 2: Angled view of the Onn 43" Smart TV, showing its slim profile and the attached stand.

2. Connecting Devices

Your Onn TV offers multiple input options. Refer to the back panel image for port locations.

- **HDMI Ports:** Connect your cable box, game console, Blu-ray player, or other HDMI devices. This model features multiple HDMI inputs.
- **USB Port:** For media playback from a USB drive.
- **Antenna/Cable In:** For connecting an antenna or cable TV.
- **Optical Audio Out:** For connecting to a soundbar or audio receiver.
- **Ethernet Port:** For a wired internet connection.



Figure 3: Rear view of the Onn 43" Smart TV, highlighting the arrangement of its input and output ports.

3. Initial Power On & Network Setup

Plug the power cord into an electrical outlet. The TV will power on and guide you through the initial setup process, including language selection, country, and network connection. For smart features, connect to your Wi-Fi network or use an Ethernet cable.

Operating Your Onn Roku TV

Remote Control Overview

The included remote control is designed for intuitive navigation of your Roku TV. It features dedicated buttons for popular streaming services and essential TV functions.





Figure 4: The Onn Roku TV remote control, showing its layout and dedicated app buttons.

- **Power Button:** Turns the TV on or off.
- **Directional Pad (D-Pad):** Navigate menus and select items.
- **OK Button:** Confirms selections.
- **Home Button:** Returns to the Roku TV home screen.

- **Back Button:** Returns to the previous screen.
- **Volume Up/Down:** Adjusts the TV volume.
- **Mute Button:** Mutes or unmutes the sound.
- **Streaming Service Buttons:** Quick access to pre-programmed streaming apps like Netflix, Disney+, etc.

Navigating the Roku TV Interface

The Roku TV interface is user-friendly and customizable. From the Home screen, you can:

- **Access Streaming Channels:** Browse and launch your favorite apps.
- **Switch Inputs:** Select connected devices like HDMI 1, HDMI 2, etc.
- **Search:** Find movies, TV shows, actors, or channels across various streaming services.
- **Adjust Settings:** Customize picture, sound, network, and system preferences.

Maintenance

To ensure the longevity and optimal performance of your Onn TV, follow these maintenance tips:

- **Cleaning:** Use a soft, dry cloth to clean the screen and TV cabinet. Do not use liquid cleaners or aerosol sprays directly on the TV.
- **Ventilation:** Ensure adequate airflow around the TV. Do not block ventilation slots.
- **Software Updates:** Your Roku TV will automatically check for and install software updates when connected to the internet. Ensure your TV is connected to receive the latest features and bug fixes.

Troubleshooting

If you encounter issues with your TV, try these common troubleshooting steps:

Problem	Solution
No Power	Check if the power cord is securely plugged into the TV and the outlet. Try a different outlet.
No Picture, but Sound is Present	Ensure the correct input source is selected. Check cable connections to external devices.
No Sound, but Picture is Present	Check volume level and mute setting. Verify audio cable connections. Try different audio output settings on the TV.
Cannot Connect to Network	Restart your router and modem. Check Wi-Fi password. Try a wired Ethernet connection if available.
Remote Not Responding	Replace batteries. Ensure no obstructions between remote and TV. Re-pair the remote if it's a Wi-Fi direct remote.

Specifications

Feature	Detail
Brand	ONN

Feature	Detail
Model	100012584
Screen Size	43 Inches
Display Technology	LED
Resolution	4K UHD
Refresh Rate	60 Hz
Aspect Ratio	16:9
Connectivity Technology	HDMI
Supported Internet Services	YouTube, Browser (and other Roku apps)
Item Weight	22 pounds
Package Dimensions	42.13 x 25.2 x 5.51 inches






Figure 5: Energy Guide label providing estimated yearly energy cost for the Onn 43" TV.

Warranty and Support

For warranty information and technical support, please refer to the warranty card included with your product or visit the official Onn support website. Keep your purchase receipt for warranty claims.

© 2023 ONN. All rights reserved.
This manual is for informational purposes only. Product specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question