

[Manuals.plus](#) /

› [ROCCAT](#) /

› ROCCAT Kone Pro PC Gaming Mouse Instruction Manual

ROCCAT ROC-11-400-01

ROCCAT Kone Pro PC Gaming Mouse Instruction Manual

Brand: ROCCAT | Model: ROC-11-400-01

1. OVERVIEW

The ROCCAT Kone Pro is a lightweight optical performance gaming mouse designed for superior comfort and precision. It features advanced optical switches, a high-resolution sensor, and customizable RGB lighting, making it suitable for various gaming styles.



Figure 1: ROCCAT Kone Pro PC Gaming Mouse (Black)

2. PACKAGE CONTENTS

- Kone Pro (Ash Black) / (Arctic White) Gaming Mouse
- Quick-start guide
- Extra set of mouse feet

3. SETUP

1. **Connect the Mouse:** Plug the PhantomFlex cable of the Kone Pro mouse into an available USB port on your PC. The mouse is plug-and-play, but for full functionality, software installation is recommended.
2. **Install ROCCAT Swarm Software:** Download the latest version of ROCCAT Swarm software from the official ROCCAT website. This software allows for customization of DPI settings, button assignments, RGB lighting, and more.
3. **Driver Installation:** Follow the on-screen instructions to install any necessary drivers.



Figure 2: ROCCAT Kone Pro Mouse Dimensions

4. KEY FEATURES

- **Ergonomic Design:** The Kone Pro features an iconic shape refined through anthropometric research, providing superior comfort for various hand sizes and grip styles. Weighing just 66g, it offers a lightweight yet robust feel.
- **ROCCAT Bionic Shell:** A solid, lightweight honeycomb shell with a translucent fade on the main clicks showcases vivid AIMO 16.8 million color RGB lighting while protecting internal components.
- **Titan Switch Optical:** Faster than traditional mechanical switches, these optical switches provide a 100 million click life cycle and speed-of-light actuation for enhanced precision.
- **ROCCAT Owl-Eye Optical Sensor:** Experience smooth and precise tracking with the world-leading 19K DPI optical

sensor.

- **PhantomFlex Cable:** Designed for a near-wireless experience, this flexible and light cable minimizes drag and interference during use.
- **Heat-Treated Pure PTFE Glides:** Pre-tuned for incredible glide and smooth mouse movements right out of the box.
- **Titan Wheel Pro:** Milled from solid aluminum, this wheel offers a satisfying scroll and tactile click, combining lightweight durability with precision engineering.



Figure 3: AIMO RGB Lighting on Kone Pro



Figure 4: Titan Switch Optical Mechanism



Figure 5: Underside showing PTFE Glides

Your browser does not support the video tag.

Video 1: Official product video showcasing the features and design of the ROCCAT Kone Pro Gaming Mouse.

5. OPERATING INSTRUCTIONS

- **Basic Functionality:** The left and right click buttons, along with the scroll wheel, function as standard mouse inputs.
- **DPI Adjustment:** Use the dedicated DPI buttons (if available and configured via Swarm) to cycle through different sensitivity levels (up to 19,000 DPI) to match your preference.
- **Customization with Swarm:** The ROCCAT Swarm software allows you to:
 - Reassign buttons for specific functions or macros.
 - Adjust DPI stages and polling rate.
 - Customize AIMO RGB lighting effects and colors.
 - Create and manage profiles for different games or applications.

6. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the mouse surface. For stubborn dirt, a slightly damp cloth can be used, ensuring no liquid enters the mouse. Avoid harsh chemicals.
- **Sensor Care:** Keep the optical sensor on the underside of the mouse clean and free from dust or debris for optimal tracking performance.
- **Cable Management:** Avoid sharp bends or excessive pulling on the PhantomFlex cable to prevent damage. Use the included cable tie for neat storage.
- **PTFE Glides:** The heat-treated PTFE glides are durable, but if they show significant wear, use the included extra set for replacement to maintain smooth movement.

7. TROUBLESHOOTING

- **Mouse Not Responding:** Try plugging the mouse into a different USB port. Restart your computer. Ensure ROCCAT Swarm software is up to date.
- **Tracking Issues:** Clean the optical sensor on the underside of the mouse. Ensure your mouse pad surface is clean and suitable for optical tracking.
- **RGB Lighting Not Working:** Check the lighting settings in ROCCAT Swarm. Ensure the software is running and updated.
- **Buttons Not Functioning:** Verify button assignments in ROCCAT Swarm. Test the mouse on another computer to

rule out system-specific issues.

8. SPECIFICATIONS

Feature	Detail
Brand	ROCCAT
Model Number	ROC-11-400-01
Connectivity Technology	Wired (PhantomFlex Cable)
Movement Detection Technology	Optical (Owl-Eye Sensor)
Max DPI	19,000 DPI
Switches	Titan Switch Optical (100 million click life cycle)
Weight	66g
Dimensions (LxWxH)	4.94 x 2.83 x 1.57 inches
RGB Lighting	AIMO RGB (16.8 million colors)
Glides	Heat-Treated Pure PTFE
Scroll Wheel	Titan Wheel Pro (Aluminum)

9. WARRANTY AND SUPPORT

The ROCCAT Kone Pro PC Gaming Mouse comes with a **2-year limited manufacturer warranty**. For technical support, driver updates, or further assistance, please visit the official ROCCAT support website or contact their customer service.

Online Support: www.roccat.com/support