

[manuals.plus](#) /

› [Playmobil](#) /

› [Playmobil EverDreamerz Edwina Music World Figure Set 70584 Instruction Manual](#)

Playmobil 70584

Playmobil EverDreamerz Edwina Music World Figure Set 70584 Instruction Manual

1. INTRODUCTION

Welcome to the magical world of Playmobil EverDreamerz! This instruction manual provides detailed guidance for the Edwina Music World Figure Set (Model 70584). Edwina, an adventurous and sporty character, brings her energy and rhythm to the drums in the glamorous Music World. This set encourages imaginative play and musical discovery.

2. WHAT'S IN THE BOX

Your Playmobil EverDreamerz Edwina Music World set includes the following components:

- 1 Edwina character figure
- 1 Drum set
- 1 Bracelet
- Beads
- 1 Collectible card
- Stickers
- Various accessories
- Instruction manual



Figure 2.1: Front view of the Playmobil EverDreamerz Edwina Music World Figure Set 70584 packaging.

5 GIRLS **COLLECT THEM ALL**



70580
Rosalee



70581
Viona



70582
Starleen



70583
Clare



70584
Edwina

+ 12 SURPRISE CHARACTERS IN SURPRISE BOXES

7 SURPRISES INSIDE



smart device not included

Discover the EverDreamerz

live in Concert

For more information about the app
EverDreamerz in Concert
visit everdreamerz.playmobil.com/app
or your app store



Download on the
App Store



GET IT ON
Google Play



2.95 in · 7.5 cm

Figure 2.2: Back view of the packaging, illustrating the included components and other EverDreamerz figures.

3. SETUP AND ASSEMBLY

The Playmobil EverDreamerz Edwina Music World set consists of 47 pieces. Assembly is generally not required for the main components, as figures and accessories are designed for immediate play. However, some smaller accessories may need to be placed or attached to the figure or drum set. Refer to the included instruction manual for specific assembly steps for any minor parts.

The pieces are designed to be robust and suitable for small hands, ensuring ease of handling during play.



Figure 3.1: Assembled Edwina figure with her drum set, ready for play.

4. OPERATING INSTRUCTIONS

The Playmobil EverDreamerz Edwina Music World set is designed for imaginative role-play. Children aged 5 years and older can engage in various scenarios:

- **Character Interaction:** Position Edwina with her drum set to simulate musical performances.
- **Accessory Use:** Utilize the bracelet, beads, collectible card, and other accessories to enhance storytelling and character customization.
- **Creative Play:** Encourage children to create their own musical adventures and challenges for Edwina within the EverDreamerz Music World.

This set promotes creativity and social interaction through imaginative play and musical discovery.

5. MAINTENANCE

To ensure the longevity of your Playmobil set, follow these simple maintenance guidelines:

- **Cleaning:** Pieces without stickers can be cleaned simply under running water. Avoid using chemical agents, as these may damage the plastic or painted details.
- **Storage:** Store the set in a clean, dry place away from direct sunlight to prevent discoloration or material degradation.
- **Handling:** While robust, avoid excessive force or bending of parts to prevent breakage.

6. TROUBLESHOOTING

If you encounter any issues with your Playmobil EverDreamerz Edwina Music World set, consider the following:

- **Missing Pieces:** Carefully check all packaging materials. If a piece is genuinely missing, contact Playmobil customer support (see Section 8).
- **Assembly Difficulties:** Re-examine the included instruction manual for detailed diagrams and steps. Ensure all parts are correctly oriented.
- **Damaged Parts:** If any part is damaged upon opening, contact the retailer or Playmobil customer support for assistance.

7. SPECIFICATIONS

Feature	Detail
Model Number	70584
ASIN	B08KVYVGRQ
Brand	Playmobil
Theme	Music
Character	Edwina
Number of Pieces	47
Material	Plastic
Product Dimensions (L x W x H)	14.2 x 18.7 x 7.2 cm
Product Weight	170 grams
Recommended Age	5 years and up
Educational Value	Encourages creativity and social interaction through imaginative play and musical discovery.

8. SAFETY INFORMATION

WARNING:

Not suitable for children under 3 years due to small parts. Choking hazard.

Always supervise young children during play to prevent accidents.

9. WARRANTY AND SUPPORT

Playmobil products are manufactured to high-quality standards. In the unlikely event of a defect or if you require replacement parts, please contact Playmobil customer service. Keep your proof of purchase for any warranty claims.

For further assistance, visit the official Playmobil website or contact their customer support directly.