

Dream B091CLZNFQ

Dream Stainless Steel Electric Kettle

Model: B091CLZNFQ | Brand: Dream

INTRODUCTION

Thank you for purchasing the Dream Stainless Steel Electric Kettle. This manual provides important information regarding the safe operation, maintenance, and care of your appliance. Please read these instructions thoroughly before first use and retain them for future reference.

This electric kettle is designed for boiling water quickly and efficiently for hot beverages, cooking, and instant foods.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock, and injury to persons, do not immerse cord, plugs, or electric kettle in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner. Contact customer support for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or injury to persons.
- Do not use outdoors.

- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to “off,” then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Scalding may occur if the lid is removed during the heating cycle.
- This appliance is for household use only.

PRODUCT OVERVIEW

The Dream Stainless Steel Electric Kettle consists of the following main components:

- **Kettle Body:** The main stainless steel container for water.
- **Lid:** Covers the kettle opening.
- **Handle:** For safe pouring and carrying.
- **Power Base:** The detachable base that connects to the power outlet and heats the kettle.
- **On/Off Switch:** Activates or deactivates the heating element.
- **Water Level Indicator:** Shows the amount of water inside the kettle.



A silver stainless steel electric kettle with a black handle and base, designed for rapid water boiling. It features a sleek, modern design suitable for any kitchen.

SETUP

1. **Unpacking:** Carefully remove the kettle and all accessories from the packaging. Dispose of packaging materials responsibly.
2. **Initial Cleaning:** Before first use, fill the kettle with clean water to the maximum level. Boil the water, then discard it. Repeat this process 2-3 times to remove any manufacturing residues.
3. **Placement:** Place the power base on a flat, stable, heat-resistant surface, away from the edge of the counter. Ensure the power cord is not dangling where it can be pulled or tripped over.

OPERATING INSTRUCTIONS

1. **Fill the Kettle:** Open the lid and fill the kettle with the desired amount of water. Do not fill below the minimum mark or above the maximum mark (1.5 liters). Overfilling may cause boiling water to spill out.
2. **Close the Lid:** Ensure the lid is securely closed before operating the kettle.
3. **Place on Power Base:** Place the kettle firmly onto the power base.
4. **Plug In:** Plug the power cord into a standard electrical outlet.
5. **Turn On:** Press the On/Off switch to the 'On' position. The indicator light will illuminate, signaling that the kettle is heating.
6. **Automatic Shut-off:** The kettle will automatically turn off once the water has boiled. The indicator light will extinguish.
7. **Pouring:** Carefully lift the kettle from the power base and pour the hot water. Be cautious of steam and hot surfaces.
8. **Re-boiling:** If you need to re-boil water, wait a few moments for the automatic shut-off mechanism to reset before pressing the On/Off switch again.

MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure the longevity and optimal performance of your kettle.

Exterior Cleaning

- Always unplug the kettle and allow it to cool completely before cleaning.
- Wipe the exterior of the kettle with a soft, damp cloth. Do not use abrasive cleaners or scouring pads, as they may scratch the stainless steel finish.
- Ensure the power base and electrical connections remain dry.

Descaling (Removing Mineral Deposits)

Over time, mineral deposits (limescale) may build up inside the kettle, especially in hard water areas. This can affect performance and taste. Descale your kettle regularly.

- Fill the kettle with a mixture of one part white vinegar and two parts water.
- Bring the mixture to a boil and then let it stand for at least 30 minutes, or longer for heavy deposits.

- Pour out the mixture and rinse the kettle thoroughly with fresh water several times.
- For stubborn deposits, you may need to repeat the process or use a commercial descaling solution following its instructions.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Kettle does not heat up.	Not plugged in; power switch not activated; kettle not properly seated on base; power outage.	Check power connection; press On/Off switch; ensure kettle is correctly placed on base; check household circuit breaker.
Kettle turns off before boiling.	Too little water; limescale buildup.	Ensure water level is above minimum mark; descale the kettle.
Water tastes unusual.	New kettle residue; limescale buildup.	Perform initial cleaning steps (boil and discard water several times); descale the kettle.
Lid does not close properly.	Obstruction; lid mechanism issue.	Check for any foreign objects; contact customer support if mechanism is faulty.

SPECIFICATIONS

- **Model:** B091CLZNFQ
- **Brand:** Dream
- **Capacity:** 1.5 Liters
- **Material:** Stainless Steel
- **Color:** Silver
- **Power:** 1500 Watts
- **Special Features:** Automatic Shut-off
- **Care Instructions:** Hand wash, wipe clean
- **Recommended Uses:** Boiling water for hot beverages, cooking, instant foods

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the warranty card included with your purchase or contact the retailer where the product was purchased. Keep your proof of purchase for any warranty claims.

If you encounter any issues not covered in this manual, please contact Dream customer service for assistance.

