YING RAY A2-TWINS-NEW(T-B10)-11

YING RAY Replacement Infrared Remote Control User Manual

For ClassicFlame Fireplace Stove Heaters

1. Introduction

This manual provides detailed instructions for the setup, operation, and maintenance of your YING RAY replacement infrared remote control. This remote is designed to function with specific Twin Star ClassicFlame and Duraflame fireplace stove heater models. Please read this manual thoroughly before use to ensure proper functionality and safety.

2. Compatibility

This replacement remote control is specifically designed for the following fireplace stove heater models:

- Twin Star ClassicFlame 19HM8000
- Twin Star ClassicFlame 19QI071ARA
- Twin Star ClassicFlame 19QH8000-W500
- Model (T-B10)

Important: This is NOT a universal remote control. It is crucial to verify your fireplace heater's model number against the list above to ensure compatibility. If you are uncertain, please contact the seller for assistance before use.



Figure 1: YING RAY Replacement Remote Control with graphic indicating compatible models.

3. Product Overview

The YING RAY replacement remote control features a straightforward button layout for easy operation of your fireplace heater.






Figure 2: Front view of the remote control, showing all buttons.







Figure 3: Back view of the remote control, showing the battery compartment cover.

4. Setup: Battery Installation

The remote control requires two AAA 1.5V batteries (not included).

1. Locate the battery compartment on the back of the remote control.
2. Press down on the tab and slide the battery cover downwards to open it.
3. Insert two AAA 1.5V batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.



Figure 4: Remote control with the battery compartment open, showing where to insert AAA batteries.

5. Operating Instructions

Once batteries are installed, the remote control is ready for use without any additional programming. Point the remote directly at the infrared receiver on your fireplace heater.

- **POWER Button:** Press to turn the fireplace heater ON or OFF.
- **HEATER Button:** Activates or deactivates the heating function.
- **ECO Button:** Engages or disengages the Economy mode, which optimizes energy consumption.
- **OSCILLATION Button:** Controls the oscillation feature, if available on your heater, to distribute heat more widely.
- **NIGHT Button:** Activates or deactivates the Night mode, often reducing light intensity or fan speed for quieter operation.
- **TIMER Button:** Sets or adjusts the operational timer for the fireplace heater. Refer to your heater's main manual for specific timer settings.

6. Maintenance

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Battery Replacement:** Replace batteries when the remote's range decreases or it stops responding. Always replace both batteries at the same time.
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage and damage.

7. Troubleshooting

If your remote control is not functioning as expected, consider the following:

- **Remote not responding:**
  - Ensure fresh AAA batteries are correctly installed with proper polarity.
  - Check for any obstructions between the remote control and the fireplace heater's infrared receiver.
  - Ensure you are within the effective operating range and pointing the remote directly at the heater.
- **Intermittent operation:**
  - Batteries may be low; replace them.
  - Ensure the remote's infrared emitter is clean and free from debris.

If issues persist after following these steps, please contact the seller for further assistance.

8. Specifications

Brand	YING RAY
Model Number	A2-TWINS-NEW(T-B10)-11
Compatible Devices	Twin Star ClassicFlame 19HM8000, 19QI071ARA, 19QH8000-W500, (T-B10)

Controller Type	Infrared Button Control
Power Source	2 x AAA 1.5V Batteries (not included)
Special Feature	Ergonomic Design

9. Warranty and Support

For warranty information or technical support, please refer to the documentation provided with your original purchase or contact the YING RAY customer service directly through the retailer where the product was purchased. Please have your purchase details and product model number ready when contacting support.