

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [NEBO](#) /
- › [NEBO Torchy 2K USB Rechargeable LED Flashlight User Manual](#)

NEBO NEB-FLT-1006-G

NEBO Torchy 2K USB Rechargeable LED Flashlight User Manual

Model: NEB-FLT-1006-G

INTRODUCTION

Thank you for choosing the NEBO Torchy 2K USB Rechargeable LED Flashlight. This powerful and compact flashlight is designed for various applications, offering multiple lighting modes and convenient magnetic charging. Please read this manual carefully to ensure proper use and maintenance of your device.



Image: The NEBO Torchy 2K flashlight, showcasing its compact design and removable pocket clip.

PRODUCT OVERVIEW

The NEBO Torchy 2K is a high-performance LED flashlight featuring a durable aluminum body, multiple light modes, and a magnetic base for hands-free operation. It is designed for reliability and ease of use in various environments.

Key Components:

- **LED Emitter:** Provides powerful illumination.
- **Power Button:** Controls power and mode selection.
- **Magnetic Charging Port:** Located at the base for easy recharging.
- **Removable Pocket Clip:** For secure attachment to pockets or belts.
- **Magnetic Base:** Allows for hands-free mounting on metallic surfaces.
- **Anodized Aluminum Body:** Ensures durability and impact resistance.

SETUP

Initial Charging:

Before first use, fully charge the NEBO Torchy 2K flashlight. The device comes with a magnetic USB charging cable.

1. Connect the USB end of the charging cable to a power source (e.g., computer, USB wall adapter).
2. Attach the magnetic end of the cable to the charging port at the base of the flashlight. The magnetic connection will snap into place.
3. The charging indicator light on the magnetic cable will illuminate to show charging status. Refer to the [Charging Status Indicator](#) section for details.
4. Allow the flashlight to charge until the indicator shows a full charge.



Image: Close-up view of the magnetic charging base connecting to the flashlight.

Attaching/Removing the Pocket Clip:

The NEBO Torchy 2K includes a removable dual-position pocket clip for versatile carrying options.

- To attach, slide the clip onto the flashlight body into the desired groove.
- To remove, gently slide the clip off the flashlight body.



Image: The NEBO Torchy 2K flashlight demonstrating its removable pocket clip, allowing for flexible attachment.

OPERATING INSTRUCTIONS

The NEBO Torchy 2K features a single power button for all operations.

Power On/Off and Mode Cycling (Default):

1. Press the power button once to turn the flashlight ON. It will typically start in High mode.
2. Press the power button repeatedly to cycle through the standard lighting modes: High > Medium > Low.
3. After approximately 10 seconds in any mode, a single press of the power button will turn the flashlight OFF. If pressed before 10 seconds, it will cycle to the next mode.

Alternative Mode Cycling (Starting from Low):

To start the flashlight in Low mode and cycle upwards:

1. While the flashlight is OFF, press and hold the power button. The flashlight will turn ON in Low mode.
2. Release the button. Subsequent presses will cycle through Medium > High.
3. After approximately 10 seconds in any mode, a single press of the power button will turn the flashlight OFF.

Activating Turbo Mode (2000 Lumens):

Turbo mode provides maximum brightness for short bursts.

- From any ON mode, press and hold the power button to activate Turbo mode.
- Release the button to return to the previously selected mode.
- *Note: Turbo mode is designed for temporary use and may automatically step down in brightness to prevent overheating.*

Activating Strobe Mode:

Strobe mode is used for signaling or disorienting.

- From any ON or OFF state, quickly double-press the power button to activate Strobe mode.
- Press the power button once to turn the flashlight OFF.



Image: A person holding the NEBO Torchy 2K flashlight, demonstrating its illumination capability.

CHARGING

The NEBO Torchy 2K is equipped with a 2200 mAh Lithium-ion rechargeable battery and a magnetic charging system.

Charging Status Indicator:

- **Red Light:** Indicates the battery is charging.
- **Blue Light:** Indicates the battery is fully charged.

A full charge can provide up to 30 hours of operation on the lowest setting.



Image: The NEBO Torchy 2K flashlight connected to its magnetic charging cable, illustrating the charging process.

LIGHTING MODES AND PERFORMANCE

The Torchy 2K offers five distinct lighting modes to suit various needs:

Mode	Lumens	Run Time	Beam Distance
Turbo	2000	30 seconds (max)	200 meters
High	500	3.5 hours	100 meters
Medium	200	6 hours	60 meters
Low	35	30 hours	25 meters
Strobe	2000	2.5 hours	200 meters

Note: Run times may vary based on environmental conditions and battery age. Turbo mode is limited to 30 seconds to prevent overheating and will automatically revert to the previous mode.

MAINTENANCE

Cleaning:

- Wipe the flashlight body with a soft, damp cloth to remove dirt and debris.
- Do not use abrasive cleaners or solvents, as these can damage the finish.
- Keep the lens clean for optimal light output. Use a lens cleaning cloth if necessary.

Battery Care:

- To prolong battery life, avoid fully discharging the battery frequently.
- If storing the flashlight for an extended period, charge it to approximately 50% every 3-6 months.
- Store in a cool, dry place.

Water Resistance (IPX6):

The Torchy 2K is rated IPX6, meaning it is protected against powerful water jets. It is not designed for submersion.

- Ensure the magnetic charging port is clean and free of debris to maintain water resistance.
- Do not attempt to charge the flashlight if the charging port or cable is wet.



Image: The NEBO Torchy 2K flashlight on a wet surface, illustrating its IPX6 water-resistant design.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Flashlight does not turn on.	Battery is depleted.	Charge the flashlight fully.
Flashlight does not turn on.	Power button malfunction.	Contact customer support if charging does not resolve the issue.
Flashlight does not charge.	Charging cable not properly connected.	Ensure the magnetic cable is securely attached to the flashlight and the USB end is connected to a working power source.
Flashlight does not charge.	Faulty charging cable or power source.	Try a different USB power source or charging cable if available.

Problem	Possible Cause	Solution
Light output is dim.	Low battery.	Recharge the flashlight.
Light output is dim.	Dirty lens.	Clean the lens with a soft cloth.

SPECIFICATIONS

Feature	Detail
Model Number	NEB-FLT-1006-G
Light Source	LED
Max Lumens	2000 lm (Turbo)
Battery Type	1 Lithium-ion (included)
Battery Capacity	2200 mAh
Voltage	3.7 Volts
Material	Anodized Aluminum
Color	Black/Grey
Dimensions (L x W x H)	2.7 x 2.7 x 11 cm (1.06 x 1.06 x 4.33 inches)
Weight	113 g (3.99 oz)
Water Resistance Rating	IPX6
Special Features	Durable, Lightweight, Magnetic Base, Removable Clip



Image: The NEBO Torchy 2K flashlight utilizing its magnetic base to attach to a metal surface for hands-free illumination.

WARRANTY AND SUPPORT

NEBO products are designed for durability and performance. For specific warranty information and customer support, please refer to the official NEBO website or contact their customer service directly.

For further assistance, visit the [NEBO Official Website](#).