MYNTA MC1611

MYNTA MC1611 Massage Chair User Manual

Brand: MYNTA | Model: MC1611

1. Safety Information

Important Safety Instructions:

- Do not exceed the maximum weight recommendation of 260 pounds.
- Always follow the assembly instructions carefully to ensure safe and proper use of the chair.
- Ensure the chair is placed on a hard, level surface.
- Keep children and pets away from the chair during operation.
- Unplug the chair from the power outlet when not in use or before cleaning.

2. Product Overview

The MYNTA MC1611 Massage Chair is designed to provide a comprehensive full-body massage experience. It features an advanced SL-track system, 3D robot hands, multiple airbag massage zones, zero gravity recline, heat therapy, foot rollers, and integrated Bluetooth speakers for an enhanced relaxation session.



Figure 2.1: MYNTA MC1611 Massage Chair - Front View



Figure 2.2: MYNTA MC1611 Massage Chair Dimensions

3. Setup

The MYNTA MC1611 Massage Chair requires no complex assembly. Upon delivery, ensure the chair is placed in your desired location, allowing sufficient space for recline and movement. Connect the power cord to a suitable electrical outlet. Ensure all packaging materials are removed before initial use.

4. Operating Instructions

The massage chair is operated via its wired remote control. Familiarize yourself with the remote's layout and functions before starting a massage program.




Figure 4.1: Remote Control Overview

To begin, press the power button on the remote. Select an automatic program or customize your massage using the manual controls for specific massage techniques, intensity, and target areas.

5. Massage Programs and Features

5.1. 3D Robot Hands Massage

The chair features 3D robot hands that mimic human touch, providing kneading, knocking, tapping, shiatsu, and rolling massage techniques. These rollers adjust to the contours of your body for a personalized experience.




Figure 5.1.1: 3D Robot Hands Massage

5.2. Extended SL-Track

The extended SL-track guides the massage rollers from your neck down to your hips, ensuring comprehensive coverage of your spine and glutes. The chair performs a body scan to adjust massage points to suit individual body types.




Figure 5.2.1: Extended SL-Track and Body Scan

5.3. Full Body Airbag Massage

Equipped with 32 airbags, the chair provides compression massage to various body parts including shoulders, arms, hips, calves, and feet. This helps relieve pain and tension and promotes circulation.



Figure 5.3.1: Full Body Airbag Massage Zones

5.4. Zero Gravity Positions

Experience three levels of zero gravity recline, which effectively reduces heart pressure and stimulates blood circulation by elevating your legs above your heart. This position enhances the massage experience.



Figure 5.4.1: Three Levels of Zero Gravity

5.5. Heat Therapy

Lumbar and calf heating elements provide soothing warmth to relieve muscle soreness and promote blood circulation.

5.6. Foot Rollers

Integrated foot rollers deliver a shiatsu massage to the soles of your feet, targeting pressure points for deep relaxation. The footrest is extendable to accommodate different user heights.

5.7. Bluetooth Speakers

Connect your device via Bluetooth to the integrated speakers to enjoy music or audio during your massage session.




Figure 5.7.1: Wireless Bluetooth Speaker and Easy Movement Wheels

5.8. Automatic Massage Programs

The chair offers 7 auto massage programs tailored for different needs, including Neck & Shoulder, Waist & Hips, For Him, For Her, Senior, Sleep, and Thai Stretch.

5.9. Thai Stretch

The Thai Stretch program gently stretches the body, helping to decompress the spine and improve flexibility.

Your browser does not support the video tag.

Video 5.9.1: Overview of MYNTA 3D Full Body Massage Chair features, including SL-track, airbags, zero gravity, and Bluetooth speakers.

Your browser does not support the video tag.

Video 5.9.2: Detailed demonstration of the MYNTA Massage Chair's 3D SL-Track and full body recline functions.

6. Maintenance

To maintain your MYNTA MC1611 Massage Chair, regularly wipe clean all surfaces with a soft, damp cloth. Avoid using harsh chemicals

or abrasive cleaners, as these can damage the material. Ensure the chair is unplugged before cleaning.

7. Troubleshooting

If you encounter any issues with your massage chair, please refer to the following general troubleshooting tips:

- **No Power:** Ensure the power cord is securely plugged into both the chair and a working electrical outlet. Check the power switch on the chair.
- **Massage Not Starting:** Verify that the remote control is properly connected and powered on. Select an auto program or manually activate massage functions.
- **Unusual Noises:** Discontinue use and inspect the chair for any obstructions. If the noise persists, contact customer support.
- **Remote Control Not Responding:** Check the remote's connection. If it's a wireless remote (this model uses wired), check batteries.

For persistent issues, please contact MYNTA customer support.

8. Specifications

Feature	Detail
Brand	MYNTA
Model Number	MC1611
Color	Black
Product Dimensions (D x W x H)	39"D x 30"W x 66"H
Item Weight	199 Pounds
Maximum Weight Recommendation	260 Pounds
Recommended Uses	Massage
Room Type	Indoor
Age Range Description	Adult
Included Components	Remote
Surface Recommendation	Hard Floor
Indoor Outdoor Usage	Indoor
Reclining Position Count	2
Required Assembly	No
Back Style	Solid Back
Pattern	Dual pattern
Finish Types	Oil Rubbed
Leg Style	Straight Leg
Chair Backrest Width	30 Inches
Frame Material Type	Wood
Product Care Instructions	Wipe Clean
Seat Material	Leather

Fill Material	Foam

9. Warranty and Support

For warranty information or to contact customer support, please refer to the documentation included with your purchase or visit the official MYNTA website. Customer support is available to assist with any product-related inquiries or service needs.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question