Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

truke Fit 1+

truke Fit 1+ True Wireless Earbuds User Manual

Model: Fit 1+

1. Introduction

This manual provides comprehensive instructions for the setup, operation, maintenance, and troubleshooting of your truke Fit 1+ True Wireless Earbuds. Please read this manual carefully before using the product to ensure optimal performance and longevity.



Image 1.1: truke Fit 1+ Earbuds and Charging Case.

2. Package Contents

Verify that all items listed below are present in your product packaging:

- 2 x Bluetooth Earbuds (Left and Right)
- 1 x Charging Case
- 1 x Type-C Charging Cable
- 1 x User Manual
- 1 x Warranty Card
- 2 pairs of Eartips (additional sizes)

3. Product Overview

The truke Fit 1+ earbuds feature a compact design with touch controls and a portable charging case.

Earbud Components:

- Touch Control Area
- LED Indicator
- Microphone
- Charging Contacts
- Silicone Eartip

Charging Case Components:

- Earbud Charging Slots
- Battery Level Display
- Type-C Charging Port (located at the back/bottom)

4. Setup

4.1 Charging the Earbuds and Case

For first-time use, fully charge the earbuds and charging case.

1. Place the earbuds into the charging case. Ensure they are correctly seated in their respective L/R slots.
2. Connect the Type-C charging cable to the charging port on the case and to a USB power source.
3. The LED indicator on the earbuds and the digital display on the case will show charging status.
4. A full charge for the earbuds provides up to 8 hours of playtime. The 300mAh charging case provides an additional 22 hours, totaling up to 30 hours of playtime.



Image 4.1: Charging case with earbuds, showing battery life.

4.2 Pairing with a Device

The earbuds utilize Bluetooth 5.1 for stable and fast connectivity.

1. Open the charging case. The earbuds will automatically power on and enter pairing mode.
2. On your smartphone or Bluetooth-enabled device, navigate to the Bluetooth settings.
3. Search for available devices and select "Truke Fit 1+" from the list.
4. Once connected, the earbuds will indicate successful pairing (e.g., an audible prompt or LED change).
5. The earbuds will automatically reconnect to the last paired device when taken out of the case, if Bluetooth is enabled on the device.



Image 4.2: Bluetooth pairing process.

5. Operating Instructions

5.1 Power On/Off

- **Power On:** Open the charging case, or long-press the touch control area on both earbuds for 2-3 seconds.
- **Power Off:** Place the earbuds back into the charging case and close the lid, or long-press the touch control area on both earbuds for 5 seconds.

5.2 Touch Controls

The truke Fit 1+ earbuds feature intuitive touch controls for various functions.

- **Play/Pause Music:** Single tap on either earbud.
- **Next Track:** Double tap on the right earbud.
- **Previous Track:** Double tap on the left earbud.

- **Answer/End Call:** Single tap on either earbud.
- **Reject Call:** Long press on either earbud for 2 seconds.
- **Activate Voice Assistant (Google Assistant/Siri):** Triple tap on the left earbud.



Image 5.1: Touch control functions.

5.3 Dedicated Gaming Mode

Enhance your gaming experience with reduced audio latency.

- **Activate Gaming Mode:** Triple tap on the right earbud.
- This mode provides low latency of up to 85ms (with SBC Codec) for synchronized audio during gameplay.
- To exit Gaming Mode, triple tap the right earbud again.



Image 5.2: Dedicated Gaming Mode.

6. Maintenance

6.1 Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Remove eartips and clean them separately with mild soap and water, then dry thoroughly before reattaching.
- Ensure charging contacts on both earbuds and case are free from dust and debris.

6.2 Storage

- Store the earbuds in their charging case when not in use to protect them and keep them charged.
- Avoid storing in extreme temperatures or high humidity.

6.3 Water Resistance (IPX4)

The truke Fit 1+ earbuds are rated IPX4 water-resistant, meaning they are protected against splashing water from any direction.

- They are suitable for use during workouts and light rain.
- Do not submerge the earbuds in water or expose them to heavy rain or strong jets of water.
- The charging case is not water-resistant.



Image 6.1: IPX4 Water and Sweat Resistance.

7. Troubleshooting

If you encounter issues with your truke Fit 1+ earbuds, refer to the following common solutions:

Problem	Possible Solution

Problem	Possible Solution
Earbuds not pairing	• Ensure earbuds are charged. • Turn off Bluetooth on your device and turn it back on. • Forget "Truke Fit 1+" in your device's Bluetooth settings and re-pair. • Place earbuds back in the case, close the lid, wait a few seconds, then open to reset.
Only one earbud working	• Ensure both earbuds are charged. • Place both earbuds back in the charging case, close the lid, then take them out together. • Perform a factory reset (refer to specific instructions if available, or try forgetting the device and re-pairing).
No sound or low volume	• Adjust volume on both your device and the earbuds. • Ensure earbuds are properly connected to your device. • Clean any debris from the earbud speaker mesh.
Earbuds not charging	• Ensure the charging cable is securely connected. • Verify the charging case has power. • Clean the charging contacts on both earbuds and the case.

8. Specifications

Feature	Detail
Model Name	truke Fit 1+
Model Number	B097
Connectivity Technology	Bluetooth 5.1
Audio Driver Size	10mm Dynamic Driver
Audio Codec Support	AAC, SBC
Earbud Playtime (Single Charge)	Up to 8 hours
Total Playtime (with Charging Case)	Up to 30 hours (300mAh case)
Charging Time	Approximately 1.5 - 2 hours for earbuds and case
Water Resistance Rating	IPX4 (Earbuds only)
Dedicated Gaming Mode	Yes, with low latency (up to 85ms)
Control Type	Touch Control
Compatible Devices	Android, Windows, iOS devices
Item Weight	41 grams (total)

Feature	Detail
Product Dimensions	7.1 x 4 x 3.1 cm

9. Warranty and Support

9.1 Warranty Information

The truke Fit 1+ True Wireless Earphones come with a **6-month warranty** from the date of purchase.

- Mandatory registration is required on the truke website within 10 days of purchase to activate the warranty.
- Please retain your proof of purchase for warranty claims.

9.2 Customer Support

For any queries, technical assistance, or warranty claims, please contact truke customer support:

- **Contact Number:** +919354170767
- **Email:** support@eccentricindia.com
- **Importer:** Eccentric Enterprises Private Limited, Office No. 111, 1st Floor, Maruti Chamber, Plot No. 857-A, Kalamboli, NAVI MUMBAI, Raigarh, Maharashtra, India, 410218.

© 2023 truke. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B091GV4N28

More documents and user manuals: **https://manuals.plus/**