

[Manuals.plus](#) /

› [Serta](#) /

› Serta Heated Throw Blanket User Manual - Model ST54-0032

Serta ST54-0032

Serta Heated Throw Blanket User Manual - Model ST54-0032

Reversible Fleece to Sherpa Electric Blanket

1. INTRODUCTION

This manual provides instructions for the safe and effective use of your Serta Heated Throw Blanket, Model ST54-0032. This premium heated throw features a cozy fleece fabric reversible to soft sherpa, designed to provide warmth and comfort. It includes multiple heat settings and an automatic shut-off timer for user convenience and safety.




Image 1.1: Serta Heated Throw Blanket (Blue) in a living room setting.

2. IMPORTANT SAFETY INFORMATION


Please read all safety instructions carefully before using this product. Failure to follow these instructions may result in electric shock, fire, or injury.

- The Serta Heated Throw Blanket is ETL certified, meeting high safety standards.
- Always plug the device directly into a wall outlet. Do not use extension cords or power strips.
- Do not leave the controller covered when the blanket is in use to prevent overheating.
- This product is not recommended for use by pets or small children.
- Supervision is required when the blanket is used by non-mobile elderly individuals.
- Unplug the blanket from the power outlet when not in use.

Dos and Don'ts for Safe Operation:



Keep Controller
Uncovered



Keep Blanket
Spread Out Evenly



Keep Cord Loose,
Not Twisted & Pinched

DOS/DON'TS



Don't Lay on
Top of the Blanket to Prevent
Damage to Internal Coils



Don't Ballup Your
Blanket While On



Don't Fold your
Blanket While On

Image 2.1: Visual guide for safe heated blanket usage.

- **Do:** Keep the controller uncovered during operation.
- **Do:** Spread the blanket out evenly when in use.
- **Do:** Keep the power cord loose, ensuring it is not twisted or pinched.
- **Don't:** Lay directly on top of the blanket, as this can damage internal coils.
- **Don't:** Ball up or fold the blanket while it is powered on.

3. PRODUCT OVERVIEW

Features:

FEATURES

Stay warm and cozy




Fleece

Provides a warm luxurious look and feel.



Ultra Soft

Underside sherpa offers a fluffy feel on skin.



Flexible Wires

flexible heating wires for durability and comfort



Image 3.1: Key features of the Serta Heated Throw Blanket.

- **Material:** 100% Fleece to Sherpa construction, offering a soft and reversible design.
- **Heat Settings:** 5 adjustable heat levels for personalized comfort.
- **Auto Shut-Off:** Integrated 3-hour automatic shut-off timer for safety.
- **Controller:** Easy-to-use wired controller.

Components:

CONTROLLER

- 5 heat setting
- 3 hr auto shut off
- 3 ft controller cord
- 6 ft power cord
- input voltage 120v /60hz
(100W)
- ETL certified

Image 3.2: Details of the heated blanket controller and its specifications.

- 1 x Heated Throw Blanket (50"W x 60"L)
- 1 x Wired Controller (3 ft cord length)
- 1 x Power Cord (6 ft length)

4. SETUP INSTRUCTIONS

1. **Unpack:** Carefully remove the heated throw blanket and its controller from the packaging.
2. **Position:** Place the blanket on a bed, couch, or chair, ensuring it is spread out evenly without any folds or bunches.
3. **Connect Controller:** Locate the connector on the blanket and firmly plug in the controller cord. Ensure a secure connection.
4. **Power Connection:** Plug the power cord directly into a standard 120V AC wall outlet. Avoid using extension cords or power strips.
5. **Controller Placement:** Position the controller where it is easily accessible and will not be covered by the blanket or other items during use.

5. OPERATING INSTRUCTIONS

1. **Power On:** Press the power button on the controller to turn on the heated throw. The indicator light will illuminate.
2. **Select Heat Setting:** Use the dial or buttons on the controller to choose your desired heat level from 1 (low) to 5 (high).
3. **Automatic Shut-Off:** The blanket is equipped with a 3-hour auto shut-off feature. After approximately 3 hours of continuous use, the blanket will automatically turn off for safety. To resume heating, simply turn the blanket off and then on again using the controller.
4. **Power Off:** To turn off the blanket manually, press the power button on the controller. Unplug the blanket from the wall outlet when not in use.

MAKE THE MOST OF YOUR LEISURE TIME
NO RECALLS, NO WORRIES!




Image 5.1: The heated throw blanket provides comfort for leisure activities.

6. CARE AND MAINTENANCE

Proper care ensures the longevity and performance of your heated throw blanket.

CARE & INFO



General

Unplug device when not in use. Plug straight to outlet only, and do not use power strips.



Cleaning

Detach controller before wash. Wash in cold water with minimal detergent. Tumble dry low and do not iron.



Safety

Not recommend for pets or small children. Supervision required for non-mobile elderly.



Peace of mind

Backed by a robust 5 year limited manufacturer warranty and customer support.

Superior Product Quality with **NO RECALL** History

Image 6.1: General care and safety information.

Washing Instructions:


WASHING



Wash by Hand or
With Delicate Cycle




Wash & Rinse in Cold Water,
Minimal Detergent



Remove Immediately
After Spin Cycle

5 mins




Tumble Dry on Medium
or Low for 5 Minutes

DRYING



Gentle Stretch and
Hang to Finish Drying



Do Not Hang with
Clothespins



Do Not Iron

Image 6.2: Detailed washing and drying instructions.

1. **Disconnect:** Always detach the controller from the blanket before washing.
2. **Wash:** Machine wash the blanket in cold water on a delicate cycle, using minimal detergent. Alternatively, hand wash.
3. **Rinse:** Rinse thoroughly in cold water.
4. **Spin:** Remove the blanket immediately after the spin cycle to prevent creasing.

Drying Instructions:

1. **Tumble Dry:** Tumble dry on a medium or low heat setting for a maximum of 5 minutes.
2. **Air Dry:** Gently stretch the blanket to its original shape and hang it to finish drying.
3. **Do Not:** Do not hang the blanket with clothespins, and do not iron the blanket.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Blanket does not heat.	Loose connection, no power, or auto shut-off activated.	Ensure controller is firmly connected to the blanket. Verify power cord is securely plugged into a working wall outlet. If recently used, the 3-hour auto shut-off may have activated; turn off and then on again.
Controller displays an error or flashes.	Internal fault or overheating protection activated.	Unplug the blanket from the wall outlet, wait a few minutes, and plug it back in. Ensure the blanket is spread out evenly and the controller is uncovered. If the issue persists, contact customer support.
Uneven heating or blanket feels too hot in one spot.	Blanket is folded, bunched, or balled up.	Immediately turn off and unplug the blanket. Spread it out completely and allow it to cool. Ensure it is always spread evenly during use.

8. SPECIFICATIONS

- **Model Number:** ST54-0032
- **UPC:** 086569468222
- **Dimensions:** 50 inches (W) x 60 inches (L)
- **Material:** 100% Fleece to Sherpa
- **Power Input:** 120V / 60Hz (100W)
- **Heat Settings:** 5 levels
- **Auto Shut-Off:** 3 hours
- **Certifications:** ETL Certified
- **Item Weight:** Approximately 2.53 pounds
- **Included Components:** 1 Heated Throw, 1 Controller

9. WARRANTY AND SUPPORT

Your Serta Heated Throw Blanket is backed by a 3-year limited manufacturer's warranty. This warranty covers defects in materials and workmanship under normal use.

For warranty claims, technical support, or any questions regarding your product, please refer to the official Serta website or contact their customer service department. Keep your proof of purchase for warranty validation.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B091HBGQSL>

More documents and user manuals: **<https://manuals.plus/>**