

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Ingco](#) /
- › [Ingco 800W Corded Electric Air Blower \(Model AB8008\) User Manual](#)

Ingco AB8008

Ingco 800W Corded Electric Air Blower (Model AB8008) User Manual

Your comprehensive guide to safe and effective operation.

1. SAFETY INSTRUCTIONS

Always prioritize safety when operating power tools. Read and understand all instructions before use.

- **Eye Protection:** Always wear safety goggles or glasses to protect your eyes from debris.
- **Hearing Protection:** Use ear protection, such as earmuffs or earplugs, especially during extended operation.
- **Electrical Safety:** Ensure the power cord is in good condition and connected to a grounded outlet. Do not operate in wet conditions.
- **Secure Grip:** Maintain a firm grip on the blower handle during operation.
- **Clear Work Area:** Keep bystanders, children, and pets away from the work area. Remove any objects that could be propelled by the air stream.
- **Ventilation:** Operate in a well-ventilated area to prevent overheating.
- **Proper Attire:** Wear appropriate clothing, avoiding loose garments that could get caught in moving parts.
- **Storage:** Store the blower in a dry, secure location out of reach of children.

2. PRODUCT OVERVIEW

The Ingco 800W Corded Electric Air Blower, Model AB8008, is a versatile tool designed for various blowing and light vacuuming tasks. It features an 800W motor, providing efficient air movement for clearing dust, debris, and leaves.



Figure 2.1: Front view of the Incco 800W Corded Electric Air Blower.



Figure 2.2: Side view of the Ingco 800W Corded Electric Air Blower, showing the air intake and exhaust ports.

Key Features:

- Model Number: AB8008
- Type: Air Blower Machine
- Power Source: Corded Electric
- Brand: Ingco

3. SETUP

Before operating the blower, ensure all components are correctly assembled.

1. **Unpacking:** Carefully remove all items from the packaging. Inspect for any damage.
2. **Attaching the Nozzle:** Align the blower nozzle with the air outlet port on the front of the blower. Push

and twist until it is securely locked in place.

3. **Attaching the Dust Bag (for vacuum function):** If using the vacuum function, attach the dust collection bag to the air intake port (usually located on the side or bottom of the blower). Ensure it is firmly attached to prevent dust leakage.



Figure 3.1: Ingco 800W Blower with the nozzle attached for blowing function.

4. OPERATING INSTRUCTIONS

Follow these steps for safe and effective operation of your Ingco air blower.

1. **Power Connection:** Plug the power cord into a suitable grounded electrical outlet.
2. **Starting the Blower:** Press the ON/OFF switch to start the blower. Some models may have a variable speed dial; adjust to the desired air speed.
3. **Blowing Function:** Direct the nozzle towards the area you wish to clear. Use a sweeping motion to move debris.
4. **Vacuum Function (if applicable):** If your model supports vacuuming, ensure the dust bag is attached and the nozzle is connected to the intake port. Switch the function selector (if present) to vacuum mode.
5. **Stopping the Blower:** Release the trigger or press the OFF switch to stop the blower.
6. **Unplugging:** Always unplug the tool from the power source when not in use or before performing any maintenance.

5. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your air blower.

- **Cleaning:** After each use, wipe down the exterior of the blower with a damp cloth. Remove any debris from the air intake and exhaust vents.
- **Dust Bag (if applicable):** Empty the dust collection bag regularly. Clean it as needed according to

manufacturer recommendations.

- **Cord Inspection:** Periodically inspect the power cord for cuts, fraying, or damage. Replace damaged cords immediately.
- **Storage:** Store the blower in a clean, dry place, away from direct sunlight and extreme temperatures.

6. TROUBLESHOOTING

Refer to this section for common issues and their solutions.

Problem	Possible Cause	Solution
Blower does not start	No power supply; Faulty switch; Damaged cord	Check power outlet and cord; Contact qualified service personnel
Reduced air flow	Blocked air intake/exhaust; Full dust bag (if applicable)	Clear blockages; Empty and clean dust bag
Unusual noise or vibration	Loose components; Internal damage	Tighten any loose parts; Discontinue use and contact service

If the problem persists after attempting these solutions, please contact customer support.

7. SPECIFICATIONS

Detailed technical specifications for the Ingco 800W Air Blower.

Feature	Detail
Manufacturer	Ingco
Part Number	800W
Item Model Number	800W
Item Weight	2.91 Kilograms
Product Dimensions	10 x 20 x 37 cm
Color	Yellow/Black
Style	Handheld
Power Source Type	Corded Electric
Number of Item Subunits	1
Speed	15000 RPM
Special Features	Cordless (Note: Product description indicates Corded Electric)
Included Components	Collection Bag

Feature	Detail
Batteries Required?	No
ASIN	B091J68P2K
Date First Available	April 1, 2021



Figure 7.1: Dimensions of the Ingco 800W Air Blower.

8. WARRANTY AND SUPPORT

For warranty information, technical support, or service inquiries, please refer to the warranty card included with your product or contact Ingco customer service directly. Keep your purchase receipt as proof of purchase.

For further assistance, you may visit the official Ingco website or contact their authorized service centers.