



[Manuals.plus](#) /

> [GMS](#) /

> [GMS-X5 Gaming Mouse Pad with 10 RGB Lighting Modes \(80cm x 30cm\) - Instruction Manual](#)

GMS GMS-X5

GMS-X5 Gaming Mouse Pad Instruction Manual

Model: GMS-X5

1. INTRODUCTION

Thank you for purchasing the GMS-X5 Gaming Mouse Pad. This large RGB mouse pad is designed to enhance your gaming and computing experience with its spacious surface, vibrant lighting, and stable anti-slip base. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your new mouse pad.



Image 1: GMS-X5 Gaming Mouse Pad with illuminated RGB edges.

2. PRODUCT FEATURES

- **Large Surface Area:** Dimensions of 80cm x 30cm provide ample space for both mouse and keyboard.
- **RGB Lighting:** Features 10 distinct RGB lighting modes for customizable aesthetics.
- **Anti-Slip Base:** Constructed with a rubber base to ensure stability during intense use.
- **Durable Material:** Made from superfine fiber braided material for smooth mouse movement and durability.
- **Ultra-Thick Design:** 4mm thickness for enhanced comfort and stability.
- **Detachable USB Cable:** For easy connection and portability.

3. PACKAGE CONTENTS

The package includes the following items:

- 1 x RGB Soft Gaming Mouse Pad (GMS-X5)
- 1 x USB Cable

Product information

Modes : **Red Mode**

Blue Mode

Green Mode

Purple Mode

Cyan Mode

Yellow Mode

White Mode

synchronizing wave

RGB Alternating wave

Alternating red changing flash

RGB Alternating flash

synchronize breathing

Alternate breathing

Size: 800mm x 300mm x 4mm

Material: Superfine fiber braided material,
Super glow fiber,
Anti-slip Rubber Base

Package:

1 x RGB Soft Gaming Mouse Pad,
1 x USB Cable

Image 2: Product information detailing package contents and specifications.

4. SETUP GUIDE

Follow these steps to set up your GMS-X5 Gaming Mouse Pad:

1. Unroll the mouse pad on a flat, clean surface.
2. Locate the connection port on the mouse pad.
3. Connect the provided USB cable to the mouse pad's connection port.
4. Plug the other end of the USB cable into an available USB port on your computer or a compatible USB power adapter.
5. The RGB lighting will illuminate, indicating the pad is powered on.

- Press once to change mode.
- Press twice continuously to adjust brightness.
- Press 3 seconds to turn on/off



CONNECTION PORT



COLOR SWITCH BUTTON

Just easily click the switch button to change color



Image 3: Detail of the USB connection port on the mouse pad.

5. OPERATING INSTRUCTIONS

The GMS-X5 Gaming Mouse Pad features a control button for managing its RGB lighting. This button is typically located near the USB connection port.

Controlling RGB Lighting:

- **Change Lighting Mode:** Press the control button once to cycle through the 10 available RGB lighting modes.
- **Adjust Brightness:** Press the control button twice continuously to adjust the brightness level of the lighting.
- **Turn On/Off:** Press and hold the control button for 3 seconds to turn the RGB lighting on or off.

Available Lighting Modes:

- Red Mode
- Blue Mode
- Green Mode

- Purple Mode
- Cyan Mode
- Yellow Mode
- White Mode
- Synchronizing Wave
- Alternating Red Changing Flash
- RGB Alternating Flash
- Synchronize Breathing
- Alternate Breathing

Color Change button




Image 4: The control button for changing colors and managing power, with the detachable USB cable.

6. CARE AND MAINTENANCE

To ensure the longevity and optimal performance of your GMS-X5 Gaming Mouse Pad, follow these care instructions:

- **Cleaning:** Gently wipe the surface with a damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the material and lighting components. Do not submerge the mouse pad in water.

- **Spills:** In case of liquid spills, immediately disconnect the USB cable and gently blot the liquid with a dry cloth. Allow the pad to air dry completely before reconnecting power.
- **Storage:** When not in use, store the mouse pad flat or gently rolled to prevent creases or damage to the lighting strips. Avoid folding the pad sharply.
- **Avoid Extreme Temperatures:** Do not expose the mouse pad to direct sunlight for extended periods or to extreme hot or cold temperatures.

7. TROUBLESHOOTING

If you encounter any issues with your GMS-X5 Gaming Mouse Pad, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
RGB lighting does not turn on.	No power or loose connection.	Ensure the USB cable is securely connected to both the mouse pad and a powered USB port. Try a different USB port or power source.
Lighting modes do not change.	Control button malfunction or incorrect press.	Press the control button firmly and briefly to cycle modes. If unresponsive, try disconnecting and reconnecting the USB cable.
Lighting appears dim or flickers.	Insufficient power or brightness setting.	Ensure the USB port provides sufficient power. Press the control button twice continuously to adjust brightness.
Mouse pad edges are detaching.	Wear and tear or manufacturing defect.	This may indicate a manufacturing issue or extensive use. If within return period, contact retailer. Otherwise, gentle adhesive may be used for minor separation.
Mouse movement is not smooth.	Dirty surface or incompatible mouse.	Clean the mouse pad surface as per maintenance instructions. Ensure your mouse sensor is clean.


8. TECHNICAL SPECIFICATIONS

Detailed specifications for the GMS-X5 Gaming Mouse Pad:

Specification	Detail
Brand	GMS
Model Number	GMS-X5 (Internal: 11111)
Dimensions (Length x Width)	80 cm x 30 cm (31.5 inches x 11.8 inches)
Thickness	4 mm
Material	Superfine fiber braided material, Anti-slip Rubber Base
Lighting Modes	10 RGB Modes (Red, Blue, Green, Purple, Cyan, Yellow, White, Synchronizing Wave, Alternating Red Changing Flash, RGB Alternating Flash, Synchronize Breathing, Alternate Breathing)

Specification	Detail
Special Features	Anti-slip, RGB Lighting
Recommended Use	Gaming
Connectivity	USB (Detachable Cable)
Color	Multicolor (RGB)
Country of Origin	Egypt

Larger Size
Perfect Movement Space



4mm ultra-thick



Image 5: GMS-X5 mouse pad illustrating its large size and 4mm thickness.

9. WARRANTY AND SUPPORT

This product is provided without an explicit warranty. For any product-related inquiries or support, please contact your retailer or the manufacturer directly through their official channels.

Please retain your purchase receipt for any potential support needs.