Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Tornado TOH-15D

Tornado Oil-Filled Heater TOH-15D User Manual

Model: TOH-15D

Introduction

Thank you for choosing the Tornado Oil-Filled Heater TOH-15D. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new heater. Please read these instructions thoroughly before using the appliance and retain them for future reference.

Important Safety Instructions

When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before using this heater.
- This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces.
- Extreme caution is necessary when any heater is used by or near children or invalids and whenever the heater is left operating and unattended.
- Do not operate any heater with a damaged cord or plug or after the heater malfunctions, has been dropped or damaged in any manner.
- Do not use outdoors.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic area and where it will not be tripped over.
- To disconnect heater, turn controls to off, then remove plug from outlet.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
- To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.
- A heater has hot and arcing or sparking parts inside. Do not use it in areas where gasoline, paint, or flammable liquids are used or stored.
- Use this heater only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons.
- Always plug heaters directly into a wall outlet/receptacle. Never use with an extension cord or relocatable power tap (outlet/power strip).

- Ensure the heater is placed on a stable, level surface.
- Do not cover the heater.

Parts Identification

Familiarize yourself with the components of your Tornado Oil-Filled Heater TOH-15D:

- **Control Panel:** Features touch controls for power, temperature adjustment, and timer.
- **Heating Fins:** 15 oil-filled fins for heat distribution.
- **Indicator Lamp:** Illuminates when the heater is operating.
- **Wheels/Casters:** For easy mobility.
- **Power Cord Storage:** Integrated area for cord management.



Image: The Tornado TOH-15D Oil-Filled Heater, showing its black finish, 15 heating fins, and the digital touch control panel on the side. The wheels for mobility are visible at the base.

Setup

1. **Unpacking:** Carefully remove the heater from its packaging. Retain packaging for off-season storage.
2. **Wheel Assembly (if required):** If the wheels are not pre-assembled, attach them according to the diagrams provided in the separate assembly sheet (if applicable). Ensure they are securely fastened.
3. **Placement:** Place the heater on a firm, level surface. Ensure there is at least 90 cm (3 feet) of clear space from walls, furniture, and curtains to allow for proper air circulation and prevent fire hazards.
4. **Power Connection:** Plug the power cord directly into a grounded 220-240V AC, 50Hz electrical outlet. Do not use extension cords or power strips.

Operating Instructions

The Tornado TOH-15D features a touch panel for easy control.

1. **Power On/Off:** Press the **POWER** button (usually indicated by a circle with a vertical line) on the touch panel to turn the heater on or off. The indicator lamp will illuminate when the heater is on.
2. **Temperature Adjustment:** Use the **+** and **-** buttons to increase or decrease the desired room temperature. The heater will cycle on and off to maintain the set temperature.
3. **Mode Selection (if applicable):** Some models may have different heating modes. Refer to the specific icons on your touch panel for mode selection (e.g., low, medium, high heat).
4. **Timer Function (if applicable):** If your model includes a timer, press the **TIMER** button (often indicated by a clock icon) and use the **+** and **-** buttons to set the desired operating duration (e.g., 1-24 hours). The heater will automatically turn off after the set time.
5. **Safety Thermostat:** The heater is equipped with a safety thermostat that will automatically turn off the unit if it overheats. If this occurs, unplug the heater, allow it to cool down, and check for any obstructions before restarting.

Maintenance

Regular maintenance ensures optimal performance and longevity of your heater.

- **Cleaning:**
    a. Always unplug the heater from the wall outlet and allow it to cool completely before cleaning.
    b. Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.
    c. Do not immerse the heater in water or allow water to drip into the interior.
- **Storage:**
    a. Store the heater in a cool, dry location when not in use.
    b. Wrap the power cord neatly around the cord storage area to prevent damage.
    c. It is recommended to store the heater in its original packaging to protect it from dust and damage.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Heater does not turn on.	• Not plugged in. • Power outlet not working. • Safety thermostat activated.	• Ensure the power cord is securely plugged into a grounded outlet. • Check the circuit breaker or try another outlet. • Unplug the heater, allow it to cool for 30 minutes, and check for obstructions.
Heater produces insufficient heat.	• Temperature setting too low. • Room size too large for heater capacity.	• Increase the temperature setting using the **+** button. • Ensure the heater is appropriate for the room size (Heating Range: 32 m²).
Heater makes unusual noises.	• Normal expansion/contraction of metal. • Loose parts.	• Minor clicking or crackling sounds are normal during heating and cooling. • If noises are loud or persistent, discontinue use and contact customer support.

Specifications

- **Model:** TOH-15D
- **Power:** 2800 Watt
- **Fins:** 15
- **Operation:** Silent
- **Controls:** Touch Panel
- **Safety Features:** Safety Thermostat, Indicator Lamp
- **Heating Range:** Up to 32 m²
- **Color:** Black
- **Item Weight:** Approximately 15 kg
- **Power Source:** Corded Electric
- **Indoor/Outdoor Usage:** Indoor only

Warranty and Support

For warranty information or technical support, please refer to the warranty card included with your product or contact Tornado customer service. Keep your purchase receipt as proof of purchase.
Tornado Customer Service: Please visit the official Tornado website or refer to the contact details provided in your product packaging for support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B091J9HZFN

More documents and user manuals: **https://manuals.plus/**