

[Manuals.plus](#) /

› [Sharper Image](#) /

› Sharper Image Powerboost Massage Gun User Manual

Sharper Image 1017246

Sharper Image Powerboost Massage Gun User Manual

Model: 1017246 | Brand: Sharper Image

INTRODUCTION

The Sharper Image Powerboost Massage Gun is an advanced deep tissue percussion massager designed to provide effective relief for muscle soreness and tension. Featuring a quiet brushless motor, multiple speed settings, and interchangeable attachments, this device offers a customizable massage experience for full body muscle recovery and pain relief. Its portable and ergonomic design ensures comfortable and precise application wherever you are.

SAFETY INFORMATION

Always follow the directions for use. Keep the massager away from water. Do not use on broken skin or areas with inflammation. Avoid using near the head or neck. Keep out of reach of children. Unplug the massager when not in use. Always inspect the massager and attachments before each use for any damage.

PACKAGE CONTENTS

- Sharper Image Powerboost Massage Gun
- 5 Interchangeable Massage Attachments
- Carrying Case
- Charging Cable



Image: The Sharper Image Powerboost Massage Gun, its compact carrying case, and the five distinct massage attachments.

SHARPER IMAGE®

POWERBOOST DEEP TISSUE

WHAT YOU GET



MASSAGER



5 INTERCHANGEABLE
ATTACHMENTS



Image: A user demonstrating the massage gun on their shoulder, highlighting the core components included in the package.

PRODUCT FEATURES

- **Advanced Deep Tissue Relief:** Targets muscle soreness and tension effectively.
- **Quiet Brushless Motor:** Ensures quiet operation for an undisturbed experience.
- **6 Speed Settings:** Allows fine-tuning of intensity for optimal relief.
- **5 Interchangeable Attachments:** Designed for tailored massage across various muscle groups.
- **Portable Design:** Lightweight and compact for on-the-go recovery.
- **Enhanced Ergonomic Grip:** Oval handle with rubber grip for comfort and precision.
- **Rechargeable & Wireless:** Provides up to 4.5 hours of use on a single charge.

+ CUSTOMIZABLE MASSAGE



Select the right intensity from a choice of 6 speeds for a personalized massage every time



Image: The massage gun showcasing its customizable massage capability with 6 speed options.

+ CONVENIENT DESIGN



**QUIET-DRIVE TECHNOLOGY FOR
WHISPER QUIET USE ANYWHERE**



**ERGONOMIC, RUBBER-GRIPPED
HANDLE**



COMPACT, LIGHTWEIGHT DESIGN



Image: A user demonstrating the convenient design of the massage gun, emphasizing its quiet operation, ergonomic grip, and lightweight nature.

RECHARGEABLE & WIRELESS

UP TO 4.5
HOURS OF
USE IN ONE
CHARGE

PERFECT
FOR
MASSAGE
ON THE GO



SHARPER IMAGE®

Image: An internal diagram of the massage gun, illustrating its rechargeable battery and wireless functionality, providing up to 4.5 hours of use.

SETUP

1. **Charge the Device:** Before first use, fully charge the massage gun using the provided charging cable. The battery indicator lights will show charging progress.
2. **Attach Desired Head:** Select the appropriate massage attachment for your needs. Align the attachment with the opening on the front of the massage gun and push it firmly into place until it clicks securely.

OPERATING INSTRUCTIONS

1. **Power On:** Press and hold the power button to turn on the device.
2. **Select Intensity:** Press the power button repeatedly to cycle through the 6 available speed settings. Start with a lower speed and gradually increase as desired.
3. **Apply to Skin:** Gently apply the attachment to your skin, avoiding bones and sensitive areas.
4. **Massage Technique:** Move the massage gun slowly and evenly across your muscle tissue. Do not apply excessive pressure.
5. **Power Off:** Press and hold the power button to turn off the device after use.

For best results, use the massage gun for 1-2 minutes per muscle group. Do not use for prolonged periods on a single area.


SHARPER IMAGE®




ROUND

Constructed from durable foam but designed for more precision.

GOOD FOR
Forearms,
Biceps, Shins




MUSCLE IMPACT
Low





FLAT

The hammer-like impact hits deeper into muscles.

GOOD FOR
Pecs, Quads,
Glutes, Calves




MUSCLE IMPACT
Medium




FORK

Gently rock from side to side to work out knots and tense spots.

GOOD FOR
Traps, Quads,
Calves, Feet




MUSCLE IMPACT
High




CONE

This pinpoint head is designed for unsurpassed muscular penetration.

GOOD FOR
Feet, Scap,
Forearms




MUSCLE IMPACT
High



COMPRESSION

The curved edge provides comfort with surprising strength.

GOOD FOR
IT Band,
Biceps



MUSCLE IMPACT
High




Image: A visual guide indicating recommended areas for full body massage, including neck, shoulders, arms, back, thighs, calves, and feet.

ATTACHMENT GUIDE

The Sharper Image Powerboost Massage Gun comes with 5 redesigned attachments, each suited for different muscle groups and massage intensities.

5 ATTACHMENTS



ROUND

Large
muscle
groups



FORK

Back and
shoulders



CONE

Trigger
points and
knots



FLAT

All areas



COMPRESSION

Sensitive points



Image: An overview of the five distinct massage attachments included with the Powerboost Massage Gun.



FULL BODY MASSAGE

THE DEEP TISSUE MASSAGER
FROM SHARPER IMAGE
REPRESENTS THE FUTURE OF
MASSAGE TECHNOLOGY,
PROVIDING FOCUSED
ATTENTION TO TARGETED
MUSCLE GROUPS

#1 MASSAGE BRAND*




Image: Detailed illustrations of each attachment, specifying their muscle impact level and ideal application areas.

Attachment	Description	Recommended Use	Muscle Impact
Round	Constructed from durable foam, designed for broad coverage.	Large muscle groups, general full body massage, overall comfort. Good for Thighs, Calves, Back, Forearms, Biceps, Shins.	Low
Flat	Hammer-like impact for dense muscle tissue.	All areas, general muscle relaxation. Good for Pecs, Quads, Glutes, Calves.	Medium
Fork	Dual-pronged design to work around bones and target specific areas.	Back and shoulders, along the spine, Achilles tendon. Good for Neck, Back, Shoulders.	High

Attachment	Description	Recommended Use	Muscle Impact
Cone	Pinpoint head designed for deep muscular penetration.	Trigger points, knots, small muscle areas. Good for Trigger Points, Knots, Feet, Scapula, Forearms.	High
Compression	Curved edge provides comfort with surprising strength.	Sensitive points, IT bands, biceps. Good for IT Bands, Biceps.	High

MAINTENANCE

- **Cleaning:** After each use, wipe the massage gun and attachments with a clean, damp cloth. Do not use abrasive cleaners or immerse the device in water.
- **Storage:** Store the massage gun and its attachments in the provided carrying case in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the device regularly, even if not in use for extended periods.

TROUBLESHOOTING

- **Device Not Turning On:** Ensure the battery is fully charged. If the device still does not turn on, try connecting it to the charger to confirm power.
- **Weak Percussion:** Check the battery level; low battery can reduce performance. Ensure the attachment is securely fastened.
- **Unusual Noise/Vibration:** Discontinue use immediately. Check for any foreign objects obstructing the attachment or motor area. If the issue persists, contact customer support.
- **Overheating:** If the device feels excessively hot, turn it off and allow it to cool down before resuming use. Avoid prolonged continuous use.

SPECIFICATIONS

Specification	Detail
Product Dimensions	9 x 6.75 x 0.98 inches
Item Model Number	1017246
Batteries	1 Lithium Ion battery required (included)
Item Weight	2 Pounds

Specification	Detail
Material	Plastic
Power Source	Battery Powered
Manufacturer	MerchSource
Date First Available	July 31, 2023

WARRANTY AND SUPPORT

This product is backed by a 1-year manufacturer warranty. For any questions or issues, please message us through Amazon for quick resolution and reliable product support.

Legal Disclaimer: Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question

