

[Manuals.plus](#) /

› [weelye](#) /

› Weelye RX25 6V Kids Powered Ride-On Car Remote Control & Receiver Kit Instruction Manual

weelye RX25

Weelye RX25 6V Kids Powered Ride-On Car Remote Control & Receiver Kit Instruction Manual

Model: RX25

INTRODUCTION

This manual provides instructions for the installation, setup, and operation of the Weelye RX25 6V Kids Powered Ride-On Car 2.4G Bluetooth Remote Control and Receiver Kit. This kit is designed as a replacement part for specific children's ride-on toys. Please read these instructions carefully before use to ensure proper functionality and safety.

COMPATIBILITY CHECK

Before installing, it is crucial to verify that this control box is compatible with your ride-on car. Open your existing electric ride-on car and locate the control box. Compare its appearance with the images provided below. If the appearance of the control box is identical, this part should be compatible with your car.



Image 1: Top view of the Weelye RX25 6V Control Box. Note the "weelye" branding and connector layout.



Image 2: Side view of the Weelye RX25 6V Control Box, showing the "RX25 6V CE/FC" label.

Additionally, ensure that other functions of your car, such as motors and batteries, are working properly before replacing the control box.

SETUP: REMOTE CONTROL FREQUENCY MATCHING

The remote control requires frequency matching for its first use or after replacing its batteries. Follow these steps:

1. Install Batteries in Remote Control:

Install two AAA 1.5V batteries into the remote control. Pay attention to the positive and negative polarity markings inside the battery compartment. Close the battery cover. The indicator light will flash three times, confirming correct battery installation.



Image 3: Front view of the Weelye 2.4G Bluetooth Remote Control.

TX4

Operation manual : For the first time to use (Or Replace the battery)Need to frequency bind

- Take out the remote control, install the battery
- Long press on the button "M" for 2-4 seconds, Indicator light will flash
- Turn on the power of the car, Indicator light flashes to long lighting, then frequency bind succeed
- If the frequency bind failed (Indicator light flashes) , remove the battery and repeat steps 1~3
- remote control without operation after 10 seconds, Indicator light will off into power saving mode
- Button Description: △ forward ▽ backward ◁ turn left ▷ turn right
- P: Emergency braking, press it ,the running function will fail, press again, it release

Install the battery of the remote control:

Buy 2 pcs of battery AAA1.5V. Use the Phillips screwdriver , unscrew the screw on the back of the remote control. Then remove the battery cover and install the battery.

- Do not mix old and new or different types of batteries
- The exhausted battery should be removed from the remote control in time.



Image 4: Remote control packaging showing battery installation instructions.

2. Initiate Pairing on Remote:

Press and hold the frequency key (often labeled "M" or "car select") on the remote control for approximately 2 seconds. The indicator light on the remote will begin to flash.

3. Power On the Car:

Turn on the power supply of the ride-on car. The indicator light on the remote control should turn off, indicating successful frequency matching.

4. Troubleshooting Unsuccessful Matching:

If the matching frequency is unsuccessful (the indicator light does not turn off), turn off the power supply of the car and repeat steps 2 and 3.

OPERATING THE REMOTE CONTROL

The remote control allows for external operation of the ride-on car. Key functions include:

- **Directional Control:** Use the arrow buttons for forward, backward, turn left, and turn right movements.
- **Emergency Braking (P button):** Press the "P" button for emergency braking. If the running function fails, press it again to release.
- **Power Saving Mode:** If the remote control is not operated for 10 seconds, the indicator light will turn off, and the remote will enter power saving mode.

MAINTENANCE

Remote Control Battery Installation and Care

- **Battery Type:** Requires 2 x AAA 1.5V batteries.
- **Installation:** Use a Phillips screwdriver to unscrew the screw on the back of the remote control. Remove the battery cover and install the batteries according to polarity.
- **Battery Mixing:** Do not mix old and new batteries, or different types of batteries.
- **Disposal:** Exhausted batteries should be removed from the remote control in a timely manner.

TROUBLESHOOTING

- **Remote Control Not Pairing:** If the indicator light on the remote does not turn off after attempting frequency matching, ensure the car's power is on and repeat the matching steps (Section: Setup). Check remote control batteries.
- **Car Not Responding:** Verify that the remote control batteries are correctly installed and charged. Ensure the car's main battery is charged and connected. Check if other car functions (motors, lights) are operational, as issues with these components may prevent the control box from functioning correctly.
- **Slow Start Function:** This product includes a slow start function, meaning no additional slow starter installation is required. If the car exhibits a harsh start, ensure the control box is correctly installed and compatible.

SPECIFICATIONS

Brand	weelye
Model Number	RX25
Voltage	6V
Connectivity	2.4G Bluetooth
Remote Control Battery Type	2 x AAA 1.5V batteries
Material Type	Plastic
Item Dimensions	4.9 x 2.9 x 1.9 inches (Control Box)
Assembly Required	No

WARRANTY AND SUPPORT

Specific warranty information is not provided in this manual. For warranty details or technical support, please refer to the product packaging or contact the manufacturer directly via their official website or customer service channels. Ensure you have your product model number (RX25) and purchase information available when contacting support.

Manufacturer: [weelye](#)

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question