

[Manuals.plus](#) /

› [Honeywell](#) /

› Honeywell HF715 Turbo Force Floor Fan Instruction Manual

Honeywell HF715

Honeywell HF715 Turbo Force Floor Fan Instruction Manual

Model: HF715

1. INTRODUCTION

This manual provides important instructions for the safe operation, maintenance, and troubleshooting of your Honeywell HF715 Turbo Force Floor Fan. Please read all instructions carefully before using the appliance and retain this manual for future reference.



Figure 1: Honeywell HF715 Turbo Force Floor Fan. A black Honeywell HF715 Turbo Force Floor Fan, shown from an angled perspective, highlighting its compact design and grille.

2. IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before using this fan.
- Use this fan only as described in this manual. Other uses not recommended by the manufacturer may cause fire, electric shock, or injury to persons.
- To protect against electric shock, do not place fan in window, immerse unit, plug or cord in water or spray with liquids.
- Close supervision is necessary when any appliance is used by or near children.

- Unplug the fan from the outlet when not in use, when moving the fan from one location to another, and before cleaning.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Always place the fan on a stable, flat, level surface when operating to avoid the chance of the fan overturning.
- Do not insert or allow fingers or foreign objects to enter any ventilation or exhaust opening as it may cause an electric shock or fire, or damage the fan.
- Do not block air intakes or exhaust in any manner.
- Do not use outdoors.
- This fan is equipped with a fused safety plug. Do not remove or tamper with the plug.

3. PACKAGE CONTENTS

Verify that the following items are included in your package:

- Honeywell HF715 Turbo Force Floor Fan
- Remote Control

4. PRODUCT FEATURES

The Honeywell HF715 Turbo Force Floor Fan is designed to provide powerful and customizable cooling. Key features include:

- **3 Speed Options:** Choose from low, medium, or high settings for personalized airflow.
- **Wide Oscillation:** Distributes air across a broader area for enhanced room circulation.
- **90-Degree Pivoting Head:** Manually adjust the fan head vertically to direct airflow precisely where needed.
- **Remote Control:** Conveniently operate all fan functions from a distance.
- **Electronic LED Controls:** Intuitive touch buttons with LED indicators on the fan unit.
- **Auto-Off Timer:** Program the fan to turn off automatically after 1, 2, or 4 hours.
- **Turbo Force Power:** Aerodynamic design maximizes air movement for intense cooling.



Figure 2: Feature Diagram. A detailed diagram of the Honeywell HF715 fan, pointing out its various features such as the 90-degree pivoting head, carrying handle, fused safety plug, oscillation, three speed settings, electronic LED control panel, remote control, and auto-off timer.

5. SETUP

The Honeywell HF715 Turbo Force Floor Fan requires no assembly. Simply follow these steps to set up your fan:

1. Place the fan on a firm, level surface.
2. Ensure the fan is positioned away from curtains or other objects that could obstruct airflow.
3. Plug the power cord into a 127 Volt AC electrical outlet.

6. OPERATION

Your Honeywell HF715 fan can be operated using the electronic LED control panel on the unit or the included remote control.

6.1 Control Panel and Remote Control



Figure 3: Control Panel. A close-up view of the Honeywell HF715 fan's electronic LED control panel, showing the power, speed, oscillation, and timer buttons.

The control panel and remote control feature the following buttons:

- **Power Button (⏻):** Turns the fan On or Off.
- **Speed Button (⋯):** Cycles through 3 speed settings (Low, Medium, High). LED indicators will show the selected speed.
- **Oscillation Button (↻):** Activates or deactivates the oscillation function.
- **Timer Button (🕒):** Sets the auto-off timer for 1, 2, or 4 hours. Press repeatedly to cycle through options.

6.2 Adjusting Fan Head Angle

The fan head can be manually tilted up or down to a 90-degree angle to direct airflow. Gently grasp the fan housing and pivot it to the desired position.



Figure 4: Air Circulation. Two individuals exercising in a room with the Honeywell HF715 fan, illustrating its ability to circulate air up to 40 feet away.

7. MAINTENANCE AND CLEANING

Regular cleaning will help maintain the fan's performance and appearance.

- Always unplug the fan before cleaning.
- Use only a soft, damp cloth to gently wipe the outer surfaces of the fan.
- Do not immerse the fan in water or allow water to drip into the motor housing.
- Do not use gasoline, paint thinner, or other chemicals to clean the fan.
- For cleaning the fan blades, the front grille can be carefully removed by following the instructions in the full user manual (if applicable). Otherwise, use a vacuum cleaner with a brush attachment to remove dust from the grille.
- Store the fan in its original packaging or cover it to protect it from dust when not in use for extended periods.



Figure 5: Fan Grille. A detailed close-up of the Honeywell HF715 fan's front grille, showing the design of the air intake and fan blades.

8. TROUBLESHOOTING

If your fan is not operating correctly, please check the following common issues before contacting customer support:

Problem	Possible Cause	Solution
Fan does not turn on.	No power to the unit.	Ensure the power cord is securely plugged into a working electrical outlet. Check household fuse/circuit breaker.
Fan operates but airflow is weak.	Fan speed is set too low. Air intake/exhaust is blocked.	Increase the fan speed setting. Clear any obstructions from the fan's grilles.
Remote control is not working.	Remote batteries are dead or incorrectly inserted. Obstruction between remote and fan.	Replace batteries with new ones, ensuring correct polarity. Ensure a clear line of sight between the remote and the fan's sensor.

Problem	Possible Cause	Solution
Fan is making unusual noise.	Fan blades or grilles are dirty. Fan is not on a stable surface.	Clean the fan blades and grilles as per maintenance instructions. Place the fan on a flat, stable surface.

9. SPECIFICATIONS

- **Model:** HF715
- **Brand:** Honeywell
- **Color:** Black
- **Electric Fan Design:** Floor Fan
- **Power Source:** Corded Electric
- **Product Dimensions:** 9.8"D x 16.9"W x 20.6"H
- **Item Weight:** 8.5 Pounds
- **Voltage:** 127 Volts
- **Number of Blades:** 3
- **Control Method:** Remote, Touch
- **Indoor/Outdoor Usage:** Indoor
- **Included Components:** Remote
- **Manufacturer:** Kaz

Turbo Force[®] Power



Electronic
LED Controls



Auto-Off Timer

Total Unit Size:
16.9" L x 9.8" W x 20.6" H



Figure 6: Controls and Dimensions. An image highlighting the electronic LED controls and auto-off timer of the Honeywell HF715 fan, along with its total unit dimensions (16.9" L x 9.8" W x 20.6" H).

10. WARRANTY AND SUPPORT

For warranty information or customer support, please contact Honeywell customer service. Keep your purchase receipt as proof of purchase.

Manufacturer: Kaz