

[Manuals.plus](#) /

> [iLive Electronics](#) /

> iLive Electronics Truly Wire-Free Earbuds with Active Noise Canceling, Charging Case, Includes 3 Set of Ear Tips, Black (IAEBT600B) - User Manual

iLive Electronics IAEBT600B

iLive Electronics Truly Wire-Free Earbuds (IAEBT600B)

User Instruction Manual

INTRODUCTION

Thank you for choosing the iLive Electronics Truly Wire-Free Earbuds (IAEBT600B). These earbuds offer a seamless audio experience with active noise canceling, a sweatproof design, and convenient on-ear controls. This manual provides essential information to help you set up, operate, and maintain your earbuds for optimal performance.

Key Features:

- Truly Wire-Free Design
- Active Noise Canceling (ANC)
- Sweatproof Construction
- Bluetooth v5.0 Connectivity
- Integrated Charging Case for Extended Playtime
- On-Ear Controls for Playback, Calls, and Voice Assistant
- Built-in Microphone for Hands-Free Calling

Package Contents:

- Truly Wire-Free Earbuds (L & R)
- Charging Case
- USB-C Charging Cable
- 3 Sets of Ear Tips (Small, Medium, Large)





The iLive Truly Wire-Free Earbuds (IAEBT600B) shown with their compact charging case.

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. The charging case acts as a portable power bank for your earbuds.

1. Place the earbuds into their respective slots in the charging case. Ensure they are seated correctly to make contact with the charging pins.
2. Connect the supplied USB-C cable to the charging port on the case and the other end to a USB power source (e.g., computer USB port, USB wall adapter).
3. The LED indicators on the charging case will illuminate to show charging status. Once fully charged, the indicators may change or turn off depending on the model.



The earbuds are placed inside the charging case for power replenishment.




The charging case provides extended playtime and features a charging indicator.

2. Bluetooth Pairing

The earbuds are pre-paired with each other out of the box. You only need to pair them with your device.

1. Ensure the earbuds are charged and removed from the charging case. They will automatically enter pairing mode.
2. On your smartphone, tablet, or other Bluetooth-enabled device, go to the Bluetooth settings.
3. Search for new devices. You should see "IAEBT600B" or a similar name appear in the list of available devices.
4. Select "IAEBT600B" to connect. Once connected, you will hear an audio confirmation, and the earbud indicator lights may change.



Effortlessly stream audio from your smartphone via Bluetooth wireless technology.

3. Fitting the Earbuds

Proper fit is crucial for comfort, sound quality, and effective Active Noise Canceling.

1. The earbuds come with three sizes of ear tips (Small, Medium, Large). Experiment with each size to find the one that provides the most secure and comfortable fit for your ears.
2. Gently insert the earbud into your ear canal and twist slightly to ensure a snug seal.



FORM & FUNCTION

Designed for a comfy, secure fit that's durable and easy to use

The earbuds are designed for a comfortable, secure fit, with three eartip sizes included to ensure proper sealing.

OPERATING THE EARBUDS

On-Ear Controls:

The earbuds feature multi-function touch controls for various operations:

- **Play/Pause:** Single tap on either earbud.
- **Skip Track:** Double tap on the right earbud for next track, double tap on the left earbud for previous track.
- **Answer/End Call:** Single tap on either earbud during an incoming call.
- **Reject Call:** Press and hold on either earbud during an incoming call.
- **Activate Voice Assistant (Siri/Google Assistant):** Triple tap on either earbud.
- **ANC On/Off:** Press and hold the touch control area on the right earbud for approximately 2 seconds to toggle Active Noise Canceling.

Active Noise Canceling (ANC):

The ANC feature reduces ambient noise, allowing for a more immersive listening experience. Activate or deactivate ANC using the on-ear controls as described above.



Tune out noise with Active Noise Cancellation or let the world in with Transparency Mode, all with a simple tap.

Making and Receiving Calls:

With the built-in microphone, you can make and receive calls hands-free when connected to your smartphone.

- Ensure your earbuds are paired with your phone.
- Use the on-ear controls to manage calls.

MAINTENANCE

Cleaning:

- Regularly clean the earbuds, especially the ear tips and charging contacts, with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, alcohol, or chemical solvents.
- Remove ear tips and clean them separately with mild soap and water if necessary, ensuring they are completely dry before reattaching.

Storage:

- When not in use, store the earbuds in their charging case to protect them and keep them charged.
- Store in a cool, dry place away from extreme temperatures and direct sunlight.

Water Resistance:

The earbuds feature a sweatproof design, making them suitable for workouts and light exposure to moisture. However, they are not designed for submersion in water. Avoid exposing them to heavy rain or swimming.

TROUBLESHOOTING

If you encounter issues with your earbuds, refer to the following common solutions:

Problem	Possible Solution
---------	-------------------

Problem	Possible Solution
Earbuds not turning on	Ensure earbuds and charging case are fully charged. Place earbuds in case, close, then reopen.
Earbuds not pairing with device	• Make sure Bluetooth is enabled on your device. • Ensure earbuds are in pairing mode (removed from case). • Forget/remove "IAEBT600B" from your device's Bluetooth list and try pairing again. • Move earbuds closer to your device.
Only one earbud has sound	• Place both earbuds back into the charging case, close the lid, wait a few seconds, then remove them. This often re-syncs them. • Ensure both earbuds are charged.
Poor sound quality or intermittent connection	• Ensure earbuds are fully charged. • Reduce the distance between earbuds and your device. • Avoid obstacles between the earbuds and your device. • Try resetting the earbuds (refer to manufacturer's website for specific reset instructions if not covered here).
Active Noise Canceling not working	• Ensure ANC is activated via the on-ear controls. • Check for proper earbud fit and seal in your ear.

SPECIFICATIONS

Detailed technical specifications for the iLive Electronics IAEBT600B Truly Wire-Free Earbuds:

Feature	Detail
Model Name	Wire-Free Earbuds (IAEBT600B)
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	5.0
Wireless Range	Up to 49 feet (15 meters)
Noise Control	Active Noise Cancellation
Battery Life (Earbuds)	~5 hours at 50% volume with ANC On; ~4 hours at 100% volume with ANC On
Charging Port	USB Type C
Water Resistance Level	Sweatproof (Waterproof)
Control Type	Touch, Voice

Feature	Detail
Compatible Devices	Smartphones, Tablets, Laptops, Desktops (Bluetooth enabled)
Item Weight	2.24 ounces (63.5 grams)
Product Dimensions	2.36 x 3.86 x 1.3 inches (6 x 9.8 x 3.3 cm)
Material	Plastic
Earpiece Shape	Bud (In-Ear)
Impedance	16 Ohm
UPC	047323704734

WARRANTY AND SUPPORT

Warranty Information:

Specific warranty details for the iLive Electronics IAEBT600B earbuds are typically provided with the product packaging or can be found on the official iLive Electronics website. Please retain your proof of purchase for warranty claims.

Customer Support:

For further assistance, technical support, or inquiries regarding your iLive Electronics earbuds, please visit the official iLive Electronics website or refer to the contact information provided in your product documentation.

© 2023 iLive Electronics. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B091Q39GV6>

More documents and user manuals: <https://manuals.plus/>