

## SAMSUNG VS20R9046P3

# SAMSUNG Jet 90 + Clean Station Bundle Cordless Stick Vacuum User Manual

Model: VS20R9046P3

## 1. INTRODUCTION

This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your SAMSUNG Jet 90 + Clean Station Bundle Cordless Stick Vacuum. Please read this manual thoroughly before using the appliance and retain it for future reference.

## 2. SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, or injury. This appliance is for household use only.

- Do not operate the vacuum cleaner with a damaged cord or plug.
- Do not use the vacuum cleaner on wet surfaces or to pick up liquids.
- Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Turn off all controls before unplugging.

## 3. PACKAGE CONTENTS

Verify that all components are present in your package:

- SAMSUNG Jet 90 Cordless Stick Vacuum Main Unit
- Clean Station

- Soft Action Brush
- Mini Motorized Tool
- Long Crevice Tool
- Combination Tool
- Flexible Tool
- Rechargeable Battery
- Charging Stand



Image: All components included in the SAMSUNG Jet 90 + Clean Station Bundle.

## 4. SETUP

### 4.1 Assembling the Vacuum

Attach the desired cleaning tool or pipe to the main vacuum unit. Ensure it clicks securely into place.

## 4.2 Charging the Battery

The removable/reusable battery can be charged directly on the vacuum when docked on the charging stand, or separately on the dual charging station. A full charge takes approximately 3 hours.



**Dual Charging Station  
and Battery**

Charge two batteries\* at once in just 3.5 hours.

**Removable/Reusable  
Battery**

Longer 60-minute run time for uninterrupted cleaning.\*\*

\*Second battery sold separately

\*\*Stated run time applies to the minimum power level with a non motorized tool attached. Second battery purchased separately.

Image: The dual charging station allows for charging two batteries simultaneously.

## 4.3 Setting up the Clean Station

Place the Clean Station in a convenient location near a power outlet. It is designed to automatically empty the vacuum's dustbin.

# Auto Empty Dustbin

Easily and automatically empty dust from your Jet™ Cordless Vacuum for simple maintenance.



Clean Station Dimensions (WxHxD): 7<sup>7/25</sup>" x 23<sup>31/50</sup>" x 7<sup>2/25</sup>"  
Weight: 12.12 lbs.

Image: The Clean Station automatically empties the dust from your Jet Cordless Vacuum.

## 5. OPERATING


### 5.1 Powering On and Adjusting Suction

Press the power button to turn on the vacuum. Use the control buttons to adjust the suction power according to your cleaning needs. The vacuum offers up to 200 Air Watts of cleaning performance.



## 5-Layer Filtration System

Captures pet dander, pollen, and other nonliving allergens for cleaner air in your home. The filter system picks up large dust particles, captures fine dust, and traps 99.999%\* of microdust.\*



\* Based on third-party testing by SLG, using Max mode, in accordance with the IEC62885-2 CL5.11 standard.

Image: The vacuum provides powerful suction for various floor types.

### 5.2 Adjusting Telescopic Pipe Length

The telescopic pipe features four available length adjustments for comfortable use, allowing you to reach high or low areas with ease.

# Telescopic Pipe

Four available length adjustments for comfortable use.



Image: The telescopic pipe can be adjusted to four different lengths for ergonomic cleaning.

## 5.3 Using the Soft Action Brush

The Soft Action Brush is ideal for delicate hard floors like parquet, effectively picking up dust and debris without scratching surfaces.



## Lightweight Design

Easily maneuver to vacuum stairs, under sofas, or above high cabinets.

Dimensions (WxHxD): 9<sup>7</sup>/<sub>8</sub>" x 44<sup>3</sup>/<sub>4</sub>" x 8<sup>1</sup>/<sub>2</sub>"  
Weight: 6.17lbs.

Image: The lightweight design allows for easy maneuverability under furniture and on stairs.

### 5.4 Using the Spinning Sweeper Mop Attachment (Optional)

If you have the Spinning Sweeper mop attachment, attach it to the main vacuum unit. Ensure the reusable wet pads or disposable wet pads are securely attached to the spinning discs. Fill the water tank on the attachment with water or a suitable cleaning solution. The spinning action of the pads will clean hard floors. Remember to remove and clean the pads after use.

## 6. MAINTENANCE

## 6.1 Emptying the Dustbin with Clean Station

Place the vacuum's dustbin into the Clean Station. The Clean Station will automatically extract dust and debris into a disposable bag, ensuring a hygienic emptying process.

## 6.2 Cleaning the 5-Layer Filtration System

The vacuum features a 5-layer filtration system designed to capture pet dander, pollen, and other non-living allergens, trapping 99.999% of microdust. Regularly clean or replace the filters as recommended to maintain optimal performance and air quality.



Image: Diagram illustrating the 5-layer filtration system for enhanced air purification.

## 6.3 Cleaning Brush Heads and Mop Pads

Periodically inspect and clean the brush heads to remove tangled hair or debris. For the Spinning Sweeper mop attachment, remove and wash the reusable mop pads after each use. Replace disposable pads as needed.

## 7. TROUBLESHOOTING

If you encounter issues with your SAMSUNG Jet 90 + Clean Station Bundle, refer to the following common solutions:

- **No Power:** Ensure the battery is fully charged and correctly inserted. Check if the charging stand is properly connected to a power outlet.
- **Reduced Suction:** Check the dustbin for fullness and empty it if necessary. Inspect the filters for clogs and clean them. Ensure there are no blockages in the brush head, pipe, or hose.
- **Unusual Noise:** Turn off the vacuum immediately. Check for any foreign objects caught in the brush head or air pathways.
- **Clean Station Not Emptying:** Ensure the vacuum's dustbin is correctly seated in the Clean Station. Check if the Clean Station's disposable bag is full and needs replacement.

For persistent issues, please contact SAMSUNG customer support.

## 8. SPECIFICATIONS

Feature	Detail
Brand	SAMSUNG
Model Name	Jet 90 + CS
Item Model Number	VS20R9046P3
UPC	887276523088
Color	Gray
Special Feature	Bagless
Filter Type	Disk (5-Layer Filtration System)
Included Components	Clean Station
Is Cordless?	Yes
Wattage	500 watts
Charging Time	3 Hours
Form Factor	Stick
Product Dimensions	8.5"L x 9.8"W x 44.7"H
Battery Description	Lithium-Ion
Noise Level	78 dB
Item Weight	40.2 pounds

Indoor/Outdoor Usage	Indoor
----------------------	--------

---

## **9. WARRANTY AND SUPPORT**

For warranty information, product registration, or technical support, please refer to the official SAMSUNG website or contact their customer service directly. Keep your proof of purchase for warranty claims.