

Lemax 12036

Lemax 12036 Caddington Village Figurine: Bakery Delivery Instruction Manual

Brand: Lemax | Model: 12036

INTRODUCTION

Thank you for choosing the Lemax 12036 Caddington Village Bakery Delivery figurine. This detailed collectible is designed to enhance your miniature village display, bringing a touch of charm and realism. This manual provides essential information for the proper handling, setup, and care of your figurine to ensure its longevity and aesthetic appeal.

SAFETY INFORMATION

WARNING: This product is not suitable for children under 8 years of age. It contains small parts and is intended for decorative purposes only. Adult supervision is required if children are present near the display. Handle with care to prevent breakage.

SETUP AND PLACEMENT

The Lemax 12036 Bakery Delivery figurine is a static decorative piece. No assembly is required.

- Unpacking:** Carefully remove the figurine from its packaging. Retain the original packaging for future storage, if desired.
- Surface Preparation:** Choose a stable, flat, and clean surface for display. Ensure the surface is free from dust and debris to prevent damage to the figurine's base.
- Placement:** Position the figurine in your Caddington Village display or any desired decorative setting. Consider its scale and theme to create a harmonious arrangement. Avoid placing it near edges where it could easily fall.
- Environmental Considerations:** Place the figurine away from direct sunlight, extreme temperatures, and high humidity to prevent fading or material degradation.



Image 1: The Lemax 12036 Caddington Village Bakery Delivery figurine. It depicts a woman in a red bonnet and blue dress, pushing a blue bread cart filled with various loaves of bread. The cart is labeled "FRESH BREAD" and lists "RYE, WHEAT, SOURDOUGH, BAGUETTES, ROLLS, BISCUITS".

OPERATING (DISPLAY)

This figurine is a static display item and does not require any operational steps. Once placed, it serves as a visual element within your miniature village or seasonal decor.

- **Integration:** Integrate the Bakery Delivery figurine with other Lemax Caddington Village pieces to create a vibrant and cohesive scene.
- **Lighting:** Consider adding appropriate lighting to your display to highlight the figurine's details, especially during evening hours.

MAINTENANCE AND CARE

Proper care will help maintain the appearance and integrity of your figurine for many years.

- **Cleaning:** Gently dust the figurine regularly with a soft, dry brush or a lint-free cloth. Avoid using abrasive cleaners or harsh chemicals, as these can damage the paint and finish.
- **Handling:** Always handle the figurine by its base to prevent damage to delicate parts. Avoid dropping or subjecting it to impacts.
- **Storage:** When not on display, store the figurine in its original packaging or a protective container in a cool, dry place, away

from direct sunlight and extreme temperatures.

TROUBLESHOOTING

While the Lemax 12036 figurine is a simple decorative item, minor issues can sometimes occur.

- **Broken Parts:** In the event of a small part breaking off (e.g., an arm, a piece of bread), it may be possible to reattach it using a strong, clear adhesive suitable for resin or ceramic materials. Apply adhesive sparingly and hold the piece in place until set.
- **Fading Colors:** If colors appear to fade over time, it is likely due to prolonged exposure to direct sunlight. Relocate the figurine to a shaded area to prevent further fading.
- **Instability:** If the figurine appears unstable on its display surface, ensure the surface is perfectly flat. A small piece of non-slip padding under the base can also help.

SPECIFICATIONS

Brand	Lemax
Model Number	12036
Product Dimensions (L x W x H)	4 x 3 x 8 cm
Item Weight	58.97 grams
Material	Resin
Finish Type	Realistic
Assembly Required	No
Batteries Required	No
Theme	Religious (Christmas Village)
Occasion	Christmas
Age Range (Description)	Child, Adult (8+ years with supervision)

WARRANTY AND SUPPORT

For information regarding warranty, returns, or customer support, please refer to the retailer's policy where the product was purchased or visit the official Lemax website. Keep your proof of purchase for any warranty claims.

© 2026 Lemax. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question