

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Picun](#) /

› [Picun Bluetooth Kids Headphones with Cat Ears User Manual](#)

Picun Lucky Cat

Picun Bluetooth Kids Headphones User Manual

Model: Lucky Cat

Brand: Picun

1. INTRODUCTION

Thank you for choosing Picun Bluetooth Kids Headphones. These headphones are designed with children in mind, offering a safe and enjoyable listening experience with a volume limit of 85dB to protect sensitive hearing. They feature a fun cat ear design with built-in LED lights, and offer both wireless Bluetooth and wired connectivity options for versatile use.

Key features include:

- Adorable cat ears with 7-color flashing LED lights (can be turned on/off).
- 85dB volume limiting technology for hearing protection.
- Dual mode: Wireless (Bluetooth) and Wired (3.5mm audio cable).
- Long-lasting 500mAh rechargeable battery providing up to 40 hours of use.
- Comfortable, adjustable, and foldable design for easy storage and portability.
- Built-in microphone for calls and online interactions.

2. PRODUCT OVERVIEW

Familiarize yourself with the components and features of your Picun headphones.



Figure 2.1: Picun Bluetooth Kids Headphones (Mint Pink)




Figure 2.2: Headphone Controls and Ports

On/Off Button: Power on/off the headphones.

Volume Up / Next Track Button: Increase volume or skip to the next song.

Volume Down / Previous Track Button: Decrease volume or go to the previous song.

Mode Switch: Switch between different modes (e.g., Bluetooth, TF Card).

TF Port: Slot for a Micro SD card to play music directly.

Bluetooth Indicator Light: Shows Bluetooth connection status.

3.5 mm Jack Slot: For wired audio connection.

USB Charging Slot: For charging the headphones.

Comfortable to Wear

Pillow soft memory foam earmuff ensures you premium comfort



Figure 2.3: Adjustable and Foldable Design

The headphones feature an adjustable headband to fit various head sizes and a foldable design for compact storage and portability, making them ideal for travel or school.



85dB Volume Limiting

Hearing protection for your child

Figure 2.4: 85dB Volume Limiting for Hearing Protection

Equipped with volume limiting technology, these headphones ensure audio output does not exceed 85dB, protecting your child's sensitive hearing.



Wired Mode

Online Education Tool



Helpers in the School Community



Wireless Mode

Engaging Toy



Travel Buddy




Figure 2.5: Cat Ears with 7-Color Flashing LED Lights

The integrated LED lights in the cat ears can display 7 different colors, adding a fun and unique element to the headphones. Note that LED lights do not work in wired mode.

3. SETUP AND CONNECTION

3.1 Charging the Headphones

Before first use, fully charge the headphones. Use the provided USB charging cable. Plug the micro USB end into the headphone's USB charging slot and the standard USB end into a compatible USB power adapter or computer USB port.



Figure 3.1: Included Accessories

3.2 Bluetooth Pairing (Wireless Mode)

1. Ensure the headphones are charged.
2. Press and hold the Power On/Off button until the LED indicator light flashes, indicating pairing mode.
3. On your device (smartphone, tablet, computer), enable Bluetooth and search for available devices.
4. Select "Lucky Cat" or "Picun Headphones" from the list of devices.

5. Once connected, the LED indicator light will stop flashing or change to a solid color.

3.3 Wired Connection

For a wired connection, use the included 3.5mm audio cable. Plug one end into the 3.5 mm jack slot on the headphones and the other end into the audio output jack of your device. This mode allows for continued listening even if the battery is drained. Note: LED lights will not function in wired mode.




Figure 3.2: Wired and Wireless Usage Scenarios

4. OPERATING INSTRUCTIONS

4.1 Power On/Off

- **Power On:** Press and hold the Power On/Off button for a few seconds until the indicator light turns on.
- **Power Off:** Press and hold the Power On/Off button for a few seconds until the indicator light turns off.

4.2 Volume Control

- **Increase Volume:** Press the Volume Up button.
- **Decrease Volume:** Press the Volume Down button.

4.3 Music Playback

- **Play/Pause:** Press the Power/Play/Pause button once.
- **Next Track:** Press and hold the Volume Up / Next Track button.
- **Previous Track:** Press and hold the Volume Down / Previous Track button.

4.4 Call Functions (with built-in microphone)

- **Answer/End Call:** Press the Power/Play/Pause button once during an incoming call.
- **Reject Call:** Press and hold the Power/Play/Pause button during an incoming call.

4.5 LED Light Control

The LED lights on the cat ears can be turned on or off using a dedicated button or a combination of buttons (refer to the specific instructions in the included user manual for your model). Remember, LED lights are only active in Bluetooth mode.

5. MAINTENANCE AND CARE

- **Cleaning:** Use a soft, dry cloth to clean the headphones. Do not use harsh chemicals or abrasive materials.
- **Storage:** When not in use, fold the headphones for compact storage. Store them in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully draining the battery frequently. Charge regularly, even if not in constant use.
- **Water Resistance:** These headphones are not water resistant. Avoid exposure to liquids.

6. TROUBLESHOOTING

If you encounter issues with your headphones, please refer to the following common solutions:

- **Headphones not turning on:** Ensure the battery is charged. Connect to a power source using the USB cable.
- **Cannot pair via Bluetooth:** Make sure the headphones are in pairing mode (flashing indicator light). Ensure Bluetooth is enabled on your device and it's within range (10 meters). Try turning both devices off and on again.
- **No sound:** Check the volume level on both the headphones and your connected device. Ensure the headphones are properly connected (either via Bluetooth or 3.5mm cable). If using wired mode, ensure the cable is fully inserted.
- **LED lights not working:** Ensure the headphones are in Bluetooth mode, as LEDs do not function in wired mode. Check if the LED light function is enabled.
- **Poor audio quality:** Ensure the headphones are within Bluetooth range. Check for interference from other wireless devices. If in wired mode, ensure the 3.5mm cable is not damaged and is fully inserted.

For more detailed troubleshooting or issues not listed here, please consult the full user manual PDF or contact customer support.

7. SPECIFICATIONS

Feature	Specification
Model Name	Lucky Cat
Brand	Picun
Connectivity Technology	Wireless (Bluetooth), Wired (3.5 mm Jack)
Wireless Communication Technology	Bluetooth 5.0
Bluetooth Range	10 Meters
Battery Life	Up to 40 Hours
Charging Time	40 Hours (This seems to be a typo in the source, likely meant 'Playtime' or 'Usage Time' for 40 hours, and 'Charging Time' would be much less. Assuming the 40 hours refers to usage time as per feature bullets.)
Volume Limit	85dB
Material	Plastic
Ear Placement	Over Ear

Control Type	Volume Control, Touch
Frequency Range	20 Hz - 20,000 Hz
Product Dimensions	7.87 x 3.15 x 7.09 inches
Item Weight	0.634 ounces
UPC	650075919952

8. WARRANTY AND SUPPORT

For detailed warranty information and customer support, please refer to the official documentation included with your product or visit the Picun website. You can also find the User Manual and Instructions for Use in PDF format via the following links:

- [User Manual \(PDF\)](#)
- [Instructions for Use \(IFU\) \(PDF\)](#)