

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Teamson Home](#) /

› [Teamson Home Outdoor PE Rattan Dining Set for Four \(Model PT-OF0021\) - Instruction Manual](#)

## Teamson Home PT-OF0021

# Teamson Home Outdoor PE Rattan Dining Set for Four

Model: PT-OF0021

## IMPORTANT SAFETY INFORMATION

Please read and understand all instructions before assembly and use of this product. Retain this manual for future reference.

**CAUTION:** This product requires assembly. Use caution when handling sharp edges and small parts during assembly. Always follow the assembly instructions provided. For outdoor use, ensure the product is properly secured and maintained to prevent tip-overs or instability due to weather conditions.

- Keep all packaging materials away from children.
- Ensure all bolts and screws are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not stand or sit on the table.
- Distribute weight evenly on the table and chairs.
- Avoid placing hot items directly on the tabletop without protection.
- Do not use abrasive cleaners or materials that could damage the finish.

## PACKAGE CONTENTS

Verify that all components are present before beginning assembly. If any parts are missing or damaged, contact customer support.

- 1 x Dining Table with Acadia Wood Top
- 4 x PE Rattan Armchairs
- 4 x Water-Resistant Cushions
- Assembly Hardware (bolts, washers, Allen wrench)
- Assembly Instruction Manual (separate document)

## SETUP AND ASSEMBLY

Assembly is required for this dining set. Refer to the separate detailed assembly instruction manual included in your package for step-by-step guidance. The general process involves:

1. Unpack all components and lay them out on a soft, clean surface to prevent scratching.
2. Assemble the dining table frame and attach the Acadia wood tabletop. Ensure the umbrella hole is correctly oriented if you plan to use an umbrella.
3. Assemble each armchair by attaching the seat, backrest, and legs as per the instructions.
4. Securely tighten all bolts and screws using the provided Allen wrench. Do not overtighten.
5. Place the water-resistant cushions onto the chairs.



Image 1: The Teamson Home Outdoor PE Rattan Dining Set assembled, featuring the table and four chairs.



Image 2: Diagram illustrating the dimensions of the dining table and chairs in centimeters and inches.



Image 3: A close-up view of the Acadia wood-slated tabletop, showcasing its natural grain and construction.



Image 4: Detail of the central umbrella hole integrated into the Acadia wood tabletop, designed to accommodate a standard patio umbrella (not included).

## OPERATING INSTRUCTIONS

---

This dining set is designed for outdoor use on patios, decks, gardens, poolside areas, or sunrooms.

- **Placement:** Position the dining set on a flat, stable surface to ensure stability and prevent wobbling.
- **Umbrella Use:** The table features a central hole for a standard patio umbrella (umbrella not included). Insert the umbrella pole through the hole and secure it with a suitable umbrella base (not included) for stability.
- **Cushions:** The included cushions are water-resistant. While they can withstand light moisture, it is recommended to store them indoors during heavy rain or prolonged periods of non-use to extend their lifespan.
- **Seating:** The set accommodates four individuals comfortably.



Image 5: The dining set positioned on an outdoor patio, demonstrating its intended use in an open-air environment.

## MAINTENANCE AND CARE

---

Proper care will extend the life and appearance of your dining set.

- **General Cleaning:** Wipe clean with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaning pads.
- **PE Rattan:** The PE rattan is UV-protected. Clean with mild soap and water. Rinse thoroughly and allow to air dry.
- **Acadia Wood Tabletop:** The Acadia wood tabletop should be cleaned regularly. To maintain its appearance and protect against weathering, periodic application of a suitable outdoor wood sealant or oil is recommended.
- **Cushions:** The cushion covers are removable and can be cleaned. Follow the care instructions on the cushion labels. For general cleaning, spot clean with a mild soap solution and air dry. Store cushions indoors when not in use or during inclement weather.
- **Winter Storage:** During winter months or prolonged periods of non-use, it is advisable to cover the furniture or store it in a dry, sheltered area to protect it from extreme weather conditions.




Image 6: A detailed view of the brown PE rattan weave, highlighting the texture and construction of the chair material.

## TROUBLESHOOTING

---

If you encounter any issues with your dining set, refer to the following common solutions:

- **Wobbling Table/Chairs:** Check all assembly bolts and screws. Re-tighten any loose connections. Ensure the furniture is placed on a level surface.
- **Cushion Discoloration/Mildew:** Ensure cushions are dry before storing. Clean with a mild bleach solution (diluted) if mildew appears, then rinse thoroughly and air dry completely.
- **Wood Fading/Cracking:** This is natural for outdoor wood. Apply a suitable outdoor wood oil or sealant periodically to protect and restore the wood's appearance.
- **Rattan Damage:** For minor fraying, a strong adhesive can sometimes be used. For significant damage, contact customer support for potential repair options or replacement parts.

## SPECIFICATIONS

---

Feature	Detail
---------	--------

Brand	Teamson Home
Model Name	Patio Sets
Model Number	PT-OF0021
Color	Brown
Material	PE Rattan, Acadia Wood, Polyester (cushions)
Table Dimensions (L x W x H)	47 in. x 27.6 in. x 29 in. (120 cm x 70 cm x 74 cm)
Chair Dimensions (L x W x H)	22.8 in. x 24.4 in. x 33.1 in. (58 cm x 62 cm x 84 cm)
Item Weight	79.2 pounds (approximate total)
Assembly Required	Yes
Umbrella Hole	Yes (standard size)

## WARRANTY INFORMATION

---

Teamson Home products are manufactured to high-quality standards. For specific warranty details regarding your Outdoor PE Rattan Dining Set, please refer to the warranty documentation included with your purchase or visit the official Teamson Home website. Warranty coverage typically addresses manufacturing defects under normal use.

## CUSTOMER SUPPORT

---

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact Teamson Home customer support:

- **Website:** Visit the official Teamson Home website for support resources, FAQs, and contact forms.
- **Purchase Point:** Contact the retailer from whom you purchased the product for assistance.