MOFII GO 180

Mofii Go180 Wireless Keyboard and Mouse Set User Manual

Model: GO 180

1. Introduction

Thank you for choosing the Mofii Go180 Wireless Keyboard and Mouse Set. This manual provides essential information for setting up, operating, and maintaining your new wireless peripheral devices. Please read this manual carefully before use and retain it for future reference.

The Mofii Go180 set offers reliable wireless connectivity, designed for compatibility with PC and laptop systems. It features an ergonomic design for comfortable use and an English keyboard layout.

2. Package Contents

Please check the package contents to ensure all items are present:

- 1 x Mofii Go180 Wireless Keyboard
- 1 x Mofii Go180 Wireless Mouse
- 1 x USB Receiver (typically stored in the mouse battery compartment)
- 1 x User Manual (this document)

3. Setup Guide

Follow these steps to set up your Mofii Go180 Wireless Keyboard and Mouse Set:

1. **Install Batteries:**
    - **Keyboard:** Open the battery compartment on the underside of the keyboard. Insert the required batteries (e.g., AAA) according to the polarity indicators (+/-). Close the compartment.
    - **Mouse:** Open the battery compartment on the underside of the mouse. If the USB receiver is stored here, remove it. Insert the required batteries (e.g., AA or AAA) according to the polarity indicators. Close the compartment.

2. **Connect USB Receiver:** Plug the USB receiver into an available USB port on your computer (PC or laptop). Your operating system should automatically detect and install the necessary drivers.
3. **Power On:** Locate the power switch on the underside of both the keyboard and the mouse. Slide the switches to the "ON" position.
4. **Test Connection:** Once powered on, the keyboard and mouse should be ready for use. Test by typing on the keyboard and moving/clicking the mouse.



This image displays the Mofii Go180 wireless keyboard and mouse set. The keyboard is black with yellow accents and black keys, while the mouse is black with a yellow base and scroll wheel. This illustrates the components of the set.

4. Operating Instructions

The Mofii Go180 set operates on a 2.4GHz wireless frequency, providing a stable connection within a typical operating range (usually up to 10 meters). Ensure the USB receiver is within this range and not obstructed by large metal objects.

4.1 Keyboard Functions

- **Standard Typing:** Use the keys as you would a standard keyboard.
- **Function Keys (Fn):** Some keys may have secondary functions accessible by holding down the **Fn** key and pressing the corresponding function key (e.g., F1-F12 for media control, volume, etc.). Refer to the keycap legends for specific functions.
- **Ergonomic Design:** The keyboard is designed for comfortable typing during extended use.

4.2 Mouse Functions

- **Left Click:** Primary selection and activation.
- **Right Click:** Accesses context menus.
- **Scroll Wheel:** Scrolls through documents and web pages. Can also function as a middle click.
- **Optical Tracking:** The mouse uses optical technology for precise cursor movement. For best performance, use on a non-reflective, opaque surface.

5. Maintenance

Proper maintenance ensures the longevity and optimal performance of your Mofii Go180 set.

- **Cleaning:**
  - Disconnect the USB receiver from your computer.
  - Use a soft, dry, lint-free cloth to wipe the surfaces of the keyboard and mouse.

- For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid excessive moisture.
- Do not spray cleaning solutions directly onto the devices.

- **Battery Replacement:**
  - When performance degrades or devices stop responding, replace the batteries.
  - Always use new batteries of the specified type (e.g., AAA for keyboard, AA/AAA for mouse).
  - Dispose of old batteries responsibly according to local regulations.
- **Storage:** When not in use for extended periods, turn off the devices to conserve battery life. Store the USB receiver in the mouse's battery compartment to prevent loss.

6. Troubleshooting

If you encounter issues with your Mofii Go180 set, please refer to the following common solutions:

- **Devices Not Responding:**
  - Ensure the power switches on both the keyboard and mouse are in the "ON" position.
  - Check if the batteries are correctly installed and have sufficient charge. Replace if necessary.
  - Verify that the USB receiver is securely plugged into a working USB port on your computer. Try a different USB port.
  - Move the keyboard and mouse closer to the USB receiver to rule out range issues or interference.
  - Restart your computer.
- **Lagging or Intermittent Connection:**
  - Ensure there are no large metal objects or other wireless devices (e.g., Wi-Fi routers, cordless phones) operating too close to the receiver, which could cause interference.
  - Replace batteries, even if they seem to have some charge left. Low battery can affect wireless performance.
  - Try plugging the USB receiver into a different USB port, preferably one on the front of your computer if using a desktop, for better line of sight.
- **Mouse Cursor Jumps or is Inaccurate:**
  - Clean the optical sensor on the underside of the mouse with a soft, dry cloth.
  - Ensure you are using the mouse on a suitable surface. Avoid highly reflective, transparent, or uneven surfaces. A mouse pad is recommended.

7. Specifications

Feature	Detail
Brand	MOFII
Model Number	GO 180
Connectivity Technology	Wireless (2.4GHz USB Receiver)
Compatibility	PC, Laptop

Feature	Detail
Keyboard Language	English
Keyboard Description	Gaming (Ergonomic)
Mouse Movement Detection	Optical
Color	Black (with yellow accents)
Power Source	Battery Powered (Batteries required)
Item Weight	480 g (Set)
Package Dimensions	35.4 x 15 x 4 cm

8. Warranty and Support

For warranty information and technical support, please refer to the documentation provided with your purchase or contact MOFII customer service directly. Details for contacting support are typically available on the manufacturer's official website or product packaging.

Please retain your proof of purchase for any warranty claims.

© 2023 MOFII. All rights reserved.