

[Manuals.plus](#) /

› [PJ Masks](#) /

› PJ Masks PJ Launching Submarine and Rovers Preschool Toy Instruction Manual (Model F5830)

PJ Masks F5830

PJ Masks PJ Launching Submarine and Rovers Preschool Toy Instruction Manual

Model: F5830 | Brand: PJ Masks

INTRODUCTION

This manual provides essential information for the safe and proper use of your PJ Masks PJ Launching Submarine and Rovers playset. This interactive toy is designed for preschoolers aged 3 and up, allowing them to engage in imaginative underwater adventures with their favorite PJ Masks characters.



Image: The complete PJ Masks PJ Launching Submarine and Rovers playset, featuring the main submarine vehicle, three mini Sub Rovers, and four action figures (Gekko, Owlette, Catboy, and Romeo).

SAFETY INFORMATION

WARNING: Small parts may be generated. This product is not suitable for children under 3 years of age due to potential choking hazards. Adult supervision is recommended during play. This toy is **not intended for water play**.

WHAT'S IN THE BOX

Verify that all components are present before beginning play:

- 1 x PJ Launching Submarine Vehicle
- 3 x Mini PJ Sub Rovers (one each for Catboy, Owlette, and Gekko)
- 3 x PJ Masks Action Figures (Catboy, Owlette, Gekko) in underwater gear
- 1 x Romeo Action Figure
- 1 x Romeo's Squid Sub Vehicle
- 1 x Trapper Net Accessory
- 3 x Underwater-themed Accessories (scuba tank, flashlight, flippers)



Image: All components of the playset laid out, including the submarine, three hero rovers, Romeo's squid sub, hero figures, Romeo figure, and the trapper net.

SETUP

1. **Unpack Components:** Carefully remove all items from the packaging.
2. **Prepare Figures:** Place the Catboy, Owlette, and Gekko action figures into their respective mini Sub Rover vehicles. The figures are designed to fit securely.

3. **Attach Accessories:** The hero figures can wear the included scuba tank, flashlight, and flipper accessories for enhanced play.
4. **Load Rovers:** Open the main compartment of the PJ Launching Submarine. Place the mini Sub Rovers into the designated launching slots within the submarine.



Image: A close-up view of the PJ Launching Submarine with the Gekko mini Sub Rover loaded into its internal compartment, ready for launch.

OPERATING INSTRUCTIONS

Launching Mini Sub Rovers

To launch the mini Sub Rovers from the PJ Launching Submarine:

1. Ensure the PJ Launching Submarine is placed on a flat, stable surface. The launch mechanism is designed to activate only when the submarine is on a flat surface for safety and proper function.
2. Press the designated launch button located on the submarine. This will propel the loaded mini Sub Rover forward.



Image: The Catboy action figure seated inside his blue mini Sub Rover, showcasing the vehicle's design.



Image: The Owlette action figure seated inside her red mini Sub Rover, highlighting the vehicle's details.

Using the Submarine's Grabber Claws

The PJ Launching Submarine features working grabber claws at the front. These can be manually operated to pick up or interact with other small objects during play.

Hero vs. Villain Play

Utilize Romeo's Squid Sub vehicle and the trapper net accessory to create engaging hero versus villain scenarios. The hero figures in their Sub Rovers can interact with Romeo's vehicle and attempt to escape the trapper net.

Your browser does not support the video tag.

Video: An official product video demonstrating the PJ Launching Submarine's features, including the launching mechanism for the mini Sub Rovers and interaction with figures.

MAINTENANCE

To ensure the longevity of your playset:

- **Cleaning:** Wipe the toy surfaces with a soft, damp cloth. Do not submerge the toy in water or use harsh chemicals.
- **Storage:** Store the playset and its components in a clean, dry place away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

Rovers Not Launching

If the mini Sub Rovers are not launching when the button is pressed:

- **Check Surface:** Ensure the PJ Launching Submarine is placed on a completely flat and stable surface. The launch mechanism is designed with a safety feature that prevents activation if the submarine is not level.
- **Proper Loading:** Verify that the mini Sub Rover is correctly seated in the launching slot within the submarine.

SPECIFICATIONS

Product Dimensions	5 x 16.5 x 13.5 inches
Item Weight	3.61 pounds
Model Number	F5830
Manufacturer Recommended Age	3 years and up
Manufacturer	Hasbro
Release Date	September 28, 2021

WARRANTY AND SUPPORT

For warranty information or product support, please refer to the manufacturer's official website or contact their customer service department. Keep your purchase receipt for proof of purchase.