

T-Wolf TF-100

T-Wolf TF-100 Wireless Keyboard and Mouse Combo User Manual

Model: TF-100 | Brand: T-Wolf

1. INTRODUCTION

Thank you for choosing the T-Wolf TF-100 Wireless Keyboard and Mouse Combo. This product is designed to provide a convenient and efficient input solution for your PC or laptop, offering wireless freedom and reliable performance. This manual will guide you through the setup, operation, and maintenance of your new device.

2. PACKAGE CONTENTS

Please check the package contents to ensure all items are present:

- 1 x T-Wolf Wireless Keyboard
- 1 x T-Wolf Wireless Mouse
- 1 x USB Receiver (typically stored inside the mouse or keyboard battery compartment)
- 1 x User Manual (this document)

3. PRODUCT OVERVIEW

The T-Wolf TF-100 combo features a full-size wireless keyboard and a comfortable wireless mouse, both connecting via a single USB receiver.



Figure 3.1: The T-Wolf TF-100 wireless keyboard and mouse combo, showcasing both devices in black.



Figure 3.2: A top-down view of the T-Wolf TF-100 wireless keyboard and mouse, highlighting the full QWERTY layout and the ergonomic mouse design.

Intelligent power saving design

The best power management level 1 dormancy, no receiving dormancy, deep dormancy
three intelligent dormancy modes, 5min do not move the mouse automatically dormancy, slide the
mouse or click the left and right keys to work normally



Figure 3.3: An angled perspective of the T-Wolf TF-100 wireless keyboard, showing the keycaps and overall profile.

4. SETUP GUIDE

Follow these steps to set up your T-Wolf TF-100 wireless keyboard and mouse combo:

1. Install Batteries:

- Open the battery compartment on the underside of the keyboard and mouse.
- Insert the required batteries (typically AA for keyboard, AAA for mouse, or as indicated on the device) ensuring correct polarity (+/-).
- Close the battery compartments securely.

2. **Locate the USB Receiver:** The small USB receiver is usually stored in the battery compartment of the mouse for safekeeping during transport. Remove it carefully.

3. **Connect the USB Receiver:** Plug the USB receiver into an available USB port on your PC or laptop.

4. **Automatic Connection:** The keyboard and mouse should automatically connect to your computer within a few seconds. No additional drivers are typically required for standard functionality.

5. **Test Functionality:** Once connected, test the keyboard by typing and the mouse by moving the cursor and clicking.

5. OPERATING INSTRUCTIONS

The T-Wolf TF-100 combo operates like standard wired peripherals, but with the added convenience of wireless connectivity.

5.1 General Usage

- **Keyboard:** Use the keyboard for typing, navigating, and executing commands as you would with any standard keyboard.
- **Mouse:** The mouse provides precise optical tracking for smooth cursor movement. It features standard left-click, right-click, and scroll wheel functions. The mouse DPI is 1600DPI for accurate tracking.
- **Wireless Range:** The wireless transmission distance is up to 15 meters, providing flexibility in your

workspace.

5.2 Intelligent Power Saving Design

The T-Wolf TF-100 features an intelligent power-saving design to extend battery life. This system includes multiple dormancy modes:

- **Level 1 Dormancy:** The best power management level, with no receiving dormancy.
- **Deep Dormancy:** The device enters a deep dormancy mode after 5 minutes of inactivity.

To reactivate the mouse from dormancy, simply slide the mouse or click the left or right keys. The keyboard will also reactivate upon key press.



Figure 5.1: Illustration of the intelligent power-saving design, showing the mouse entering a low-power state after inactivity.

6. MAINTENANCE

To ensure the longevity and optimal performance of your T-Wolf TF-100 combo, follow these maintenance tips:

- **Cleaning:** Use a soft, dry cloth to clean the surfaces of the keyboard and mouse. For stubborn dirt, a slightly damp cloth can be used, but ensure no moisture enters the device. Avoid harsh chemicals or abrasive cleaners.
- **Battery Replacement:** Replace batteries when performance degrades or the device stops responding. Always use fresh batteries of the correct type.
- **Storage:** When not in use for extended periods, remove the batteries to prevent leakage. Store the devices in a cool, dry place.
- **USB Receiver:** Keep the USB receiver protected. When traveling, store it securely, ideally in the mouse's battery compartment.

7. TROUBLESHOOTING

If you encounter issues with your T-Wolf TF-100 combo, try the following troubleshooting steps:

Problem	Possible Cause	Solution
Keyboard/Mouse not responding	Low or dead batteries. USB receiver not properly connected. Out of range.	Replace batteries. Re-plug the USB receiver into a different USB port. Move the keyboard/mouse closer to the receiver.
Laggy or erratic cursor movement	Low batteries. Interference from other wireless devices. Dirty optical sensor (mouse).	Replace mouse batteries. Move the receiver or devices away from other wireless devices (e.g., Wi-Fi routers, cordless phones). Clean the optical sensor on the mouse with a soft cloth.
Keyboard/Mouse disconnects frequently	Weak signal due to distance or obstacles. Battery issues.	Ensure line of sight between devices and receiver, or reduce distance. Replace batteries.
Keys not registering	Dust or debris under keys. Software conflict.	Gently clean around the affected keys. Restart your computer.

8. SPECIFICATIONS

Detailed technical specifications for the T-Wolf TF-100 Wireless Keyboard and Mouse Combo:

Product parameters

Ray Wolf TF100 wireless waterproof keyway mouse suit

Wireless transmission rate: 1Mbps
frequency: 2402-2480MHz
channel: 16↑ Automatic hopping
Rated operating voltage: 1.5V
Rated working current : 6mA
Wireless transmission distance: 15m
The mouse DPI: 1600DPI
Set details: one mouse keyboard each
Interface: usb interface



Figure 8.1: Image displaying key product parameters for the T-Wolf TF-100 wireless combo.

Feature	Detail
Brand	T-Wolf
Model Number	TF-100
Connection Type	Wireless (USB Receiver)
Compatible Devices	PC, Laptop

Feature	Detail
Color	Black
Wireless Transmission Rate	1Mbps
Frequency	2402-2480MHz
Channel	16 (Automatic Hopping)
Rated Operating Voltage	1.5V
Rated Working Current	6mA
Wireless Transmission Distance	15m
Mouse DPI	1600DPI
Motion Detection (Mouse)	Optical
Hand Orientation (Mouse)	Right
Batteries Required	Yes
Item Weight	580 g
Shipping Dimensions	50.6 x 13.6 x 4.8 cm

9. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation provided with your purchase or visit the official T-Wolf website. Keep your proof of purchase for any warranty claims. For further assistance, you may contact T-Wolf customer service through their official channels.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question