

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [NutriChef](#) /

› [NutriChef NCCW20SBR 20-Piece Non-Stick Cookware and Bakeware Set Instruction Manual](#)

NutriChef NCCW20SBR

NutriChef NCCW20SBR 20-Piece Non-Stick Cookware and Bakeware Set Instruction Manual

Model: NCCW20SBR

INTRODUCTION

This manual provides essential instructions for the safe and effective use, care, and maintenance of your NutriChef NCCW20SBR 20-Piece Non-Stick Cookware and Bakeware Set. Please read all instructions thoroughly before first use and retain this manual for future reference.

PRODUCT OVERVIEW

The NutriChef 20-Piece Cookware and Bakeware Set is designed for comprehensive kitchen use, featuring non-stick surfaces and cool-touch handles. The set includes a variety of pots, pans, bakeware, and essential utensils to support diverse cooking and baking needs.



Image: The complete NutriChef 20-Piece Cookware and Bakeware Set, showcasing various pots, pans, and bakeware items.

Included Components:

- 6-piece bakeware set (muffin pan, loaf pan, square pan, roasting tray, round cake pan, cookie sheets)
- 3 nylon utensils (soup ladle, pasta fork, spatula)
- 1 silicone drainer
- 3 open fry pans (8", 10", 12")
- 1.5-quart saucepot with lid
- 2.5-quart sauce pot with lid
- 5-quart stew pot with lid
- 9.45" grill pan



Image: A selection of cookware pieces from the set, including frying pans, saucepots, a stew pot, a grill pan, and a silicone drainer.



Image: The bakeware components of the set, featuring a muffin pan, loaf pan, square pan, roasting tray, and round cake pan.



HEAT-RESISTANT KITCHEN TOOLS INCLUDED

Image: The heat-resistant nylon and silicone utensils included in the set, such as a spatula, ladle, and pasta fork.

SETUP AND FIRST USE

1. **Unpack:** Carefully remove all items from the packaging.
2. **Wash:** Before first use, wash all cookware and bakeware pieces with warm, soapy water. Rinse

thoroughly and dry completely.

3. **Seasoning (Optional for Non-Stick):** While not strictly necessary for non-stick, a light seasoning can enhance performance. Apply a thin layer of cooking oil (e.g., vegetable, canola) to the non-stick surface, heat over low to medium heat for 30 seconds, then let cool and wipe clean. Repeat if desired.

OPERATING INSTRUCTIONS

General Cooking Guidelines:

- **Heat Settings:** Use low to medium heat for most cooking. High heat can damage the non-stick coating over time and is rarely necessary due to the efficient heat distribution of these pans.
- **Utensils:** Always use nylon, silicone, or wooden utensils to protect the non-stick surface. Avoid metal utensils, which can scratch and damage the coating.
- **Cool-Touch Handles:** The ergonomic handles are designed to remain cool during stovetop use. Always exercise caution and use oven mitts when handling hot cookware, especially after prolonged cooking or oven use.
- **See-Through Lids:** Tempered glass lids allow you to monitor cooking progress without lifting the lid, helping to retain heat and moisture. Lids include vent holes to release steam.

Cooktop Compatibility:

This cookware set is compatible with a variety of heat sources, including:

- Gas cooktops
- Electric cooktops
- Ceramic cooktops
- Induction cooktops



Image: Cookware pieces demonstrating compatibility with induction, gas, and ceramic cooktops.

Oven Use:

All cookware and bakeware pieces are oven safe up to 500°F (260°C). Always use oven mitts when transferring items to and from a hot oven.

Video: An overview of the NutriChef 20-Piece Professional Cookware and Bakeware Set, highlighting its features and components.

MAINTENANCE AND CARE

Cleaning:

- **Hand Washing:** For best results and to prolong the life of the non-stick coating, hand washing with warm, soapy water and a soft sponge is recommended.
- **Dishwasher Safe:** The set is dishwasher safe, but frequent dishwasher use may reduce the lifespan of the non-stick surface and exterior finish.
- **Stubborn Food:** For baked-on food, soak the pan in warm, soapy water for a few minutes before cleaning. Avoid abrasive cleaners, steel wool, or scouring pads.




Image: A non-stick frying pan with an omelet, illustrating the easy food release and cleaning properties.

Storage:

Store cookware and bakeware carefully to prevent scratching the non-stick surface. Placing paper towels or soft cloths between stacked items can help protect the coating.

TROUBLESHOOTING

- **Food Sticking:** Ensure sufficient cooking oil or butter is used. Avoid excessively high heat, which can degrade the non-stick properties. Ensure the pan is clean and free of residue from previous cooking.
- **Uneven Heating:** Verify that the cookware is properly centered on the heat source. For induction cooktops, ensure the pan size matches the burner size for optimal performance.
- **Discoloration:** Minor discoloration on the exterior is normal over time due to heat exposure. This does not affect the performance of the non-stick interior.

SPECIFICATIONS

Feature	Detail
Brand	NutriChef
Model Number	NCCW20SBR
Material	Aluminum (Cookware), Tempered Glass (Lids)

Color	Brown
Handle Material	Bakelite, Stainless Steel, Silicone
Non-Stick Coating	PFOA/PFOS-Free
Cooktop Compatibility	Gas, Electric, Ceramic, Induction
Oven Safe Temperature	Up to 500°F (260°C)
Dishwasher Safe	Yes
Item Weight	27.1 pounds
Product Dimensions	13.39 x 14.37 x 24.61 inches

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact NutriChef customer service directly. Keep your purchase receipt as proof of purchase.