

[Manuals.plus](#) /

› [Bass Jaxx](#) /

› Bass Jaxx Levels Set of 2 Aux-in Gaming Speakers User Manual

Bass Jaxx Levels

Bass Jaxx Levels Set of 2 Aux-in Gaming Speakers User Manual

Model: **Levels** | Brand: **Bass Jaxx**

PRODUCT OVERVIEW

The Bass Jaxx Levels Gaming Speakers are a set of two compact, aux-in compatible speakers designed to enhance your audio experience for computers, tablets, and smartphones. Featuring a minimalist design and dynamic sound, these speakers are ideal for gaming and general multimedia use.



Image: Packaging for the Bass Jaxx Levels Set of 2 Aux-in Gaming Speakers, highlighting features like "High Quality Sound" and "Detachable USB / Aux-in Cable".

WHAT'S IN THE BOX

Upon unboxing your Bass Jaxx Levels Gaming Speakers, please ensure all components are present:

- 2 x Bass Jaxx Levels Speakers
- 1 x Detachable USB / Aux-in Cable

SETUP INSTRUCTIONS

Follow these steps to set up your Bass Jaxx Levels Gaming Speakers:

1. **Placement:** Position the two speakers on a flat, stable surface, such as your desk, ensuring they are equidistant from your listening position for optimal stereo sound.
2. **Power Connection:** Connect the USB end of the provided detachable USB / Aux-in cable to a powered USB port (e.g., on your computer, a USB wall adapter, or a power bank). The speakers are battery powered, but the USB connection is for charging or direct power.
3. **Audio Connection (Aux-in):** Connect the 3.5mm Aux-in jack of the provided cable to the audio output port of your device (computer, tablet, smartphone, etc.).
4. **Power On:** Locate the power button on one of the speakers (typically the main speaker) and press it to turn on the speakers. An indicator light should illuminate.

OPERATING INSTRUCTIONS

Learn how to use your Bass Jaxx Levels Gaming Speakers effectively:

Power On/Off

- To turn on, press and hold the power button until the indicator light illuminates.
- To turn off, press and hold the power button until the indicator light turns off.

Volume Control

Adjust the volume using the dedicated volume controls on the speaker (if available) or directly from your connected device.

Bluetooth Connection (Optional)

While primarily Aux-in, these speakers also support Bluetooth connectivity:

1. Ensure the speakers are powered on.
2. Activate Bluetooth on your device (smartphone, tablet, etc.).
3. Search for "Bass Jaxx Levels" or a similar name in your device's Bluetooth settings.
4. Select the speaker to pair. A confirmation sound or indicator light change may occur.
5. Once paired, audio will stream wirelessly to the speakers. The effective Bluetooth range is approximately 10 meters (33 feet).

App Control (Optional)

If an official Bass Jaxx app is available, download it from your device's app store to access additional control features and settings for your speakers.

MAINTENANCE

To ensure the longevity and optimal performance of your Bass Jaxx Levels Gaming Speakers, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe down the exterior of the speakers. Do not use liquid cleaners, aerosols, or abrasive solvents.
- **Storage:** When not in use for extended periods, store the speakers in a cool, dry place away from direct sunlight and

extreme temperatures.

- **Handling:** Avoid dropping the speakers or subjecting them to strong impacts, as this can damage internal components.
- **Moisture:** These speakers are not waterproof. Keep them away from water, humidity, and spills.

TROUBLESHOOTING

If you encounter issues with your Bass Jaxx Levels Gaming Speakers, refer to the following common problems and solutions:

Problem	Possible Solution
No sound from speakers.	Ensure speakers are powered on and indicator light is active. Check that the Aux-in cable is securely connected to both the speakers and your audio source. Verify the volume on both the speakers and your audio source is turned up. If using Bluetooth, ensure the speakers are paired and connected to the correct device. Test with a different audio source or cable to rule out source/cable issues.
Poor sound quality or distortion.	Reduce the volume on your audio source or speakers to prevent distortion. Ensure the audio cable is fully inserted and not damaged. If using Bluetooth, move your device closer to the speakers to improve signal strength.
Speakers not turning on.	Check the USB power connection. Ensure the USB port is providing power. If battery-powered, ensure the battery is charged.

PRODUCT SPECIFICATIONS

Model Name	Levels
Brand	Bass Jaxx
Speaker Type	Woofer
Connectivity Technology	Bluetooth, Aux-in (Wired)
Wireless Communication Technology	Bluetooth
Bluetooth Range	10 Meters
Audio Output Mode	Stereo
Surround Sound Channel Configuration	2.0
Power Source	Battery Powered
Controller Type	Button
Control Method	App
Color	Black

Item Weight	13.2 ounces
Package Dimensions	6.42 x 5.2 x 4.37 inches
Is Waterproof	FALSE
UPC	192234047668
ASIN	B0923J4B5J

WARRANTY AND SUPPORT

Warranty information for your Bass Jaxx Levels Gaming Speakers is typically provided with your purchase documentation or on the product packaging. Please retain your proof of purchase for warranty claims.

For further assistance, technical support, or to inquire about replacement parts, please visit the official Bass Jaxx website or contact their customer service department. Contact details are usually available on the manufacturer's website or product packaging.

© 2024 Bass Jaxx. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question