

[Manuals.plus](#) /

› [Casaria](#) /

› Casaria Polyrattan Garden Bench Instruction Manual

Casaria B08YZ2HGTJ

Casaria Polyrattan Garden Bench Instruction Manual

Model: B08YZ2HGTJ

1. INTRODUCTION

This manual provides instructions for the assembly, operation, and maintenance of your Casaria Polyrattan 2-Seater Garden Bench. Please read these instructions carefully before assembly and use to ensure safe and correct operation.



Image 1.1: The Casaria Polyrattan Garden Bench in grey, designed for outdoor use.

2. SAFETY INFORMATION

WARNING: Always ensure the bench is assembled correctly and all fasteners are securely tightened to guarantee stability before use.

- Do not exceed the maximum load capacity of **320 kg (705 lbs)**.
- Regularly inspect the bench for any signs of wear or damage. Discontinue use if damage is found.
- For outdoor use, position the bench in an area protected from extreme weather conditions to prolong its lifespan and maintain UV resistance.
- Keep small children and pets away from the assembly area to prevent accidents.

3. PACKAGE CONTENTS

Upon opening the package, verify that all components are present and undamaged:

- 1x Casaria Polyrattan Garden Bench (unassembled)
- 1x Assembly Instructions Manual (this document)
- All necessary hardware for assembly (screws, bolts, tools if included)

If any parts are missing or damaged, please contact customer support before proceeding with assembly.

4. ASSEMBLY INSTRUCTIONS

Assembly is required for this product. Please follow the included assembly instructions carefully. It is recommended to assemble the bench on a soft, clean surface to prevent scratches.

1. Unpack all components and lay them out on a protected surface.
2. Identify all parts according to the assembly diagram in the separate instruction sheet.
3. Attach the legs to the seat frame using the provided hardware. Ensure all connections are finger-tight initially.
4. Attach the backrest to the seat frame and legs.
5. Once all components are in place, gradually tighten all screws and bolts using the appropriate tools. Do not overtighten.
6. Ensure the bench is stable and level. Adjust the feet if necessary (if adjustable feet are present).



Image 4.1: Detail of the bench leg, showing the adjustable foot for leveling.

For detailed step-by-step diagrams, refer to the separate assembly instruction sheet provided in the package.

5. OPERATION AND USAGE

The Casaria Polyrattan Garden Bench is designed for comfortable seating for up to two people in outdoor environments such as balconies, terraces, and gardens.

- Place the bench on a flat, stable surface.
- Ensure the bench is not exposed to direct, prolonged sunlight or extreme weather if possible, to preserve the polyrattan material.
- Avoid standing on the bench or using it for purposes other than seating.

6. MAINTENANCE

Proper maintenance will extend the life and appearance of your garden bench.

- **Cleaning:** Clean the polyrattan and metal frame regularly with a soft, damp cloth. For stubborn dirt, a mild soap solution can be used, followed by rinsing with clean water and drying thoroughly.
- **Protection:** While polyrattan is weather-resistant and UV-resistant, storing the bench indoors or covering it during harsh weather conditions (heavy rain, snow, strong sun) is recommended for optimal longevity.
- **Inspection:** Periodically check all screws and bolts to ensure they remain tight. Retighten if necessary.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the polyrattan and metal finish.



Image 6.1: Cleaning the polyrattan surface with a damp cloth.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Bench is wobbly or unstable.	Loose fasteners; uneven surface.	Ensure all screws and bolts are tightened. Adjust the bench's position or use the adjustable feet to level it on an uneven surface.
Difficulty during assembly.	Incorrect part orientation; fasteners not aligned.	Refer to the detailed assembly instructions. Do not overtighten screws until all parts are loosely fitted. If issues persist, contact customer support.
Polyrattan appears dull or dirty.	Accumulation of dirt and grime.	Clean regularly with a damp cloth and mild soap solution as described in the Maintenance section.

8. PRODUCT SPECIFICATIONS

Model Number:	B08YZ2HGTJ
Brand:	Casaria
Dimensions (W x D x H):	122 cm x 58 cm x 87 cm
Seat Dimensions (W x D):	122 cm x 46 cm
Seat Height:	46 cm
Weight:	Approximately 12.75 kg
Material:	Polyrattan, Aluminum, Metal, Polypropylene
Frame Material:	Metal, Plastic
Color:	Grey
Number of Seats:	2
Maximum Load Capacity:	320 kg
Assembly Required:	Yes
Country of Origin:	Vietnam




Image 8.1: Dimensional diagram of the garden bench.

9. WARRANTY INFORMATION

Specific warranty details are typically provided at the point of purchase or on the manufacturer's official website. Please retain your proof of purchase for any warranty claims.

The product is designed for durability under normal use and proper maintenance. Damage resulting from improper assembly, misuse, neglect, or exposure to extreme conditions beyond its intended use may not be covered under warranty.

10. CUSTOMER SUPPORT

For further assistance, missing parts, or warranty inquiries, please contact Casaria customer support through the retailer where the product was purchased or visit the official Casaria website.

You can find more information about Casaria products and support at: [Casaria Official Store on Amazon](#)

