

[Manuals.plus](#) /

› [Tutti Bambini](#) /

› Tutti Bambini Rio Baby Changing Dresser Station Unit Instruction Manual

Tutti Bambini Rio (B0924XTTJF)

Tutti Bambini Rio Baby Changing Dresser Station Unit

INSTRUCTION MANUAL - MODEL B0924XTTJF

1. Introduction and Product Overview

Thank you for choosing the Tutti Bambini Rio Baby Changing Dresser Station Unit. This solid wood 3-drawer chest with a top changer is designed to provide a safe and convenient space for changing your baby, while also offering ample storage. It is crafted to complement the Rio and Malmo cot beds, ensuring a cohesive nursery aesthetic. Please read this manual thoroughly before assembly and use to ensure safe operation and proper maintenance of your product.



Image 1.1: The Tutti Bambini Rio Baby Changing Dresser Station Unit in White.

2. Safety Information

- The chest top changer is suitable for use with babies up to approximately 15kg. Do not exceed this weight limit.
- Always keep one hand on your baby while they are on the changing top to prevent falls.
- Ensure the dresser is placed on a flat, stable surface.
- Keep all assembly hardware and small parts out of reach of children.
- Regularly check all fittings and connections to ensure they remain secure. Loose fittings can compromise stability.
- This product is compliant with British Standards for Safety and Performance.

3. Components List

Before beginning assembly, please verify that all components listed in the packaging contents are present and undamaged. If any parts are missing or damaged, please contact Tutti Bambini customer support immediately.

Typical components include:

- Dresser panels (top, bottom, sides, back)
- Drawer fronts, sides, and bottoms
- Drawer runners/slides
- Changing top frame
- Handles/knobs
- All necessary screws, dowels, and cam locks

4. Setup and Assembly

Assembly of the Tutti Bambini Rio Chest Changer typically takes approximately 45 minutes with two adults. Detailed step-by-step instructions are included within the product packaging. Please follow these instructions carefully to ensure correct and safe assembly.

1. Unpack all components and lay them out on a clean, soft surface to prevent scratching.
2. Identify each part using the provided diagrams in the assembly guide.
3. Begin by assembling the main dresser frame, ensuring all connections are tight and secure.
4. Install the drawer runners according to the instructions, paying attention to their orientation.
5. Assemble each of the three drawers, ensuring the soft-close mechanisms are correctly aligned.
6. Slide the assembled drawers into the dresser frame.
7. Finally, attach the changing top securely to the dresser.



Image 4.1: Drawer mechanism and storage capacity.

5. Operating Instructions

The Tutti Bambini Rio Chest Changer is designed for ease of use and functionality.

- **Changing Top:** The integrated changing top provides a dedicated and elevated surface for changing your baby. Always use a suitable changing mat (not included) on the top for comfort and hygiene. Ensure your baby is always supervised while on the changing top.
- **Drawers:** The three spacious drawers are equipped with a soft-close mechanism. To open, gently pull the knob. To close, push the drawer in; the soft-close feature will engage to ensure a quiet and smooth closure, preventing accidental finger traps and reducing noise. These drawers are ideal for storing baby essentials such as nappies, wipes, clothing, and blankets.

6. Maintenance and Care

To maintain the appearance and longevity of your Tutti Bambini Rio Chest Changer, follow these care instructions:

- **Cleaning:** Wipe clean with a soft, damp cloth and a mild detergent. Avoid using abrasive cleaners, solvents, or strong chemicals, as these can damage the finish.
- **Spills:** Promptly wipe up any spills to prevent staining or damage to the wood.
- **Environment:** Avoid placing the dresser in direct sunlight or near heat sources, which can cause fading or warping. Maintain a stable room temperature and humidity.
- **Hardware:** Periodically check and tighten all screws and fittings to ensure the dresser remains stable and secure.

7. Troubleshooting

If you encounter any issues with your Tutti Bambini Rio Chest Changer, please refer to the following common solutions:

- **Wobbly or Unstable:** Ensure the dresser is on a level surface. Check all assembly hardware (screws, cam locks) and tighten them securely. If the issue persists, disassemble and reassemble, paying close attention to each connection point.
- **Drawers Not Closing Smoothly:** Verify that the drawer runners are correctly installed and aligned. Check for any obstructions within the drawer slides or debris that might be hindering movement. Ensure the soft-close mechanism is not damaged.
- **Chipped or Damaged Parts:** Inspect all parts upon receipt. If any components are chipped or damaged before assembly, do not proceed with assembly. Contact Tutti Bambini customer support for replacement parts.

8. Specifications

Feature	Detail
Brand	Tutti Bambini
Model	Rio (B0924XTTJF)
Colour	White
Assembled Dimensions (W x D x H)	78.6 cm x 50 cm x 88 cm
Internal Drawer Dimensions (W x D x H)	66 cm x 37 cm x 12 cm
Weight	33.3 kg
Changer Suitability	Up to approximately 15kg
Assembly Time (approx.)	45 minutes (2 adults)



Image 8.1: Product Dimensions.

9. Warranty and Support

Your Tutti Bambini Rio Baby Changing Dresser Station Unit comes with a **3-year warranty**. This warranty covers manufacturing defects under normal use and service.

For warranty claims, technical support, or to purchase replacement parts, please contact Tutti Bambini directly:

- **Website:** tuttibambini.co.uk
- **Facebook:** [@tuttibambiniuk](https://www.facebook.com/tuttibambiniuk)
- **Twitter:** [@tuttibambiniuk](https://twitter.com/tuttibambiniuk)

Please retain your proof of purchase for warranty purposes.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question