

BOGASING M4

BOGASING M4 Bluetooth Speaker Instruction Manual

Brand: BOGASING

Model: M4

1. INTRODUCTION

Welcome to your BOGASING M4 Bluetooth Speaker instruction manual. This guide provides essential information for setting up, operating, and maintaining your portable speaker, ensuring an optimal audio experience. Please read this manual thoroughly before using the product.

2. PACKAGE CONTENTS

Ensure all items are present in the package:

- 1 x BOGASING M4 Bluetooth Speaker
- 1 x 3.5mm Audio Cable
- 1 x USB-C Charging Cable
- 1 x User Manual
- 1 x Lanyard

3. KEY FEATURES

- **Amazing Bass & HD Sound:** 40W powerful stereo sound with deep bass and exceptional clarity.
- **IPX7 Waterproof:** Provides strong waterproof protection, suitable for outdoor and wet environments.
- **Portable & Long Battery Life:** Compact design with a rechargeable Li-ion battery offering up to 24 hours of playtime.
- **Built-in Microphone:** For hands-free speakerphone calls.
- **Excellent Compatibility:** Advanced Bluetooth 5.0 for stable connections up to 100 ft, also supports Micro SD/TF card and 3.5mm AUX.

4. SETUP GUIDE

4.1 Charging the Speaker

Before first use, fully charge the speaker using the provided USB-C charging cable. The charging indicator light will show charging status.



Figure 4.1: USB-C Charging Port

4.2 Initial Bluetooth Pairing

1. Power on the BOGASING M4 speaker by pressing and holding the power button. The Bluetooth indicator light will flash, indicating it's in pairing mode.
2. On your device (smartphone, tablet, etc.), enable Bluetooth and search for