Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Hitachi 22HE4002

Hitachi Smart TV 21.5" Wi-Fi Full HD - 12V User Manual

Model: 22HE4002

Introduction

Welcome to your new Hitachi Smart TV. This manual provides essential information for setting up, operating, and maintaining your 21.5-inch Full HD Smart TV with Wi-Fi connectivity, designed for 12V power systems. Please read this manual thoroughly before using your TV.

Important Safety Information

To ensure safe operation and prevent damage, please observe the following safety precautions:

- Read all instructions before operating the TV.
- Do not expose the TV to rain or moisture to prevent fire or electric shock.
- Ensure proper ventilation. Do not block any ventilation openings.
- Use only the specified 12V power supply for this unit.
- Protect the power cord from being walked on or pinched.
- Refer all servicing to qualified service personnel. Do not attempt to service this product yourself.

Package Contents

Please check that all the following items are included in your package:

- Hitachi Smart TV (21.5")
- Remote Control
- 12V Power Adapter
- TV Stand and Screws
- User Manual (this document)

Setup

Attaching the Stand

Carefully place the TV screen-down on a soft, clean surface to prevent scratches. Align the stand with the mounting

holes on the bottom of the TV. Secure the stand firmly using the provided screws.

Wall Mounting (Optional)

If you choose to wall mount your TV, please consult a professional installer. Ensure you use a VESA-compatible wall mount kit (not included) that supports the TV's weight and size.

Connecting Your TV

Your Hitachi Smart TV offers various connectivity options for external devices and networks.



Image: Rear view of the Hitachi Smart TV, highlighting the available input ports including HDMI, USB, VGA, and RCA connections.

- **HDMI:** Connect Blu-ray players, game consoles, or other HDMI-enabled devices. Your TV has multiple HDMI ports.
- **USB:** Connect USB drives for media playback. Your TV features 1 USB port.
- **VGA:** Connect a computer or laptop using a VGA cable.
- **RCA (Composite):** Connect older audio/video devices using RCA cables.
- **Wi-Fi:** Connect to your wireless home network to access Smart TV features and internet services.
- **Antenna/Cable:** Connect an antenna for over-the-air broadcasts or a cable TV source.

Initial Power-On and First-Time Setup

After connecting the power adapter, press the power button on the TV or the remote control. The TV will guide you through the initial setup process, which typically includes language selection, network connection, and channel scanning.

Operating Your TV



Image: Front view of the Hitachi Smart TV, displaying the screen and the Hitachi logo.

Basic Controls

- **Power:** Press to turn the TV on or off.
- **Volume:** Use the volume buttons on the remote to adjust the sound level.
- **Channel:** Use the channel buttons to navigate through TV channels.
- **Input/Source:** Press this button to select the desired input source (e.g., HDMI 1, USB, VGA, TV).

Smart TV Features

Connect your TV to a Wi-Fi network to unlock its full Smart TV capabilities:

- **Internet Services:** Access popular streaming applications such as Netflix and YouTube directly from your TV.
- **Web Browser:** Browse the internet using the integrated web browser.
- **Media Playback:** Play videos, music, and photos from connected USB storage devices.

Maintenance

Cleaning the Screen

Gently wipe the screen with a soft, lint-free cloth. For stubborn marks, apply a small amount of screen cleaning solution (specifically designed for electronics) to the cloth, then wipe the screen. Never spray liquid directly onto the screen.

General Care

Keep the TV away from direct sunlight, excessive heat, and moisture. Ensure there is adequate space around the TV for proper ventilation to prevent overheating.

Troubleshooting

If you encounter issues with your TV, refer to the table below for common problems and their solutions:

Problem	Possible Cause	Solution
No Power	Power cable not connected; No power from outlet.	Check all power connections; Try plugging into a different electrical outlet.
No Picture, but Sound	Incorrect input source selected; Loose video cable.	Press the 'Input' or 'Source' button on the remote to select the correct source; Check video cable connections.
No Sound, but Picture	Volume too low or muted; Audio cable loose.	Increase volume or unmute the TV; Check audio cable connections.
Wi-Fi Connection Issues	Incorrect Wi-Fi password; Router too far or off.	Re-enter the Wi-Fi password carefully; Move the TV closer to the router or restart your router.
Remote Control Not Working	Batteries dead or incorrectly inserted.	Replace batteries with new ones; Ensure correct polarity (+/-).

Specifications

Feature	Detail
Brand	Hitachi
Model Name	22HE4002
Screen Size	21.5 Inches
Resolution	1080p (Full HD)
Connectivity Technology	VGA, Wi-Fi, USB, HDMI
Special Feature	Internet (Smart TV)
Supported Internet Services	Netflix, YouTube
Aspect Ratio	1.77:1
Number of USB Ports	1
Item Weight	4 Kilograms
Model Year	2018

Warranty and Support

For detailed warranty information, please refer to the warranty card included with your product or visit the official Hitachi website. Keep your purchase receipt as proof of purchase for any warranty claims.

For technical support or further assistance, please contact Hitachi customer service through their official channels.

Visit Hitachi Official Website

© 2024 Hitachi. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0926YRY4Z

More documents and user manuals: **https://manuals.plus/**