Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

NOQIZ NO-IOCK01

NOQIZ Keyless Entry Door Lock with Deadbolt Instruction Manual

Model: NO-IOCK01

Introduction

This manual provides comprehensive instructions for the installation, operation, and maintenance of your NOQIZ Keyless Entry Door Lock with Deadbolt. Please read this manual thoroughly before installation and use to ensure proper function and safety.

Components List

Before beginning installation, verify that all components are present and in good condition. Refer to the image below for a visual representation of the included parts.



Image: All components of the NOQIZ Keyless Entry Door Lock, including the exterior keypad assembly, interior battery assembly, latch, strike plate, screws, and physical keys.

- Exterior Keypad Assembly
- Interior Battery Assembly
- Deadbolt Latch
- Strike Plate
- Mounting Plate
- Screws (various sizes for different parts)
- Physical Keys (2 supplied)
- Installation Template

Installation Instructions

Follow these steps carefully for proper installation. A video guide is also provided for visual assistance.

[redacted]

Video: Official installation instructions for the NOQIZ Electronic Keypad Deadbolt Lock. This video demonstrates each step of the physical installation process.

Step 1: Install the Latch and Strike

Insert the deadbolt latch into the door edge. Ensure the latch bolt is oriented correctly for your door's swing. Secure it with the provided screws. Install the strike plate on the door frame, aligning it with the latch bolt.




Image: Visual guide showing the installation of the latch and strike plate into the door and door frame.

Step 2: Install the Exterior Assembly

Route the cable from the exterior keypad assembly through the door below the latch bolt. Ensure the key cylinder is in the correct vertical position. Carefully align the exterior assembly with the latch and door holes, then push it into place.

Step 3: Install the Mounting Plate

Take off the mounting plate from the interior assembly. Route the cable through the bottom of the mounting plate. Secure the mounting plate to the door using the provided screws, ensuring it is flush and stable. Tighten screws evenly.

Step 4: Connect the Cable and Install Interior Assembly

Connect the cable from the exterior assembly to the port on the interior assembly. Ensure a tight connection. Carefully align the interior assembly with the mounting plate and secure it with the remaining screws. Ensure the thumb turn is vertical.

Step 5: Install Batteries and Perform Door Handing Process

Install 4 AA batteries (not included) into the battery pack of the interior assembly. Close the battery cover. Perform the door handing process:

1. Press the "Lock" button (or equivalent) on the keypad. The latch bolt should extend by itself.
2. Enter the preset code (e.g., 123456) followed by the "Lock" button. The latch bolt should retract by itself.

If the latch bolt does not extend or retract smoothly, check the latch and re-install the lock.

Operating Instructions

Your NOQIZ Keyless Entry Door Lock offers convenient and secure access. It supports both keypad entry and traditional physical keys.



Image: The NOQIZ door lock provides two locking options: keypad entry and physical keys.

Setting User Codes

Refer to the detailed programming instructions included in your package for setting and managing user codes. Typically, this involves entering a master code followed by a sequence to add or delete user-specific access codes.

Auto-Lock Function

The lock features an auto-lock function that automatically locks the door after a set period (e.g., 5 seconds) once it's closed. This feature can usually be enabled or disabled, and the delay time adjusted, through the lock's programming settings. Consult your programming guide for specific steps.



Image: Icons illustrating key features including easy installation, two ways of entry (code/key), and convenient auto-lock function.

Alarm Function

The lock is equipped with an alarm feature designed to enhance security. This alarm may activate under certain conditions, such as multiple incorrect code entries or forced entry attempts. Refer to the programming guide for details on alarm triggers and how to manage them.



Image: Icons illustrating additional features such as fitting standard-sized doors, an alarm for safety, and a smart reminder function.

Maintenance

Regular maintenance ensures the longevity and optimal performance of your lock.

- **Cleaning:** Wipe the keypad and lock body with a soft, dry cloth. Avoid abrasive cleaners or solvents that could damage the finish or electronic components.
- **Battery Replacement:** The lock requires 4 AA batteries. Replace all batteries when the low battery indicator activates or if the lock's response becomes sluggish. Do not use rechargeable batteries.
- **Lubrication:** Periodically lubricate the latch bolt mechanism with a silicone-based lubricant to ensure smooth operation. Do not lubricate the key cylinder.

Troubleshooting

If you encounter issues with your NOQIZ Keyless Entry Door Lock, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Lock does not respond to keypad entry.	Low batteries; incorrect code entered; keypad malfunction.	Replace batteries; ensure correct code is entered; use physical key if necessary and contact support.
Latch bolt does not extend/retract smoothly.	Misalignment during installation; obstruction in door frame; worn latch mechanism.	Check alignment of lock and strike plate; clear any obstructions; lubricate latch bolt; re-install if necessary.
Auto-lock not functioning.	Feature disabled; incorrect programming; door not fully closed.	Verify auto-lock setting in programming; ensure door closes completely; re-program if needed.
Lock beeps continuously.	Low battery warning; alarm triggered.	Replace batteries immediately; check programming for alarm settings and clear any active alarms.

For issues not listed here or if solutions do not resolve the problem, please contact customer support.

Specifications

- **Brand:** NOQIZ
- **Model:** NO-lOCK01
- **Special Features:** Alarm, Auto Lock, Keyless
- **Lock Type:** Keypad
- **Material:** Metal
- **Recommended Uses:** Home, Office
- **Style:** Modern
- **Color:** Silver
- **Number of Pieces:** 1 (main unit)
- **Included Components:** Mounting hardware
- **Controller Type:** Hand Control, Mechanical knob
- **Item Weight:** 1 pound (approximately)
- **Control Method:** Touch
- **Connectivity Protocol:** Wi-Fi
- **UPC:** 799953791553
- **Manufacturer:** NOQIZ
- **Package Dimensions:** 7.52 x 5.79 x 4.49 inches
- **Date First Available:** May 11, 2022

Warranty and Support

NOQIZ products are designed for durability and reliability. For information regarding warranty coverage, technical support, or service, please refer to the contact details provided with your product packaging or visit the official NOQIZ website. For immediate assistance, you may also contact customer support via email:service@noqizlock.com.

© 2023 NOQIZ. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How do I remove or disable the sound and alarm on the NOQIZ NO-lOCK01 Keyless Entry Door Lock?

To manage the sound and alarm settings on your NOQIZ NO-lOCK01, please follow these guidelines based on the manual: Continuous Beeping: If the lock is beeping continuously, it is likely a Low Battery Warning...

Read full answer

Can you send me the manual for the NOQIZ M22 model lock?

The manual for the NOQIZ Keyless Entry Door Lock (Model NO-lOCK01), which is often associated with the M22 series, is available directly on this page. You can view the full instructions for installation, programming,...

Read full answer

Open the live page

https://manuals.plus/asin/B0928BZ4PM

More documents and user manuals: **https://manuals.plus/**