

[Manuals.plus](#) /

› [Gocheer](#) /

› Gocheer H1 Dehumidifier User Manual

Gocheer H1

Gocheer H1 Dehumidifier User Manual

Model: H1 | Brand: Gocheer

1. INTRODUCTION

Thank you for choosing the Gocheer H1 Dehumidifier. This compact and efficient dehumidifier is designed to remove excess moisture from your indoor environment, creating a more comfortable and healthier living space. It is ideal for use in basements, bedrooms, bathrooms, closets, RVs, and other small to medium-sized areas prone to high humidity. Please read this manual thoroughly before operating the unit to ensure proper use, optimal performance, and safety.



The Gocheer H1 Dehumidifier effectively reduces humidity for a more comfortable environment.

2. SAFETY INSTRUCTIONS

To prevent injury to the user or others and property damage, the following instructions must be followed. Incorrect operation due to ignoring instructions may cause harm or damage.

- Do not operate the unit with a damaged cord or plug.
- Do not place the unit near heat sources or in direct sunlight.
- Ensure the unit is placed on a stable, level surface to prevent water spillage.
- Do not block the air inlet or outlet. Maintain at least 20cm clearance around the unit.
- Always unplug the dehumidifier before cleaning or performing any maintenance.
- Keep out of reach of children and pets.
- Do not immerse the unit, power cord, or plug in water or other liquids.

3. PRODUCT COMPONENTS AND DIMENSIONS

Familiarize yourself with the main components of your Gocheer H1 Dehumidifier.



Front view of the Gocheer H1 Dehumidifier, showing the main unit and transparent water tank.



The compact dimensions of the Gocheer H1 Dehumidifier: 13.58 inches (H) x 9.84 inches (W) x 7.09 inches (D).

Key Components:

- **Main Unit:** Houses the internal components and control panel.
- **Water Tank:** Removable 4000ml (128oz) capacity tank for collected water.
- **Air Inlet/Outlet:** Vents for air circulation.
- **Control Panel:** Buttons and indicators for operation.
- **Power Cord:** For connecting to an electrical outlet.

4. SETUP

1. **Unpack the Unit:** Carefully remove the dehumidifier and all packaging materials from the box.
2. **Choose a Location:** Place the dehumidifier on a firm, level surface in the area where you wish to reduce humidity. Ensure there is at least 20cm (8 inches) of space around the unit for proper airflow. Avoid placing it directly against walls or furniture.
3. **Power Connection:** Plug the power cord into a suitable electrical outlet. Ensure the voltage matches the unit's requirements.
4. **Water Tank Installation:** Ensure the water tank is correctly inserted into the unit. The unit will not operate if the tank is not properly seated or is full.




Proper placement and airflow are crucial for the dehumidifier's efficiency in maintaining optimal humidity levels.

5. OPERATING INSTRUCTIONS

Power On/Off:

- Press the Power button on the control panel to turn the unit ON or OFF.



Why 50%?

According to research, the best environmental humidity is 50%, we will feel uncomfortable when humidity is too high or too low.

RV Bedroom Kids Room Bathroom Wardrobe

The dehumidifier offers both quiet and powerful operating modes for various needs.

Timer Setting:

- Press the Timer button to set the desired operating duration (e.g., 12H, 24H, 36H, 48H, 60H). The unit will automatically shut off after the set time.



Timer Setting

12H 24H 36H 48H 60H

Easily set the operating time using the timer function for convenience.

Automatic Shut-Off:

- The dehumidifier is equipped with an automatic shut-off feature. When the water tank is full, the unit will stop operating, and an indicator light will illuminate.
- Empty the water tank and reinsert it properly to resume operation.



The automatic shut-off feature prevents overflow when the water tank is full.

Water Tank Handling:

- Gently pull out the water tank from the front of the unit.
- Empty the collected water.
- Slide the empty tank back into the unit until it clicks into place.



The 4000ml water tank is easily removable for emptying.

6. MAINTENANCE

Regular maintenance ensures the longevity and efficiency of your dehumidifier.

Cleaning the Water Tank:

- Empty the water tank regularly.
- Clean the tank with mild detergent and warm water every few weeks to prevent mold and mildew growth. Rinse thoroughly and dry before reinserting.

Cleaning the Exterior:

- Wipe the exterior of the unit with a soft, damp cloth. Do not use abrasive cleaners or solvents.

Air Filter Cleaning:

- The dehumidifier features a removable air filter located at the back of the unit.
- Gently pull out the filter.

- Clean the filter with a vacuum cleaner or wash it with warm, soapy water. Ensure it is completely dry before reinserting.
- Clean the filter every 2-4 weeks, or more frequently if the unit is used in a dusty environment.



The unit's design includes a convenient storage compartment for the power cable, aiding in portability and neatness.

7. TROUBLESHOOTING

Before contacting customer support, please refer to the following table for common issues and their solutions.

Problem	Possible Cause	Solution
Unit does not turn on.	No power supply; Water tank full or not properly inserted.	Check power connection; Empty and reinsert water tank correctly.
Dehumidifying effect is poor.	Room temperature too low; Air filter clogged; Air inlet/outlet blocked; Room size too large.	Ensure room temperature is above 41°F (5°C); Clean air filter; Clear obstructions; Use in recommended room size (up to 510 sq.ft).
Unit is noisy.	Unit not on a level surface; Fan obstruction.	Place on a flat, stable surface; Check for any foreign objects near the fan.
Water leaks from the unit.	Water tank not properly inserted; Unit tilted.	Reinsert water tank firmly; Ensure unit is upright and level.

8. SPECIFICATIONS

Feature	Detail
Brand	Gocheer
Model Name	H1
Capacity	4000 Milliliters (128oz)
Dehumidification Capacity	1 Liters per Day

Feature	Detail
Floor Area Coverage	Up to 510 Sq.ft (5300 Cubic Feet)
Product Dimensions	7.09"D x 9.84"W x 13.58"H
Item Weight	2.1 Pounds
Operation Mode	Continuous
Color	White
Included Components	User Manual, Dehumidifier
UPC	754449021385

9. WARRANTY AND SUPPORT

Gocheer provides a limited warranty for this product. For detailed warranty information, product support, or to inquire about replacement parts, please refer to the warranty card included with your purchase or visit the official Gocheer website. You may also contact Gocheer customer service directly for assistance.

Gocheer Official Store: [Visit Gocheer Store on Amazon](#)