

[Manuals.plus](#) /

› [Armitron](#) /

› Armitron 20/5313 Men's Multifunction Two-Tone Bracelet Watch User Manual

Armitron 20/5313BKTT

Armitron 20/5313 Men's Multifunction Two-Tone Bracelet Watch

Model: 20/5313BKTT

INTRODUCTION

Thank you for choosing the Armitron 20/5313 Multifunction Watch. This timepiece combines classic design with practical features, including day, date, and 24-hour sub-dials, all powered by a reliable Japanese quartz movement. Designed for durability, it features a scratch-resistant mineral crystal and is water-resistant up to 50 meters. This manual provides essential information for setting up, operating, and maintaining your watch.



Image: Front view of the Armitron 20/5313 men's multifunction watch, showcasing its two-tone stainless steel bracelet, black dial, and gold-

tone accents on the sub-dials and hands.

KEY FEATURES

- **Tachymeter Bezel:** A fixed bezel with a tachymeter scale for measuring speed based on travel time over a known distance.
- **Multifunction Dial:** Black dial featuring dedicated sub-dials for day of the week, date, and 24-hour time display.
- **Luminous Hands and Markers:** Gold-tone luminous hands and hour markers ensure readability in low-light conditions.
- **Two-Tone Adjustable Bracelet:** Durable two-tone stainless steel link bracelet with a fold-over clasp and safety for a secure and comfortable fit.
- **Water Resistance:** Rated water-resistant up to 50 meters (165 feet), suitable for short periods of recreational swimming.
- **Mineral Crystal:** Equipped with a scratch-resistant mineral crystal to protect the dial.

SETUP

Setting the Time and Date

1. **Pull out the Crown:** Gently pull the crown (the knob on the side of the watch) out to position 2 (first click) or position 3 (second click), depending on the function you wish to adjust.
2. **Setting the Time:** Pull the crown out to position 3. Rotate the crown clockwise or counter-clockwise to move the hour and minute hands to the correct time. Ensure to account for AM/PM if your watch has a 24-hour indicator or date change. Push the crown back in to position 1 to start the watch.
3. **Setting the Date:** Pull the crown out to position 2. Rotate the crown to adjust the date sub-dial. If the date changes at noon, you are in the PM cycle. Adjust accordingly.
4. **Setting the Day:** The day sub-dial is typically linked to the time setting. As you advance the time past midnight, the day will change. Adjust the time until the correct day is displayed.
5. **Setting the 24-Hour Sub-dial:** This sub-dial usually synchronizes with the main hour hand and cannot be set independently. It indicates whether the main time is AM or PM.

Adjusting the Bracelet

The two-tone bracelet is adjustable. For proper fit, it may require the removal or addition of links. It is recommended to have this adjustment performed by a professional jeweler to prevent damage to the watch or bracelet.



Image: The Armitron 20/5313 watch displayed on a person's wrist, illustrating its size and fit.

OPERATING

Reading the Time and Sub-dials

- The main hour, minute, and second hands indicate the current time.
- The sub-dial at the 12 o'clock position displays the day of the week.
- The sub-dial at the 6 o'clock position displays the date.
- The sub-dial at the 9 o'clock position displays the 24-hour time, synchronizing with the main hour hand.

Water Resistance

Your Armitron 20/5313 watch is water-resistant to 50 meters (165 feet). This rating means it can withstand splashes, rain, and brief immersion in water, such as during recreational swimming. It is **not** suitable for diving, snorkeling, or prolonged water activities. Always ensure the crown is fully pushed in before any contact with water.

WATER RESISTANT CHART	
 NOT WATER RESISTANT	NOT WATER RESISTANT
 ACCIDENTAL SPLASHES	WATER RESISTANT TO 30M (100FT): In general, withstands splashes or brief immersion in water, but not suitable for swimming or bathing
 SWIMMING	WATER RESISTANT TO 50M (165FT): In general, suitable for short periods of recreational swimming, but not diving or snorkeling
 SNORKELING	WATER RESISTANT TO 100 M (330 FT): In general, suitable for swimming and snorkeling, but not scuba diving

Image: A chart detailing different levels of watch water resistance, indicating that 50M (165FT) is suitable for swimming but not diving or snorkeling.

MAINTENANCE

Cleaning

To maintain the appearance of your watch, wipe it regularly with a soft, dry cloth. For the bracelet, a slightly damp cloth can be used, followed by a dry one. Avoid using harsh chemicals or abrasive materials, as these can damage the finish.

Battery Replacement

The watch is powered by a standard watch battery. When the watch stops running, it indicates the battery needs replacement. It is highly recommended to have the battery replaced by a qualified watchmaker or service center to ensure the watch's water resistance is maintained and to prevent damage to the internal components.

Care for Water Resistance

- Do not operate the crown or pushers when the watch is wet or submerged in water.

- Avoid exposing the watch to extreme temperature changes, as this can affect the seals.
- Have the water resistance seals checked periodically, especially after battery replacement, to ensure continued protection.

TROUBLESHOOTING

Watch Not Running

- **Check the Crown:** Ensure the crown is fully pushed in to position 1. If it's pulled out, the watch will not run.
- **Battery:** The battery may be depleted. Refer to the 'Battery Replacement' section for guidance.

Incorrect Time/Date Display

- **Resetting:** Follow the 'Setting the Time and Date' instructions in the Setup section to reset the time and date.
- **Day/Date Cycle:** Ensure you have set the time correctly for AM/PM, as this affects the day and date change.

Condensation Under Crystal

- If condensation appears under the crystal, it indicates a breach in the water resistance. Seek professional service immediately to prevent internal damage.

SPECIFICATIONS

Feature	Detail
Model Number	20/5313BKTT
Movement	Japanese Quartz
Crystal Material	Mineral Crystal
Case Material	Stainless Steel
Band Material	Stainless Steel
Water Resistance	50 Meters (165 Feet)
Item Weight	175.77 grams
Battery	1 Non-standard Battery (included)
Country of Origin	China

WARRANTY AND SUPPORT

Specific warranty details for your Armitron 20/5313 watch are typically provided with the original packaging or can be found on the official Armitron website. Please refer to these resources for comprehensive information regarding warranty coverage, terms, and conditions.

For technical support, service, or inquiries not covered in this manual, please contact Armitron customer service through their official website or the contact information provided with your purchase. Always ensure to provide your model number (20/5313BKTT) when seeking support.



Image: The gray Armitron watch box, where additional product information and warranty details may be found.

© 2023 Armitron. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question