

HK48-WW

Adjustable LED Touch Screen Makeup Mirror

Model: HK48-WW (Also known as XR-1608-)

Brand: Generic

PRODUCT OVERVIEW

The Generic Adjustable LED Touch Screen Makeup Mirror is a portable and versatile accessory designed to provide optimal lighting for makeup application. It features long-lasting LED bulbs that distribute light evenly, ensuring a clear and bright reflection. The mirror is equipped with a smart touch switch for easy operation and brightness adjustment, and it offers 360-degree rotation for flexible viewing angles. A convenient storage tray is integrated into the base for small accessories.



Image: The Adjustable LED Touch Screen Makeup Mirror, white in color, featuring a rectangular mirror surface surrounded by bright LED lights. The mirror is mounted on an adjustable stand with a circular base that includes a small storage tray.

SETUP

1. **Unpack:** Carefully remove all components from the packaging.
2. **Battery Installation:** Locate the battery compartment on the back of the mirror. Insert 4 x AA batteries

(not included), ensuring correct polarity (+/-).

3. **Placement:** Place the mirror on a stable, flat surface such as a tabletop or vanity.

OPERATING INSTRUCTIONS

- **Power On/Off:** Locate the ON/OFF switch on the back of the mirror. Flip the switch to the "ON" position to activate the power.
- **LED Light Control:** Once the power is on, touch the smart touch switch located on the mirror surface to turn the LED lights on or off.
- **Adjusting Brightness:** To adjust the brightness of the LED lights, press and hold the smart touch switch. The brightness will cycle through different levels. Release your finger when the desired brightness is achieved.
- **Mirror Rotation:** The mirror can be rotated approximately 360 degrees vertically. Gently tilt the mirror to your preferred viewing angle.
- **Storage Tray:** Use the integrated tray at the base of the mirror to store small makeup items or accessories.

MAINTENANCE

- **Cleaning:** To clean the mirror surface and frame, use a soft, dry, lint-free cloth. For stubborn spots, dampen the cloth slightly with water or a mild glass cleaner, then wipe dry immediately. Avoid abrasive cleaners or solvents.
- **Battery Replacement:** When the LED lights dim or stop working, it's time to replace the batteries. Turn off the mirror, open the battery compartment, remove the old batteries, and insert new 4 x AA batteries, observing correct polarity.
- **Storage:** When not in use for extended periods, store the mirror in a cool, dry place and consider removing the batteries to prevent leakage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
LED lights do not turn on.	<ul style="list-style-type: none">• Power switch is off.• Batteries are dead or incorrectly installed.	<ul style="list-style-type: none">• Ensure the ON/OFF switch on the back is in the "ON" position.• Check battery polarity and replace with new 4 x AA batteries if necessary.
LED lights are dim.	<ul style="list-style-type: none">• Low battery power.• Brightness setting is low.	<ul style="list-style-type: none">• Replace batteries with new ones.• Press and hold the touch switch to increase brightness.
Touch switch is unresponsive.	<ul style="list-style-type: none">• Power switch is off.• Mirror surface is dirty.	<ul style="list-style-type: none">• Ensure the ON/OFF switch on the back is in the "ON" position.• Clean the mirror surface, especially around the touch switch area.

SPECIFICATIONS

- **Model:** HK48-WW (XR-1608-)

- **Brand:** Generic
- **Dimensions:** Approximately 27 x 17 x 0.03 cm (Mirror size: 22x16cm)
- **Weight:** Approximately 520 g
- **LED Quantity:** 22 LEDs (some models may have 16 LEDs)
- **Power Source:** 4 x AA Batteries (not included)
- **Features:** Adjustable tilt, 360-degree rotation, Smart Touch Switch, Storage Tray
- **Color:** White

WARRANTY AND SUPPORT

Specific warranty information for this product is not provided in the available details. For any warranty claims, technical support, or service inquiries, please contact the retailer or the manufacturer directly with your purchase details.

It is recommended to retain your proof of purchase for any potential support needs.