

[Manuals.plus](#) /

› [KUTCHINA](#) /

› Kutchina Marica HB 4B ECO BRS 60 Hob Gas Stove User Manual

KUTCHINA Marica HB 4B ECO BRS 60

Kutchina Marica HB 4B ECO BRS 60 Hob Gas Stove

User Manual

1. INTRODUCTION

Thank you for choosing the Kutchina Marica HB 4B ECO BRS 60 Hob Gas Stove. This manual provides essential information for the safe and efficient installation, operation, and maintenance of your new appliance. Please read these instructions thoroughly before using the hob and retain them for future reference.

2. SAFETY INFORMATION

Always prioritize safety when operating gas appliances. Failure to follow these instructions could result in fire, explosion, electric shock, or other injuries.

- Ensure proper ventilation in the kitchen area during use.
- Do not store flammable materials near the hob.
- Keep children and pets away from the appliance during operation.
- Do not use the hob for space heating.
- If you smell gas, immediately turn off the gas supply, open windows, and do not operate any electrical switches. Contact a qualified technician.
- Only use the type of gas for which the appliance is designed.
- Ensure all burners are turned off after cooking.

3. PRODUCT OVERVIEW

The Kutchina Marica HB 4B ECO BRS 60 is a 4-burner hob gas stove designed for efficient and convenient cooking. It features a sleek glass top, auto-ignition, and sturdy cast iron pan supports.



Overall view of the Kutchina Marica HB 4B ECO BRS 60 Hob Gas Stove with four burners and control knobs.



Close-up of a durable brass burner, designed for efficient heat distribution.



Detail of a smooth metallic control knob for precise flame adjustment.



Sturdy cast iron pan support providing stable and even support for various cookware.



The 8mm thick tempered glass top, offering durability and an elegant finish.



A burner with an active flame, demonstrating the auto-ignition feature.

4. SETUP AND INSTALLATION

Installation of this gas hob should only be performed by a qualified and authorized technician to ensure safety and proper functioning.

4.1 Unpacking

- Carefully remove the hob from its packaging.
- Check for any damage during transit. Report any damage to your supplier immediately.
- Ensure all components listed in the package details are present.

4.2 Countertop Preparation

- The hob dimensions are approximately 78 cm (length) x 52 cm (width) x 13 cm (height).
- The ideal countertop cut-out size for this 4-burner gas stove is **69 cm x 40.5 cm**.
- Ensure adequate clearance around the hob for ventilation and safety.

4.3 Gas Connection

- Connect the hob to the gas supply using appropriate fittings and flexible hose, ensuring all connections are leak-free.
- Verify the gas type matches the appliance's specifications.

4.4 Battery Installation for Auto Ignition

- The auto-ignition system requires a 1.5V battery.
- Locate the battery compartment (usually underneath the hob or near the control panel) and insert the battery, observing polarity.

5. OPERATING INSTRUCTIONS

5.1 Lighting a Burner

1. Place your cookware centrally on the pan support over the desired burner.
2. Push down and turn the corresponding control knob counter-clockwise to the maximum flame position.
3. The auto-ignition will spark, lighting the burner. Hold the knob down for a few seconds after ignition to allow the thermocouple to heat up and activate the flame failure device (if present).
4. Once lit, adjust the flame to your desired intensity by turning the knob between the maximum and minimum flame settings.

5.2 Turning Off a Burner

- Turn the control knob clockwise until it clicks into the "OFF" position.
- Ensure the flame is completely extinguished.

5.3 Burner Power Specifications

- Two 70 mm burners: 1.75 Kw each
- One 100 mm burner: 2.5 Kw
- One 130 mm burner: 3.3 Kw

6. MAINTENANCE AND CLEANING

Regular cleaning and maintenance will prolong the life of your hob and ensure safe operation.

6.1 General Cleaning

- Always ensure the hob is cool before cleaning.
- Use a soft cloth and mild detergent for the glass top and metallic surfaces. Avoid abrasive cleaners or scouring pads.
- The scratch-proof drip tray can be removed for easy cleaning of spills and splatters.

6.2 Burner and Pan Support Cleaning

- Remove the cast iron pan supports and brass burner caps/crowns.
- Wash them with warm soapy water. For stubborn stains, a non-abrasive scrub brush can be used.
- Ensure all parts are completely dry before reassembling them. Moisture can affect ignition.
- Periodically check burner ports for blockages and clean with a fine wire or needle if necessary.

7. TROUBLESHOOTING

Before contacting customer service, please refer to the following troubleshooting guide:

Problem	Possible Cause	Solution
Burner does not ignite.	◦ No gas supply. ◦ Ignition battery is dead or incorrectly installed. ◦ Burner parts are wet or clogged. ◦ Ignition electrode is dirty or damaged.	◦ Check gas cylinder/supply valve. ◦ Replace 1.5V battery; ensure correct polarity. ◦ Clean and dry burner caps and crowns. ◦ Clean the ignition electrode with a dry cloth.

Problem	Possible Cause	Solution
Flame is irregular or yellow.	◦ Burner ports are clogged. ◦ Incorrect gas pressure.	◦ Clean burner ports. ◦ Contact a qualified technician to check gas pressure.
Gas smell detected.	◦ Gas leak.	◦ Immediately turn off gas supply. Open windows. Do not operate electrical switches. Contact a qualified technician.

8. SPECIFICATIONS

Brand	KUTCHINA
Model	Marica HB 4B ECO BRS 60
Heating Elements	4 Burners
Colour	Black
Power Source	Gas Powered
Fuel Type	Gas
Ignition System Type	Battery (1.5V)
Control Type	Knob
Installation Type	Built-In
Product Dimensions	78 cm x 52 cm x 13 cm (approx.)
Countertop Cut-out Size	69 cm x 40.5 cm (ideal)

9. WARRANTY AND CUSTOMER SUPPORT

Your Kutchina Marica HB 4B ECO BRS 60 Hob Gas Stove comes with the following warranty:

- **1 year warranty** on the product.
- **5 years warranty** on the tempered glass.

Important Note: The warranty is applicable only on functionality. There is no warranty claim for burner discoloration, deformation, denting, chipping, or peeling of enameled black coating.

For any assistance, service requests, or queries, please contact Kutchina customer service:

Customer Service Helpline: [18004197333](tel:18004197333)

