

Cecotec 05926

Cecotec EnergySilence 9800 Skyline Bladeless Tower Fan User Manual

Model: 05926

1. IMPORTANT SAFETY INSTRUCTIONS

Read all instructions carefully before using the appliance. Keep this manual for future reference.

- Ensure the voltage indicated on the appliance corresponds to your mains voltage.
- Do not immerse the appliance, power cord, or plug in water or any other liquid.
- Unplug the fan from the power outlet when not in use, before cleaning, or before moving it.
- Do not operate the fan with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Keep hands, hair, clothing, and other objects away from the fan's openings during operation to prevent injury.
- This appliance is for household use only. Do not use outdoors.
- Do not allow children to play with the appliance. Close supervision is necessary when the appliance is used near children.
- Place the fan on a stable, flat surface to prevent it from tipping over.
- Do not block air openings.

2. PRODUCT OVERVIEW

The Cecotec EnergySilence 9800 Skyline is a bladeless tower fan designed to provide efficient air circulation with a minimalist aesthetic.

2.1 Components

- **Main Unit:** The primary body of the fan, housing the motor and air outlet.
- **Base:** Provides stability for the fan.
- **Control Panel:** Located on the main unit for manual operation.
- **Remote Control:** For convenient operation from a distance.
- **Power Cord:** Connects the fan to an electrical outlet.




Image 2.1: Front view of the Cecotec EnergySilence 9800 Skyline Bladeless Tower Fan. This image shows the tall, slender design of the fan with its conical base and the main air outlet column.

3. SETUP

Follow these steps to set up your tower fan.

1. **Unpacking:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Base Assembly:** Attach the base to the main unit. Ensure it is securely fastened according to the instructions provided in the full product manual (not included here).
3. **Placement:** Place the fan on a firm, level surface. Ensure there is adequate space around the fan for optimal air circulation and oscillation.

4. **Power Connection:** Plug the power cord into a standard electrical outlet.



Image 3.1: The tower fan positioned in a living room setting, demonstrating its compact footprint and integration into home decor.

4. OPERATING INSTRUCTIONS

Your Cecotec EnergySilence 9800 Skyline fan can be operated using the control panel on the unit or the included remote control.

4.1 Control Panel



Image 4.1: A close-up view of the fan's control panel, highlighting the power button and the digital display indicating the current speed setting.

- **Power Button:** Press to turn the fan ON or OFF.
- **Speed Adjustment:** Press the speed button to cycle through 9 available speeds. The current speed will be displayed on the digital screen.
- **Oscillation Button:** Activates or deactivates the oscillation function, allowing the fan to rotate horizontally.
- **Timer Button:** Sets the automatic shut-off timer (up to 8 hours).

4.2 Remote Control

The remote control provides access to all functions of the fan.



Image 4.2: A user operating the tower fan with the remote control from a sofa, illustrating the convenience of remote operation.

- **Power:** Turns the fan ON/OFF.
- **Speed (+/-):** Increases or decreases the fan speed (9 levels).
- **Oscillation:** Toggles the oscillation function.
- **Timer:** Sets the timer for automatic shut-off.

4.3 Features

- **AirBladeless Technology:** Generates a powerful airflow without visible blades, ensuring safety and quiet operation.
- **9 Speeds:** Allows for precise control over airflow intensity.
- **Oscillation Mode:** Distributes air across a wider area for enhanced cooling.



Image 4.3: An aerial view illustrating the fan's oscillation capability, with arrows indicating the range of movement.

- **Timer Function:** Set for up to 8 hours for automatic shutdown.
- **Copper Motor:** Durable and efficient motor for reliable performance.



Image 4.4: A detailed view of the internal copper motor components, highlighting the quality of construction.

5. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your fan.

1. Cleaning:

- Always unplug the fan before cleaning.
- Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Use a soft brush or vacuum cleaner with a brush attachment to remove dust from the air intake and outlet openings.
- Ensure no water enters the internal components.

2. **Storage:** When not in use for extended periods, store the fan in its original packaging in a cool, dry place.

6. TROUBLESHOOTING

Refer to this section for common issues and their solutions.

Problem	Possible Cause	Solution
Fan does not turn on.	Not plugged in; power outlet not working; power button not pressed.	Ensure the fan is securely plugged into a working outlet. Press the power button.
Weak airflow.	Low speed setting; air intake/outlet blocked; dust accumulation.	Increase speed setting. Check for obstructions. Clean air intake/outlet.
Fan is noisy.	Unstable surface; internal obstruction; high speed setting.	Place on a stable surface. Check for foreign objects. Reduce speed.
Remote control not working.	Batteries depleted; obstruction between remote and fan; remote not aimed correctly.	Replace batteries. Ensure clear line of sight. Aim remote directly at the fan's receiver.

7. SPECIFICATIONS







- Brand:** Cecotec
- Model Number:** 05926
- Product Dimensions:** 101.5 x 25.5 x 26 cm (Height x Width x Depth)
- Weight:** 2.57 kg
- Power:** 26 Watts
- Voltage:** 220 Volts (AC)
- Color:** White
- Special Features:** Bladeless design, 9 speeds, Oscillation, Timer (up to 8 hours), Remote control, Copper motor.

8. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the warranty card included with your product or visit the official Cecotec website. Keep your proof of purchase for any warranty claims.

Cecotec Official Website: www.cecotec.com



	<p>Manual de Instrucciones Cecotec ENERGYSILENCE AERO 5270 - Ventilador de Techo con Motor DC</p> <p>Manual de instrucciones completo para los ventiladores de techo Cecotec ENERGYSILENCE AERO 5270, incluyendo guías de seguridad, montaje, funcionamiento, limpieza, mantenimiento y especificaciones técnicas.</p>
	<p>Cecotec EnergySilence 4800 Light: Manual de Instrucciones y Seguridad</p> <p>Manual de instrucciones y seguridad para el ventilador de techo Cecotec EnergySilence 4800 Light. Descubra cómo instalar, operar y mantener su ventilador de forma segura y eficiente.</p>
	<p>Cecotec Energysilence Aero 360/365 Ceiling Fan - Instruction Manual</p> <p>Comprehensive instruction manual for the Cecotec Energysilence Aero 360 and 365 series ceiling fans. Includes assembly, operation, maintenance, troubleshooting, and technical specifications.</p>
	<p>Cecotec EnergySilence 9090 Skyline Smart Light User Manual</p> <p>Comprehensive user manual for the Cecotec EnergySilence 9090 Skyline Smart Light tower fan, covering safety instructions, assembly, operation, cleaning, maintenance, and technical specifications.</p>
	<p>Cecotec Energysilence Aero 5275: Manual de Instrucciones y Seguridad</p> <p>Descubra el ventilador de techo Cecotec Energysilence Aero 5275. Este manual proporciona instrucciones detalladas de seguridad, funcionamiento, limpieza y mantenimiento para los modelos DarkWood, Black&WhiteWood, White&BlackWood y WhiteWood.</p>
	<p>Cecotec EnergySilence Aero 5600 Classic: Manual de Instrucciones y Seguridad</p> <p>Descubra el manual completo para el ventilador de techo Cecotec EnergySilence Aero 5600 Classic. Incluye guías detalladas de instalación, uso seguro, mantenimiento, especificaciones técnicas y cumplimiento normativo.</p>

