

Pukomc Spartan

Pukomc Spartan 1.7L Electric Water Kettle User Manual

Model: Spartan

1. INTRODUCTION

Thank you for choosing the Pukomc Spartan 1.7L Electric Water Kettle. This manual provides essential information for the safe and efficient use of your new appliance. Please read all instructions carefully before first use and retain for future reference.

2. IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

1. Read all instructions.
2. Do not touch hot surfaces. Use handles or knobs.
3. To protect against fire, electric shock, and injury to persons, do not immerse cord, plugs, or electric kettle in water or other liquid.
4. Close supervision is necessary when any appliance is used by or near children.
5. Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
6. Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or adjustment.
7. The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or injury to persons.
8. Do not use outdoors.
9. Do not let cord hang over edge of table or counter, or touch hot surfaces.
10. Do not place on or near a hot gas or electric burner, or in a heated oven.
11. Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to 'off', then remove plug from wall outlet.

12. Do not use appliance for other than intended use.
13. Do not touch the kettle or open the lid when it is hot.
14. Please make sure that the lid is closed when working.
15. Keep the kettle out of reach of children.

3. PRODUCT OVERVIEW

The Pukomc Spartan Electric Water Kettle features a retro design with modern functionality, including a temperature gauge, automatic shut-off, and boil-dry protection.



Image 1: Front view of the Pukomc Spartan Electric Water Kettle, showcasing its green finish, temperature gauge, and handle.

Components:

- **Kettle Body:** Double-layer liner made of food-grade 304 stainless steel.
- **Lid:** Independent, removable lid for easy filling and cleaning.
- **Spout:** Circular spout with a filter to prevent splashing.
- **Handle:** Curved, ergonomic handle for comfortable pouring.

- **Temperature Gauge:** Analog dial on the front to display water temperature.
- **Water Level Line:** Visible window to monitor water volume.
- **Power Base:** 360° rotational base with cord storage.
- **On/Off Switch:** One-touch operation with LED indicator.



Image 2: Diagram highlighting key features such as ergonomic handle, visual window, large thermometer, auto-shutoff switch, UK STRIX thermostat, and 360° rotational base.

4. SPECIFICATIONS

Feature	Description
Brand	Pukomc
Model Name	Spartan
Capacity	1.7 Liters (also listed as 1.8 Liters in some specifications)
Power	1500W
Material	Food Grade 304 Stainless Steel (liner, inner lid, spout)

Color	Green
Special Features	Automatic Shut-Off, Boil Dry Protection, Illuminated Water Window, Temperature Gauge, Rapid Boil
Product Dimensions	7.8"L x 7.8"W x 10.8"H
Item Weight	3.28 pounds

5. SETUP

1. **Unpack:** Carefully remove all packaging materials and inspect the kettle for any damage.
2. **Clean:** Before first use, fill the kettle with clean water to the MAX line. Boil the water, then discard it. Repeat this process twice to ensure the kettle is clean.
3. **Placement:** Place the power base on a stable, flat, heat-resistant surface. Ensure the power cord is not dangling or in contact with hot surfaces.
4. **Connect:** Plug the power cord into a grounded electrical outlet.

6. OPERATING INSTRUCTIONS

1. **Fill the Kettle:** Open the lid and fill the kettle with the desired amount of water. Do not fill below the MIN line or above the MAX line (visible on the water level indicator). Ensure the lid is securely closed.
2. **Place on Base:** Position the kettle onto its 360° rotational power base.
3. **Start Boiling:** Press the On/Off switch down. The LED indicator will illuminate, signaling that the kettle is heating.
4. **Monitor Temperature:** The integrated temperature gauge will display the water's current temperature, allowing you to achieve optimal heat for various beverages.
5. **Automatic Shut-Off:** The kettle will automatically turn off once the water reaches a rolling boil. The LED indicator will extinguish.
6. **Serve:** Carefully lift the kettle from the base and pour. The curved handle and spout filter ensure controlled pouring.
7. **Re-boil:** If the kettle has cooled, you can re-boil by pressing the On/Off switch again.

Video 1: A quick demonstration of the Pukomc Electric Tea Kettle's features and operation, including filling, placing on the base, and activating the boil function.

Video 2: A user demonstrating the ease of use of the electric kettle, highlighting its quick boiling and convenient features.

7. MAINTENANCE AND CLEANING

Regular cleaning and maintenance will prolong the life of your Pukomc Electric Water Kettle.

1. **Daily Cleaning:** After each use, empty the kettle. Wipe the exterior with a soft, damp cloth. Do not use abrasive cleaners or scouring pads.
2. **Descaling:** To minimize mineral deposits (limescale), descale your kettle regularly, especially in hard water areas.
 - Add 1 cup of white vinegar and 3 cups of water to the kettle.

- Heat to a boil, then turn off and let it sit overnight.
 - Alternatively, use half a teaspoon of cream of tartar in half a kettle of water.
 - After emptying the descaling solution, refill the kettle with fresh water only, bring it to a boil, and drain. Repeat this rinsing process twice more to remove any residual taste or odor.
3. **Storage:** Ensure the kettle is clean and dry before storing. Wrap the excess cord around the cord storage base.



Image 3: The kettle with its lid removed, illustrating the large opening for easy cleaning and filling.

8. TROUBLESHOOTING

- **Kettle does not turn on:**

- Ensure the power base is properly plugged into a working electrical outlet.
- Check that the kettle is correctly seated on the power base.
- Verify the On/Off switch is pressed down and the LED indicator is lit.
- If there is no water in the kettle, the boil-dry protection may have activated. Add water and try again.

- **Water is not boiling:**

- Ensure the kettle is filled above the MIN line.
- Check that the lid is securely closed.

- **Water has an unusual taste:**

- Perform the descaling procedure outlined in the Maintenance section.
- Ensure the kettle has been thoroughly rinsed after descaling.

9. WARRANTY AND SUPPORT

For any product problems or damaged goods, please contact Pukomc customer support. We are committed to providing excellent after-sales service and will assist you promptly. Please refer to your purchase documentation for specific warranty details.