Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JXMOX USB C Female to USB Male Adapter

JXMOX USB C Female to USB Male Adapter User Manual

Model: USB C Female to USB Male Adapter

Brand: JXMOX



Image: A pack of four JXMOX USB C Female to USB Male Adapters.

1. Introduction

This manual provides essential instructions for the safe and efficient use of your JXMOX USB C Female to USB Male Adapter. This adapter is designed to convert a USB-C cable end into a standard USB-A male connector, allowing compatibility with a wider range of devices for charging and data transfer.

2. Key Features

- **USB-C Female to USB-A Male Conversion:** Enables connection of USB-C cables to standard USB-A ports.
- **Efficient Charging:** Supports stable charging speeds up to 5V/3A, 9V/2A for phones and tablets.

- **Data Transfer:** Offers USB 2.0 data transfer speeds up to 480 Mbps.
- **Plug and Play:** No drivers or software installation required for immediate use.
- **Safety and Durability:** Constructed with high-quality materials and features a built-in double-sided 56KΩ resistor for safe charging and data transfer.

3. Device Compatibility

This adapter is compatible with a wide range of USB-C enabled devices when connecting to a USB-A port for charging and data transfer. Compatible devices include, but are not limited to:

- iPhone models (X, 11, 12, 13, 14, 15, 16, 17 Pro Max)
- Apple Watch (iWatch Series SE, 7, 8 Ultra)
- iPad models (iPad Pro, iPad Air, iPad mini 6)
- Samsung Galaxy models (S25, S25+, S25 Ultra, S24, S24+, S24 Ultra, S23, S23+, S23 Ultra, S22, S22+, S22 Ultra, S21, S21+, S21 Ultra, S20, S20+, S20 Ultra, Note 10, Note 20)
- Google Pixel models (7, 7a, 6, 5, 4, 4a, 3, 3A, 2 XL)
- Other Type-C supported devices for charging and data transfer.



Image: Universal compatibility chart for USB-A and USB-C devices with the adapter.

4. Important Functional Limitations

Please be aware of the following limitations to ensure proper use:

- This adapter **will NOT support video signal transmission** (HDMI, VGA, DP, or other video signals).
- Due to incompatible charging protocols, this adapter **does NOT work with MagSafe wireless chargers**.
- This adapter **cannot charge laptops** (e.g., MacBook). It is designed for phones and tablets.
- This is a **USB 2.0 adapter** and does NOT support USB 3.0/3.1 protocol. It cannot achieve 5Gbps transmission speed.



Image: Visual representation of the adapter's use with a note on specific functional limitations.

5. Setup and Operation

The JXMOX USB C Female to USB Male Adapter is designed for simple plug-and-play functionality.

1. **Connect USB-C Cable:** Insert the USB-C male end of your charging or data cable into the USB-C female port of the JXMOX adapter. Ensure a secure connection.
2. **Connect to USB-A Port:** Plug the USB-A male end of the JXMOX adapter (now connected to your USB-C cable) into any standard USB-A port on your charger, power bank, computer, or car.
3. **Functionality:**
    - For *charging*, your device will begin charging at supported speeds.
    - For *data transfer*, your device will be recognized by the host device (e.g., computer) for file exchange at USB 2.0 speeds.



Image: Illustrates connecting a USB-C cable to the adapter and then to a USB-A wall charger for device charging.

6. Technical Specifications

Product Name	USB C Female to USB Male Adapter
Brand	JXMOX
Connector Type	USB Type C Female to USB Type A Male
Data Transfer Speed	Up to 480 Mbps (USB 2.0)
Power Output	Up to 5V/3A, 9V/2A
Safety Feature	Built-in Double-sided 56KΩ Resistor

Material	Aluminum shell
Item Weight	0.317 ounces (per adapter)



Image: Internal view of the adapter, illustrating the buck protection chip and aluminum shell for durability and safety.

7. Care and Maintenance

- Keep the adapter clean and free from dust and debris. Use a soft, dry cloth for cleaning.
- Avoid exposing the adapter to extreme temperatures or moisture.
- Do not attempt to disassemble or modify the adapter, as this may void any warranty and could cause damage.
- Store in a safe place when not in use to prevent loss or damage.

8. Troubleshooting

- **Device not charging/data not transferring:**

- Ensure both the USB-C cable and the adapter are securely connected.
- Verify that the power source (wall adapter, power bank, computer) is functional.
- Check if your device is listed under the "Important Functional Limitations" section (e.g., MagSafe, MacBook).
- Try using a different USB-C cable or USB-A port to rule out other component issues.

- **Slow charging/data transfer:**
  - Confirm that the connected USB-A port and cable support the desired speed. This adapter supports USB 2.0 speeds (up to 480 Mbps).
  - Ensure the power source provides sufficient output for your device.

9. Warranty and Support

For warranty information or technical support, please refer to the product packaging or contact JXMOX customer service directly. Keep your purchase receipt for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B092JNHDSB

More documents and user manuals: **https://manuals.plus/**