AERUS Beyond Guardian Air

AERUS Beyond Guardian Air Purifier Instruction Manual


Introduction

Welcome to your AERUS Beyond Guardian Air Purifier. This manual provides essential information for the safe and efficient operation and maintenance of your device. Please read these instructions carefully before using the product and retain them for future reference.

Key Features

The AERUS Beyond Guardian Air Purifier incorporates advanced technologies for comprehensive air purification, designed to improve indoor air quality.

- **Directional Air Intake:** Optimized design for efficient air capture.
- **Multi-Point Ion Generator:** Creates electrically charged particles to attract contaminants.
- **Carbon Layer:** Pre-filters large particles and absorbs odors.
- **Better-than-HEPA Filter:** Made from waterproof polypropylene, capturing 99.9% of particles as small as 0.1 micron.
- **UVC Light:** A germicidal lamp for enhanced purification.
- **ActivePure Technology:** A proprietary, active, Certified Space Technology that continuously works to remove contaminants from the air and surfaces.
- **4-Speed Dual Intake All-Metal Fan:** Moves particles towards the filter efficiently.
- **Angled Blades at Emission Point:** Creates dynamic airflow throughout the room.
- **HEPA Silent System:** Offers whisper-quiet operation on its lowest setting.
- **Durable All-Steel Construction:** Ensures longevity and contributes to sound insulation.



This diagram illustrates the internal structure and airflow path of the Beyond Guardian Air Purifier. Air enters through the directional intake (1), passes through the multi-point ion generator (2) and carbon layer (3). It then goes through the advanced polypropylene filter (4) and is exposed to UVC light (5) and ActivePure Technology (6). A 4-speed dual intake all-metal fan (7) moves the air, which is then emitted through angled blades (8). The unit features a HEPA Silent System (9) and durable all-steel construction (10).

Setup Instructions

Unpacking

Carefully remove the air purifier from its packaging. Retain all packaging materials for future transport or storage.

Placement

Place the unit on a flat, stable surface in an area where air circulation is not obstructed. Ensure adequate space around the air intake and exhaust vents. Avoid placing the unit near heat sources, direct sunlight, or in excessively humid environments.

Power Connection

Plug the power cord into a standard electrical outlet. Ensure the voltage matches the specifications of the unit.

Operating Instructions

Power On/Off

To turn the unit on, rotate the control knob clockwise from the 'OFF' position. To turn it off, rotate the knob counter-clockwise to 'OFF'.

Adjusting Airflow Speed

The unit features a 4-speed control knob for adjusting airflow:

- **HEPASilent™:** Provides quiet operation for minimal noise.
- **Low:** For general air purification.
- **Medium:** For increased air purification.
- **MAX airflow:** For maximum air purification and circulation.

Rotate the knob clockwise to increase airflow speed and counter-clockwise to decrease it.

Maintenance and Care

Filter Replacement

The Beyond HEPA Particle Filter (Part # 04057) should be replaced periodically to maintain optimal performance. The frequency depends on usage and air quality. To replace the filter:

1. Ensure the unit is powered off and unplugged.
2. Locate the filter access panel, typically on the side or back of the unit.
3. Open the panel and carefully remove the old filter. Note the orientation of the filter; the side labeled "THIS SIDE MUST FACE FRONT" should face outwards.
4. Insert the new Beyond HEPA Particle Filter, ensuring it is correctly oriented.
5. Close the filter access panel securely.

UVC Light Bulb Replacement

The UVC light bulb has a limited lifespan and will require replacement. Refer to the manufacturer's guidelines for specific replacement intervals and instructions. **Caution:** UVC light can be harmful. Always ensure the unit is unplugged before attempting to replace the UVC bulb. If you are unsure, contact qualified service personnel.

Exterior Cleaning

Wipe the exterior of the unit with a soft, damp cloth. Do not use abrasive cleaners or solvents.

Troubleshooting Guide

Unit Does Not Power On

- Check if the power cord is securely plugged into both the unit and the electrical outlet.
- Verify that the electrical outlet is functional by plugging in another device.
- Ensure the control knob is not in the 'OFF' position.

Reduced Airflow or Odor Removal

- Check if the air intake or exhaust vents are obstructed.
- The HEPA filter may be clogged and require replacement.
- The carbon layer may be saturated and require filter replacement.
- The UVC light bulb may need replacement.

Unusual Noise

- Ensure the unit is on a stable, level surface.
- Check for any foreign objects obstructing the fan.

- If the noise persists, contact customer support.

Product Specifications

Feature	Detail
Brand	AERUS
Model Number	Beyond Guardian Air
Color	Silver/Titanium
Power Source	Battery Powered
Control Method	Touch
Filter Type	Pre-Filter
Package Dimensions	23.23 x 19.69 x 11.02 inches
Item Weight	35.27 Pounds
Manufacturer	AERUS
First Available	April 14, 2021

Important Information

Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question