

Sharp 4T-C65DL6EX

Sharp 65-inch 4K Ultra HD LED Smart Android TV User Manual

Model: 4T-C65DL6EX

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation of your Sharp 65-inch 4K Ultra HD LED Smart Android TV, Model 4T-C65DL6EX. Please read these instructions thoroughly before using your television and retain them for future reference. Your new television features a 65-inch 4K Ultra HD display, runs on Android 10.0, and includes a built-in receiver and remote control.

2. IMPORTANT SAFETY INSTRUCTIONS

Observe the following safety precautions to prevent fire, electric shock, or injury:

- Do not expose this apparatus to rain or moisture.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- Only use attachments/accessories specified by the manufacturer.
- Unplug this apparatus during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified service personnel.

3. WHAT'S INCLUDED

Upon unpacking your Sharp 65-inch Smart Android TV, please ensure all the following items are present:

- Sharp 65-inch 4K Ultra HD LED Smart Android TV
- Remote Control
- Power Cable
- TV Stand (2 pieces) and Screws

- User Manual (this document)

4. SETUP

4.1 Attaching the TV Stand

To attach the stand to your television:

1. Carefully place the TV face-down on a soft, flat surface to prevent screen damage.
2. Align each stand piece with the corresponding slots on the bottom of the TV.
3. Secure each stand piece using the provided screws. Ensure they are tightened firmly.



Figure 4.1: Front view of the Sharp 65-inch Smart Android TV with its stand attached, displaying a vibrant landscape image.



Figure 4.2: Angled front view of the Sharp 65-inch Smart Android TV, showcasing the slim bezel and stand design.

4.2 Connecting External Devices

Your TV offers various ports for connecting external devices. Refer to the diagram below for port locations.



Figure 4.3: Side profile of the Sharp 65-inch Smart Android TV, highlighting the various input ports available for connectivity.

- **HDMI Ports:** Connect Blu-ray players, game consoles, cable/satellite boxes, etc.
- **USB Ports:** Connect USB storage devices for media playback.
- **Antenna/Cable Input:** Connect your antenna or cable for broadcast TV.
- **Ethernet Port:** For a wired internet connection.

4.3 Powering On for the First Time

After connecting all necessary cables:

1. Plug the power cable into the TV and then into a wall outlet.
2. Press the Power button on the remote control or on the TV itself.
3. Follow the on-screen instructions to complete the initial setup, including language selection, network connection (Wi-Fi or Ethernet), and Google account sign-in for Android TV features.



Figure 4.4: Close-up view of the power and control buttons located on the television unit.

5. OPERATING YOUR TV

5.1 Remote Control Overview

The included remote control allows you to navigate your TV's features. Familiarize yourself with its buttons:



Figure 5.1: The Sharp Smart TV remote control, featuring dedicated buttons for popular streaming services and voice control.

- **Power:** Turns the TV on or off.
- **Number Buttons:** Select channels directly.
- **Navigation Pad (Up/Down/Left/Right/OK):** Navigate menus and select options.
- **Back:** Returns to the previous screen.
- **Home:** Accesses the Android TV home screen.
- **Volume +/-:** Adjusts the volume level.
- **Channel +/-:** Changes TV channels.
- **Source:** Selects input sources (HDMI, AV, TV).
- **Netflix/YouTube/Prime Video Buttons:** Direct access to these applications.
- **Google Assistant Button:** Activates voice control.

5.2 Android TV Interface

Your TV runs on Android 10.0, providing access to a wide range of apps and services. The home screen displays your favorite apps, recommended content, and settings.



Figure 5.2: The Android TV home screen, showing various applications and content recommendations.

- **Apps:** Access installed applications from the 'Apps' row.
- **Google Play Store:** Download new apps, games, and content.
- **Settings:** Customize TV settings, network connections, and user preferences.
- **Google Assistant:** Use voice commands to search for content, control smart home devices, and get information.

5.3 Switching Input Sources

To switch between connected devices (e.g., a game console on HDMI 1, a Blu-ray player on HDMI 2, or the built-in receiver):

1. Press the **Source** button on your remote control.
2. Use the navigation buttons to highlight the desired input source.
3. Press **OK** to select it.

6. MAINTENANCE

6.1 Cleaning the TV Screen

To clean the screen, gently wipe it with a soft, lint-free cloth. For stubborn marks, lightly dampen the cloth with water or a specialized screen cleaner. Never spray cleaner directly onto the screen.

6.2 Cleaning the TV Casing

Wipe the TV casing with a soft, dry cloth. Avoid using abrasive cleaners or solvents, as they may damage the finish.

7. TROUBLESHOOTING

If you encounter issues with your TV, refer to the following common problems and solutions:

Problem	Possible Solution
No power	Ensure the power cable is securely plugged into both the TV and the wall outlet. Check if the outlet is working.
No picture, but sound is present	Check the input source selection. Ensure external devices are powered on and connected correctly.
No sound, but picture is present	Check the volume level and ensure the TV is not muted. Verify audio cables for external devices.
Remote control not working	Replace the batteries in the remote control. Ensure there are no obstructions between the remote and the TV's IR sensor.
Smart TV features are slow or unresponsive	Check your internet connection. Restart the TV by unplugging it for a few minutes and plugging it back in. Clear app caches if necessary.

8. SPECIFICATIONS

Key technical specifications for the Sharp 65-inch 4K Ultra HD LED Smart Android TV (Model 4T-C65DL6EX):

- **Screen Size:** 65 Inches
- **Display Technology:** LED
- **Resolution:** 4K Ultra HD
- **Refresh Rate:** 60 Hz
- **Operating System:** Android 10.0
- **Connectivity Technology:** Wi-Fi
- **Aspect Ratio:** 16:9
- **Item Model Number:** 4T-C65DL6EX
- **Manufacturer:** Sharp
- **Item Dimensions (D x W x H):** 29D x 144.8W x 89.9H centimeters
- **Package Dimensions:** 50 x 50 x 18 cm; 21 kg




Figure 8.1: Dimensional diagram of the Sharp 65-inch Smart Android TV, indicating height, width, and depth.






9. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation provided with your purchase or contact your local Sharp authorized service center. In some regions, support may be provided by Al-Araby Group.

© 2025 Sharp Corporation. All rights reserved.

Related Documents - 4T-C65DL6EX

	<p>Sharp AQUOS TV User Manual - Operation Guide</p> <p>This user manual provides comprehensive instructions for Sharp AQUOS TVs, covering remote control operation, TV settings, picture and sound adjustments, applications, Google Assistant features, gaming interface, troubleshooting, and important disclaimers. It details various models including the 4T-C85HU8500X series.</p>
---	--

	<p>SHARP AQUOS LED Backlight TV User Manual and Setup Guide</p> <p>Comprehensive guide for SHARP AQUOS LED Backlight TVs, covering initial setup, safety precautions, troubleshooting, and technical specifications. Includes model information for 4T-C65FL1X, 4T-C75FK1X, and others.</p>
	<p>SHARP AQUOS Google TV 4T-C</p> <p>SHARP AQUOS Google TV , 4T-C Google</p>
	<p>Sharp AQUOS LED Backlight TV/Monitor Operation Manual</p> <p>Comprehensive operation manual for Sharp AQUOS LED Backlight TVs and Monitors, covering setup, features, troubleshooting, and advanced settings.</p>
	<p>SHARP AQUOS Google TV User Manual - Setup, Features, and Troubleshooting Guide</p> <p>Comprehensive guide for SHARP AQUOS Google TV models (HU, HN, HL, HJ series). Learn about remote control functions, picture and sound settings, app installation, Google Assistant, game features, and troubleshooting tips.</p>
	<p>Manual Operasi SHARP AQUOS Google TV</p> <p>Panduan komprehensif untuk TV/monitor LED backlight SHARP AQUOS Google TV, mencakup pengaturan, antarmuka pengguna, fitur Google Assistant, AI Karaoke, pemecahan masalah, dan spesifikasi teknis.</p>