

Swatch SB03B100

Swatch Big Bold Standard Next Quartz Watch SB03B100 - Instruction Manual

Model: SB03B100

1. INTRODUCTION

Welcome to your new Swatch Big Bold Standard Next Quartz Watch. This manual provides essential information for the proper setup, operation, and maintenance of your timepiece. Please read it thoroughly to ensure optimal performance and longevity of your watch.

Your Swatch watch is designed with quality materials and precision engineering to offer reliable timekeeping and a distinctive style. Enjoy wearing your new Swatch!

2. PRODUCT OVERVIEW

The Swatch Big Bold Standard Next Quartz Watch (Model SB03B100) features a robust 47mm round case made from bioceramic material, offering a lightweight yet durable design. It is equipped with a reliable Quartz movement for accurate timekeeping and a comfortable silicone strap. The watch is water-resistant up to 100 feet (3 BAR), making it suitable for everyday wear and light water activities.



Figure 2.1: Front view of the Swatch Big Bold Standard Next Quartz Watch.



3. SETUP

3.1 Initial Activation

Your Swatch watch comes with a pre-installed CR2 battery. To activate the watch, gently push the crown (the small knob on the side of the watch case) inwards until it clicks into place. The second hand will begin to move, indicating the watch is active.

3.2 Setting the Time

1. Pull the crown outwards to the time-setting position.
2. Rotate the crown clockwise or counter-clockwise to adjust the hour and minute hands to the correct time.
3. Once the time is set, push the crown back into its original position to start the watch.

4. OPERATING INSTRUCTIONS

4.1 Time Display

The watch displays time using three hands: an hour hand, a minute hand, and a second hand. The dial features clear markers for hours and minutes, ensuring easy readability.

4.2 Water Resistance

Your Swatch watch is water-resistant up to 3 BAR (100 feet / 30 meters). This means it is suitable for everyday use and can withstand splashes, rain, and brief immersion in water. It is **not** recommended for swimming, diving, or showering, as prolonged exposure to water pressure or hot water can compromise the seals.

5. MAINTENANCE

5.1 Cleaning Your Watch

To clean your Swatch watch, use a soft, damp cloth. Avoid using harsh chemicals, solvents, or abrasive cleaners, as these can damage the watch case, crystal, or strap. For the silicone strap, mild soap and water can be used, followed by thorough rinsing and drying.

5.2 Battery Replacement

When the watch stops running, it indicates that the battery needs to be replaced. Your Swatch watch uses one CR2 battery. Swatch offers free battery exchange at official Swatch retail locations. It is recommended to have the battery replaced by an authorized Swatch service center to ensure proper sealing and maintain water resistance.

5.3 Storage

Store your watch in a cool, dry place away from direct sunlight, extreme temperatures, and strong magnetic fields when not in use. This helps preserve the watch's materials and battery life.

6. TROUBLESHOOTING

- **Watch not running:** Check if the crown is fully pushed in. If it is, the battery may need replacement.

Refer to Section 5.2.

- **Time is inaccurate:** Reset the time as described in Section 3.2. If inaccuracy persists, the watch may require servicing.
- **Condensation under the crystal:** This indicates a potential breach in water resistance. Avoid further water exposure and have the watch inspected by an authorized service center immediately.
- **Strap discomfort or irritation:** Ensure the strap is clean (refer to Section 5.1) and not too tight. If irritation continues, consult a medical professional.

7. SPECIFICATIONS

Feature	Detail
Model Number	SB03B100
Collection	BIG BOLD STANDARD NEXT
Movement	Quartz
Case Material	Bioceramic
Case Diameter	47 mm
Case Thickness	11.75 mm
Strap Material	Silicone
Strap Width	16 mm
Clasp Type	Plastic Buckle
Water Resistance	3 BAR (100 Feet / 30 Meters)
Battery Type	1 CR2 (included)
Display Type	Analog

8. WARRANTY AND SUPPORT

8.1 International Warranty

Your Swatch watch comes with a 2-year international warranty covering manufacturing defects. This warranty does not cover normal wear and tear, accidental damage, or damage resulting from improper use or unauthorized repairs. For detailed warranty information, please refer to the official Swatch warranty documentation provided with your purchase or visit the [product page](#).

8.2 Customer Support

For any questions, service requests, or technical support, please contact Swatch customer service or visit an authorized Swatch retail store. Authorized service centers are equipped to handle repairs and battery replacements while maintaining the integrity of your watch.

