

[Manuals.plus](#) /

› [Midea](#) /

› Midea MF100W70-E Washing Machine User Manual

Midea MF100W70-E

Midea MF100W70-E Washing Machine User Manual

Your comprehensive guide to installation, operation, and maintenance.

INTRODUCTION

Thank you for choosing the Midea MF100W70-E Washing Machine. This appliance is designed to provide efficient and reliable laundry care with its 7 kg capacity, 1200 RPM spin speed, and a super slim 400mm depth, making it ideal for spaces where depth is a concern. This manual provides essential information for safe and effective use, from initial setup to daily operation and maintenance.



Front view of the Midea MF100W70-E Washing Machine, showcasing its sleek white design and large front-loading door.

SAFETY INFORMATION

Please read all safety instructions carefully before using the appliance to prevent personal injury or damage to the machine.

- Ensure the appliance is properly grounded and connected to a suitable power supply.
- Do not allow children to play with or operate the washing machine.
- Never force the door open during operation. Wait until the cycle is complete and the door unlocks.
- Do not wash items that have been soiled with flammable substances.
- In case of malfunction, switch off the appliance and unplug it immediately. Contact qualified service personnel.
- Always close the water tap after use to prevent leaks.

PRODUCT OVERVIEW

Key Features

- **7 kg Capacity:** Suitable for small to medium-sized households.
- **Energy Efficiency Class D:** Efficient performance with reduced energy consumption.
- **1200 RPM Spin Speed:** Effective water extraction for faster drying.
- **Super Slim Design (400mm Depth):** Space-saving design without compromising capacity or wash results.
- **Multiple Temperature Options:** Five selectable temperatures (Cold, 20°C, 40°C, 60°C, 90°C) for diverse fabric care.
- **Hygiene 90°C Program:** Thoroughly removes stubborn stains, detergent residues, and harmful germs.
- **Cold Wash Function:** Reduces color fading, protects clothes, and saves energy.
- **Pre-wash Function:** Additional wash cycle for heavily soiled items.
- **AquaStop:** Integrated safety feature to prevent water damage.



Angled view of the washing machine, highlighting its compact and modern design.



Slim Design



Hygiene 90 °C



Schnellwäsche 15'/45'



Intuitiv Lunar Dial



Visual representation of the washing machine's dimensions and highlighted features like Slim Design and Hygiene 90°C.

Das neue Lunar Dial Kombi-Display

Ein Drehknopf mit integrierter LED-Bildschirmanzeige für eine reibungslose Steuerung



Detailed view of the intuitive Lunar Dial control panel with integrated LED display for seamless operation.

400mm



The pull-out detergent dispenser drawer, designed for easy filling of washing agents.

Unpacking

Carefully remove all packaging materials. Ensure all transit bolts at the rear of the machine are removed before use. Keep packaging materials out of reach of children.

Placement

Place the washing machine on a firm, level surface. Ensure there is adequate space around the appliance for ventilation and connections. The appliance dimensions are H x W x D: 85 x 60 x 40 cm.



Diagram showing the front and side dimensions (850mm H, 600mm W, 400mm D) of the washing machine.



Side view emphasizing the slim 400mm depth, ideal for compact spaces.

Water and Electrical Connections

Connect the water inlet hose to a cold water tap and the drain hose to a suitable drain. Ensure all connections are secure to prevent leaks. Plug the power cord into a grounded electrical outlet. The appliance operates at 240 Volts and 2050 Watts.

Leveling

Adjust the leveling feet at the bottom of the machine to ensure it is perfectly stable and level. This will minimize vibration and noise during operation.

OPERATING INSTRUCTIONS

Control Panel Overview

The washing machine features an intuitive Lunar Dial with an integrated LED display for easy program selection and monitoring.



ENERG 



MIDEA

MF100W70-E



69 kWh /  **100** **F**



7,0 kg




3:28



45 L

G



2019/2014

A hand turning the central control dial to select a wash program.

Loading Laundry

Open the washing machine door and load your laundry. Do not overload the machine; ensure there is enough space for clothes to tumble freely.



The Midea washing machine integrated into a home environment, ready for use.

Adding Detergent

Pull out the detergent dispenser drawer and add the appropriate amount of detergent and fabric softener to the designated compartments.

Program Selection

Turn the program selector dial to choose the desired wash program. The display will show the estimated time and selected temperature.

- **Quick Wash 15'/45'**: For lightly soiled items requiring a fast wash.
- **Hygiene 90°C**: For deep cleaning and sanitization, ideal for baby clothes or heavily soiled items.
- **Cold Wash**: Energy-saving option for delicate fabrics and color retention.
- **Mix**: For mixed loads of cotton and synthetics.

- **Jeans:** Specific program for denim.
- **ECO 40-60:** Energy-efficient program for normally soiled cotton items washable at 40°C or 60°C.

WARTUNG

Delegierte Verordnung (EU) 2019/2023

Name oder Handelsmarke des Lieferanten: Midea Europe GmbH					
Anschrift des Lieferanten (b): Ludwig-Erhard-Straße 14, DE-65760 Eschborn					
Modellkennung:		MF100W70-E			
Allgemeine Produktparameter:					
Parameter	Wert		Parameter	Wert	
Nennkapazität (a) (kg)	7,0		Abmessungen in cm	Höhe	85
				Breite	60
				Tiefe	40
EElw(a)	80,0		Energieeffizienzklasse (a)	D	
Wascheffizienzindex (a)	1,04		Spülwirkung (g/kg) (a)	5,0	
Energieverbrauch in kWh pro Betriebszyklus im Programm „eco 40-60“. Der tatsächliche Energieverbrauch hängt von der jeweiligen Nutzung des Geräts ab.	0,69		Wasserverbrauch in Litern pro Betriebszyklus im Programm „eco 40-60“. Der tatsächliche Wasserverbrauch hängt von der jeweiligen Nutzung des Geräts und vom Härtegrad des Wassers ab.	45	
Höchste Temperatur innerhalb der behandelten Textilien (a) (°C)	Nennkapazität	39	Restfeuchte (a) %	Nennkapazität	62
	halbe Nennkapazität	35		halbe Nennkapazität	62
	Viertel der Nennkapazität	30		Viertel der Nennkapazität	62
Schleuderdrehzahl (a) (U/min)	Nennkapazität	1200	Schleudereffizienzklasse (a)	C	
	halbe Nennkapazität	1200			
	Viertel der Nennkapazität	1200			
Programmdauer (a) (h: min)	Nennkapazität	3:28	Art	freistehend	
	halbe Nennkapazität	2:42			
	Viertel der Nennkapazität	2:42			
Luftschallemissionen im Schleudergang(a) (dB(A) re 1 pW)	80		Luftschallemissionsklasse (a) (Schleudergang)	C	
Aus-Zustand(W)	0,50		Bereitschaftszustand(W)	1,00	
Zeitvorwahl (W) (falls zutreffend)	4,00		vernetzter Bereitschaftsbetrieb (W) (falls zutreffend)	k.A.	
Mindestlaufzeit der vom Lieferanten angebotenen Garantie (b): 24 Monate					
Dieses Produkt ist so konzipiert, das es während des Waschzyklus Silberionen freisetzt			NO		
Weitere Angaben:					
Weblink zur Website des Lieferanten, auf der die Informationen gemäß Anhang II Nummer 9 der Verordnung (EU) 2019/2023 der Kommission (1) (b) zu finden sind: www.midea.com/de					

- (A) Angaben für das Programm „eco 40-60“.
- (b) Änderungen dieser Einträge gelten nicht als relevante Änderungen im Sinne des Artikels 4 Absatz 4 der Verordnung (EU) 2017/1369.
- (c) Wenn die Produktdatenbank automatisch den endgültigen Inhalt dieser Zelle generiert, darf der Lieferant diese Daten nicht eingeben.

Visual showing the quick wash options, allowing for washes in 15 or 45 minutes.

WARTUNG

Delegierte Verordnung (EU) 2019/2023

Name oder Handelsmarke des Lieferanten: Midea Europe GmbH					
Anschrift des Lieferanten (b): Ludwig-Erhard-Straße 14, DE-65760 Eschborn					
Modellkennung: MF100W70-E					
Allgemeine Produktparameter:					
Parameter	Wert		Parameter	Wert	
Nennkapazität (a) (kg)	7,0		Abmessungen in cm	Höhe	85
				Breite	60
				Tiefe	40
EElw(a)	80,0		Energieeffizienzklasse (a)	D	
Wascheffizienzindex (a)	1,04		Spülwirkung (g/kg) (a)	5,0	
Energieverbrauch in kWh pro Betriebszyklus im Programm „eco 40-60“. Der tatsächliche Energieverbrauch hängt von der jeweiligen Nutzung des Geräts ab.	0,69		Wasserverbrauch in Litern pro Betriebszyklus im Programm „eco 40-60“. Der tatsächliche Wasserverbrauch hängt von der jeweiligen Nutzung des Geräts und vom Härtegrad des Wassers ab.	45	
Höchste Temperatur innerhalb der behandelten Textilien (a) (°C)	Nennkapazität	39	Restfeuchte (a) %	Nennkapazität	62
	halbe Nennkapazität	35		halbe Nennkapazität	62
	Viertel der Nennkapazität	30		Viertel der Nennkapazität	62
Schleuderdrehzahl (a) (U/min)	Nennkapazität	1200	Schleudereffizienzklasse (a)	C	
	halbe Nennkapazität	1200			
	Viertel der Nennkapazität	1200			
Programmdauer (a) (h: min)	Nennkapazität	3:28	Art	freistehend	
	halbe Nennkapazität	2:42			
	Viertel der Nennkapazität	2:42			
Luftschallemissionen im Schleudergang(a) (dB(A) re 1 pW)	80		Luftschallemissionsklasse (a) (Schleudergang)	C	
Aus-Zustand(W)	0,50		Bereitschaftszustand(W)	1,00	
Zeitvorwahl (W) (falls zutreffend)	4,00		vernetzter Bereitschaftsbetrieb (W) (falls zutreffend)	k.A.	

Mindestlaufzeit der vom Lieferanten angebotenen Garantie (b): 24 Monate

Dieses Produkt ist so konzipiert, das es während des Waschzyklus Silberionen freisetzt

NO

Weitere Angaben:

Weblink zur Website des Lieferanten, auf der die Informationen gemäß Anhang II Nummer 9 der Verordnung (EU) 2019/2023 der Kommission (1) (b) zu finden sind: www.midea.com/de

(A) Angaben für das Programm „eco 40-60“.

(b) Änderungen dieser Einträge gelten nicht als relevante Änderungen im Sinne des Artikels 4 Absatz 4 der Verordnung (EU) 2017/1369.

(c) Wenn die Produktdatenbank automatisch den endgültigen Inhalt dieser Zelle generiert, darf der Lieferant diese Daten nicht eingeben.


33

Illustration of the Hygiene 90°C program, designed to eliminate 99% of bacteria for a thorough clean.



ENERG

**MIDEA****MF100W70-E****69 kWh****F**



红框为裁切线

Visual demonstrating the cold wash option, suitable for a range of fabrics to prevent color fading and save energy.

Starting a Wash Cycle

Press the Start/Pause button to begin the selected wash cycle. The machine will automatically proceed through the wash, rinse, and spin phases.

End of Cycle

Once the cycle is complete, the machine will signal with an audible alert and the door will unlock. Remove your laundry promptly.

MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your washing machine.

Cleaning the Detergent Dispenser

Periodically remove and clean the detergent dispenser drawer to prevent residue buildup. Rinse it under running water and dry thoroughly before reinserting.

Cleaning the Drum

Run a maintenance wash cycle (e.g., Hygiene 90°C without laundry) monthly to clean the drum and remove any detergent or fabric softener residues.

Cleaning the Filter

The drain pump filter should be cleaned regularly to prevent blockages. Refer to the diagram near the bottom right of the machine for filter access. Place a shallow container to catch any residual water before opening.

External Cleaning

Wipe the exterior of the machine with a soft, damp cloth. Do not use abrasive cleaners or solvents.

TROUBLESHOOTING

Before contacting customer support, please refer to the following table for common issues and their solutions.


Problem	Possible Cause	Solution
Machine does not start.	Power cord not plugged in; door not closed properly; program not selected.	Check power connection; ensure door is securely latched; select a program and press Start.
No water intake.	Water tap closed; water inlet hose kinked or blocked.	Open water tap; straighten hose; check for blockages.
Machine vibrates excessively.	Transit bolts not removed; machine not level; uneven load.	Remove transit bolts; adjust leveling feet; redistribute laundry evenly.
Water not draining.	Drain hose kinked or blocked; drain pump filter clogged.	Straighten hose; clean drain pump filter.
Unpleasant odor from machine.	Residue buildup in drum or detergent dispenser.	Run a maintenance wash (e.g., Hygiene 90°C); clean detergent dispenser.

SPECIFICATIONS

Detailed technical specifications for the Midea MF100W70-E Washing Machine.

Specification	Value
Model Number	MF100W70-E
Capacity	7 Kilograms
Energy Efficiency Class	D
Maximum Spin Speed	1200 RPM
Product Dimensions (H x W x D)	85 x 59.5 x 40 cm
Weight	55 Kilograms
Annual Energy Consumption (per 100 cycles)	69 kWh
Airborne Acoustical Noise Emission (Spin Cycle)	80 dB
Voltage	240 Volts
Wattage	2050 Watts
Installation Type	Freestanding

Specification	Value
Control Type	Push Button / Rotary Dial
Door Opening	Front Load



Official EU Energy Label for the Midea MF100W70-E, indicating its energy efficiency class D and consumption details.

For more details, visit the [EPREL database](#).

WARRANTY INFORMATION

The Midea MF100W70-E Washing Machine comes with a standard manufacturer's warranty. Based on available information, the minimum warranty period offered is **24 months** from the date of purchase. Please retain your proof of purchase for warranty claims. For specific terms and conditions, refer to the warranty card included with your appliance or contact Midea customer support.

SUPPORT AND CONTACT

Should you require further assistance or have any questions regarding your Midea washing machine, please do not hesitate to contact our customer support team.



Our dedicated customer support team is ready to assist you.

Phone: +49 (0) 6196-90 20-0 (Monday - Friday, 08:30 - 17:30)

Email: kundenservice@midea.com

Website: www.midea.com

© 2024 Midea. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question