

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [EarFun](#) /

› [EarFun Free 2 Wireless Earbuds User Manual](#)

EarFun Free 2

EarFun Free 2 Wireless Earbuds User Manual

Model: Free 2

INTRODUCTION

Thank you for choosing the EarFun Free 2 Wireless Earbuds. This manual provides detailed instructions on how to set up, operate, and maintain your earbuds to ensure optimal performance and longevity. Please read this manual thoroughly before use and retain it for future reference.

SAFETY INFORMATION

- Do not disassemble or modify the earbuds or charging case.
- Keep the device away from extreme temperatures, humidity, and liquids.
- Avoid prolonged exposure to high volume levels to prevent hearing damage.
- Clean the earbuds regularly with a soft, dry cloth.
- Dispose of the device responsibly according to local regulations.

PACKAGE CONTENTS

Please check that all items are present in your package:

- EarFun Free 2 Wireless Earbuds (L/R)
- Charging Case
- USB-C Charging Cable
- Ear Tips (S/M/L)
- User Manual

PRODUCT OVERVIEW



Image: The EarFun Free 2 Wireless Earbuds are shown inside their open charging case. The case is black with a matte finish. One earbud is partially visible in its charging slot, while the other is shown removed from the case, positioned above it. Both earbuds are black with the "earfun" logo visible on their outer surface. A blue indicator light is visible on the earbud outside the case, and another on the earbud inside the case, indicating power or charging status.

The EarFun Free 2 consists of two wireless earbuds and a portable charging case. Each earbud features a touch control area, microphone, and charging contacts. The charging case has a USB-C port for charging and LED indicators for battery status.

SETUP

1. Initial Charge

Before first use, fully charge both the earbuds and the charging case. Place the earbuds into the charging case and connect the USB-C cable to the charging port on the case and a power source. The LED indicators on the case will show charging status.

2. Pairing with Your Device

1. Ensure the earbuds are fully charged.
2. Open the charging case. The earbuds will automatically enter pairing mode (indicated by a flashing blue light on the earbuds).
3. On your device (smartphone, tablet, etc.), enable Bluetooth.
4. Search for "EarFun Free 2" in the list of available Bluetooth devices and select it to connect.
5. Once connected, a voice prompt will confirm successful pairing.

Note: If pairing fails, place the earbuds back into the case, close the lid, then open it again and repeat the steps.

3. Wearing the Earbuds

Choose the ear tips that provide the best seal and comfort for your ears. Gently insert the earbuds into your ear canal and twist them slightly to secure a snug fit. A proper fit is crucial for optimal sound quality and noise isolation.

OPERATING INSTRUCTIONS

Power On/Off

- **Power On:** Open the charging case, and the earbuds will automatically power on.
- **Power Off:** Place the earbuds back into the charging case and close the lid. They will automatically power off and begin charging.

Touch Controls

Function	Action
Play/Pause	Single tap on either earbud
Next Track	Double tap on the Right earbud
Previous Track	Double tap on the Left earbud
Volume Up	Triple tap on the Right earbud
Volume Down	Triple tap on the Left earbud
Answer/End Call	Single tap on either earbud
Reject Call	Press and hold either earbud for 2 seconds
Activate Voice Assistant	Press and hold the Left earbud for 2 seconds
Game Mode On/Off	Press and hold the Right earbud for 2 seconds

MAINTENANCE

- **Cleaning:** Regularly clean the ear tips and charging contacts with a dry, soft cotton swab. Do not use harsh chemicals or abrasive materials.
- **Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged.
- **Battery Care:** To prolong battery life, avoid fully discharging the earbuds and case frequently. Charge them regularly, even if not in constant use.
- **Water Resistance:** The earbuds are IPX7 waterproof. However, ensure they are completely dry before placing them back into

the charging case to prevent damage to the charging contacts.

TROUBLESHOOTING

Problem	Possible Solution
Earbuds not connecting to device	<ul style="list-style-type: none">Ensure Bluetooth is enabled on your device.Check if "EarFun Free 2" is selected in your device's Bluetooth settings.Place earbuds back in case, close lid, then open to re-enter pairing mode.Forget "EarFun Free 2" from your device's Bluetooth list and re-pair.
Only one earbud playing sound	<ul style="list-style-type: none">Ensure both earbuds are charged.Place both earbuds back into the charging case, close the lid, and then open it again.Try resetting the earbuds (refer to the full user manual for specific reset instructions if needed).
Low volume or poor sound quality	<ul style="list-style-type: none">Adjust the volume on both your device and the earbuds.Ensure ear tips provide a proper seal in your ear canal.Clean any debris from the ear tips and earbud nozzles.
Earbuds not charging	<ul style="list-style-type: none">Ensure the charging cable is securely connected to both the case and the power source.Check if the charging contacts on the earbuds and inside the case are clean and free of debris.Try a different USB-C cable or power adapter.

SPECIFICATIONS




- Model:** Free 2
- Bluetooth Version:** 5.2
- Bluetooth Profile:** A2DP, AVRCP, HFP, HSP
- Bluetooth Codec:** aptX, AAC, SBC
- Operating Range:** Up to 15m (without obstacles)
- Battery Capacity (Earbud):** 50mAh
- Battery Capacity (Charging Case):** 400mAh
- Playtime:** Up to 7 hours (earbuds), 30 hours (with charging case)
- Charging Time (Earbuds):** Approx. 1.5 hours
- Charging Time (Case):** Approx. 2 hours
- Water Resistance:** IPX7
- Microphones:** 4 (cVc 8.0 Noise Reduction)


WARRANTY AND SUPPORT

EarFun products come with a standard warranty. For detailed warranty information, product registration, or technical support, please visit the official EarFun website or contact their customer service. Please have your product model and purchase details ready when contacting support.

Website: www.myearfun.com

Related Documents - Free 2

 User Manual	<p>EarFun Free 2S True Wireless Earbuds User Manual</p> <p>Comprehensive user manual for EarFun Free 2S True Wireless Earbuds, covering setup, features, functions, troubleshooting, and specifications. Learn how to pair, use the EarFun Audio app, and maintain your earbuds.</p>
 User Manual	<p>EarFun Free Wireless Earbuds: FAQs and Troubleshooting Guide</p> <p>Find answers to common questions about EarFun Free wireless earbuds, including pairing, reset procedures, waterproofing, and connectivity. Get support for your Bluetooth headphones.</p>
 User Manual	<p>EarFun Free Pro 3 ANC Wireless Earbuds User Manual</p> <p>Comprehensive user manual for the EarFun Free Pro 3 ANC Wireless Earbuds, covering setup, pairing, functions, troubleshooting, and specifications. Features Qualcomm aptX Adaptive technology.</p>
 User Manual	<p>EarFun Air Pro 3 ANC Wireless Earbuds User Manual</p> <p>Explore the EarFun Air Pro 3 ANC Wireless Earbuds. This user manual covers setup, features like Qualcomm aptX Adaptive, Bluetooth 5.3, multipoint connection, app customization, and troubleshooting for an optimal audio experience.</p>
 User Manual	<p>EarFun Free 2 Skutečně Bezdrátová Sluchátka – Uživatelská Příručka</p> <p>Komplexní uživatelská příručka pro bezdrátová sluchátka EarFun Free 2. Obsahuje informace o součástech, nabíjení, párování, funkcích, řešení problémů a technických specifikacích.</p>
 User Manual	<p>Mifo O5 Plus Gen 2 Wireless Earbuds User Manual</p> <p>User manual for the Mifo O5 Plus Gen 2 Wireless Earbuds, covering Bluetooth pairing, charging case indicators, on-earbud functions, and important safety information.</p>




Használati utasítás

Issue About The Low Volume:

In fact, the volume of the EarFun Free 2 Earbuds is at a mid-to-high level, NOT low.

We appreciate the feedback from our customers that they felt the volume of EarFun Free 2 was not high enough in their actual experience.

We immediately paid attention to it and did a very scientific test on the volume. The result is that the ear sound is at a normal level among many headphones. (Please refer to the chart below.)



* If you feel that the volume is low, please pay attention to **wearing the earbuds well**, so that the earbuds perfectly fit your ear canal, which will significantly make you feel the louder volume.

Or please **clean the dusts or earwax** on the mesh of earbuds with cotton swabs.

Or please note if you **adjust the volume of your phone higher** rather than lower.

[pdf] User Manual Specifications

EarFun TW101 T8 04 01 EarFun Free 2 Használati utasítás HU dwn alza cz manual 97451 |||

Használati utasítás 1 Mi van a dobozban EarFun Free 2 Tilt tok USB-C kabel 2 Termék vzlat

Felugrók S, M, L Használati utasítás 1 rint vezetés 5 USB-C tilt port 9 Tilt tok gomb 2

LEDjelzés 6 Tilt tok 3 Mikrofon 7 Tilt dokkol 4 Tilt rintkezés 8 Tilt tok jelzés 01 3 Tilt

1. Nyissa ki vagy zárja be a tl...

lang:en score:32 filesize: 1.05 M page_count: 12 document date: 2021-10-25

[pdf] Troubleshooting Guide


Troubleshooting guide EarFun® Free 2S Wireless Earbuds Upgraded Version Qualcomm® CVC™ 8.0

ENC Bluetooth 5.2 Sweatshield™ IPX7 Waterproof Headphone aptX™ Deep Bass EarFun APP Game

Mode Amazon ca Electronics 71IZqBC6Y1L m media amazon images 1 |||

Issue About The Low Volume: In fact, the volume of the EarFunFree 2 Earbuds is at a mid-to-high level, NOT low. We appreciate the feedback from our customers that they felt the volume of EarFun Free 2 was not high enough in their actual experience. We immediately paid attention to it and did a very...

lang:en score:27 filesize: 238.18 K page_count: 1 document date: 2021-09-18



EarFun Free 2 Skutečně Bezdrátová Sluchátka – Uživatelská Příručka

Komplexní uživatelská příručka pro bezdrátová sluchátka EarFun Free 2. Obsahuje informace o součástech, nabíjení, párování, funkcích, řešení problémů a technických specifikacích.

lang:hr score:27 filesize: 1.5 M page_count: 2 document date: 2022-09-13




[pdf]

EarFun TW101 T1 02 23 Packaging Earfun Technology HK Limited True Wireless Earbuds 2AVIT

2AVITTW101 tw101

TW101- EarFun Free 2 True Wireless Earbuds EarFun Free 2 Superior Sound with Composite Drivers 30 Hour Playtime: 7 Hours 23 Hours with Charging Case IPX7 Waterproof with SweatShieldTM Technology IPX7 Wireless Charging Compatible Single Earbud Mode - Right or Left Intuitive Touch Control Volume ...


lang:af score:19 filesize: 795.65 K page_count: 1 document date: 2021-04-08



[EarFun Free 2 True Wireless Earbuds User Manual](#)

Comprehensive user manual for the EarFun Free 2 True Wireless Earbuds. Includes setup instructions, pairing guide, function details, specifications, troubleshooting tips, and compliance information. Features Qualcomm aptX technology.

lang:af score:19 filesize: 1.25 M page_count: 13 document date: 2021-06-03



[\[pdf\] Frequently Asked Questions](#)

FAQ Amazon EarFun Free 2S Wireless Earbuds Upgraded Version Qualcomm® CVC™ 8.0 ENC

Bluetooth 5.2 Sweatshield™ IPX7 Waterproof Headphone aptX™ Deep Bass APP Game Mode


Electronics 61qGLJvG7mL m media amazon images I |||

FAQ Table of Contents BLUETOOTH.....

CE TEAM..... 4 BLUETOOTH How do I reset EarFun

Free 2S 1. Unpair EarFun **Free 2S** from your Bluetooth- enabled device and delete the old connection ...

lang:en score:17 filesize: 122.99 K page_count: 5 document date: 2022-10-31



[\[pdf\]](#)

Пользователь евразийский экономический союз декларация о соответствии заявляет что

Аудиоаппаратура наушники и гарнитуры беспроводные торговой марки EARFUN модели AIR

TW200 S TW201 MINI TW202 400048675 img mvideo ru certificates Certificates |||

: , : 107140, , , . 1- , . 9, 3, . 9, 9, : 1177746480163, : 7 9153075886, : oootechport ya.ru : , : EARFUN , : AIR TW200 , AIR S TW201 , AIR MINI TW202 , AIR PRO TW302 , AIR PRO SV TW306 , AIR PRO 2 TW300 , **FREE 2 TW101** , FREE MINI TW102 , FREE PRO ...

lang:de score:17 filesize: 342.96 K page_count: 1 document date: 2022-09-12



[\[pdf\] User Manual](#)

EarFun TW101 T9 04 02 EarFun Free 2 User Manual EarFun True Wireless Earphones Addicted To Audio NZEarFun Manual Engcdn shopify s files 1 0875 3864 Eng v 1625061066 |||

...

lang:de score:17 filesize: 6.7 M page_count: 60 document date: 2021-06-30

FAQ

Table of Contents	
BLUETOOTH	2
SOUND	3
CHARING	4
COMFORT	4
TAP CONTROL	4
CUSTOMER SERVICE TEAM	4

[pdf] Frequently Asked Questions

BLUETOOTH I Will the earbuds shut off automatically 1 Delete earbud from MacBook then will lose Bluetooth connection to and enter into pairing mode View 71106EbZ mL m media amazon images I

FAQ Table of Contents BLUETOOTH.....

CE TEAM..... 4 BLUETOOTH How do I reset EarFun

Free 2 1. Unpair EarFun **Free 2** from your Bluetooth-enabled device and delete the old connection on ...

lang:en score:13 filesize: 144.39 K page_count: 5 document date: 2021-11-02

FAQ

Table of Contents	
BLUETOOTH	2
SOUND	3
CHARGING	3
COMFORT	4
ANC MODE	4
TOUCH CONTROL	4

[pdf] Frequently Asked Questions

71tQVrQMUL m media amazon images I |||

FAQ Table of Contents BLUETOOTH.....

eset EarFun Free Pro . 3. Delete the old connection from the Bluetooth device and reconnect EarFun **Free 2** . What should I do If the earbuds don t turn off automatically when put back in the case and...

lang:en score:13 filesize: 145.62 K page_count: 5 document date: 2021-11-02



VGP 2022 -

VGP VGP 2022

LZ2000 DMR-ZR1 ES1 4K EL

VGP

lang:sw score:11 filesize: 11 M page_count: 55 document date: 2022-07-12



VGP 2023

VGP 2023

TVS REGZA LG

lang:sw score:10 filesize: 5.49 M page_count: 48 document date: 0000-00-00



[\[pdf\]](#)

EarFun TW101 T8 04 01 Ear Fun Free 2 True Wireless Earbuds earfun Reichelt First time pairing with device Step 1 Open the charging case earbuds will automatically power on and enter into mode Activate Bluetooth EARFUN FREE2 BDA INT reichelt index html ACTION 7 LA 3 OPEN 0 INDEX FILENAME E910
...

lang:sw score:9 filesize: 22.9 M page_count: 60 document date: 2021-04-01