

Dekain BL-FU200D

Dekain Projector Lamp for Optoma DAWSSU DAWSZBST User Manual

Model: BL-FU200D

INTRODUCTION

This manual provides essential information for the installation, operation, and maintenance of your Dekain Projector Lamp, designed for Optoma DAWSSU and DAWSZBST projectors. This replacement lamp module features an original Philips bulb, ensuring optimal performance and compatibility with your projector.

Dekain projector lamps are manufactured with original bulbs from OEM manufacturers (UHP, P-VIP, NSH, SHP, UHE, UHM, and HS) and include compatible housing made from durable materials for a proper fit. Each lamp is tested to meet OEM original standards for quality, function, and performance, offering a lifespan significantly longer than economic lamps.

SAFETY INFORMATION

Please read and understand all safety instructions before attempting to install or replace the projector lamp. Failure to follow these instructions may result in injury or damage to the projector.

- Always disconnect the projector from the power outlet and allow it to cool down completely before handling the lamp. Projector lamps operate at high temperatures and can cause severe burns if touched immediately after use.
- Do not touch the glass part of the new lamp with bare hands. Oils from your skin can reduce lamp life. Use gloves or a clean cloth when handling.
- Avoid looking directly into the projector lens or the lamp when it is operating, as the intense light can damage your eyes.
- Dispose of old lamps according to local regulations. Projector lamps contain mercury and other hazardous materials.
- Ensure the lamp cover is securely closed after installation to prevent light leakage and maintain proper cooling.

PACKAGE CONTENTS

Your Dekain Projector Lamp package should contain the following:

- 1 x Dekain Projector Lamp Module (Model: BL-FU200D)
- This User Manual

INSTALLATION INSTRUCTIONS

Follow these steps to safely replace the projector lamp:

1. **Power Off and Cool Down:** Shut down your projector completely and disconnect it from the power source. Allow the projector to cool down for at least 30 minutes. The lamp operates at high temperatures and needs to cool to prevent burns.
2. **Locate Lamp Compartment:** Refer to your projector's original user manual to locate the lamp compartment cover. This is typically secured by one or more screws.
3. **Remove Lamp Cover:** Carefully unscrew and remove the lamp compartment cover.
4. **Remove Old Lamp:** Loosen the screws that secure the old lamp module in place. Gently pull the handle on the lamp module to slide it out of the projector. Avoid forcing it.
5. **Install New Lamp:** Carefully insert the new Dekain lamp module into the projector, ensuring it is seated firmly and the plug is connected well. Secure the lamp module with its screws.
6. **Replace Lamp Cover:** Reattach the lamp compartment cover and secure it with its screws. Ensure it is closed properly.
7. **Reconnect Power:** Plug the projector back into the power source.
8. **Reset Lamp Timer:** Turn on the projector. Navigate to the projector's menu settings and locate the "Lamp Timer Reset" option. Follow the on-screen instructions to reset the lamp timer. This is crucial for accurate lamp life tracking.

Dekain OEM Make VS Generic Copy Lamp



Image: The Dekain Projector Lamp Module (Model BL-FU200D) with its housing, ready for installation.

OPERATING INSTRUCTIONS

Once the Dekain projector lamp is installed and the lamp timer is reset, your projector is ready for use. The lamp functions as an integral part of your projector's display system.

- **Power On/Off:** Operate your projector as usual using its power button or remote control.
- **Lamp Timer:** Regularly check the lamp timer in your projector's menu. Resetting the timer after each lamp replacement ensures accurate tracking of lamp usage and helps in planning future replacements.
- **Picture Quality:** The original Philips bulb inside your Dekain lamp ensures bright, clear, and consistent image quality throughout its lifespan.



Image: A projector in operation, casting a bright image. The Dekain lamp provides the light source for such projections.

MAINTENANCE AND LAMP LIFE EXTENSION

To maximize the lifespan and performance of your Dekain projector lamp, consider the following maintenance tips:

- **Operating Conditions:** Use your projector under normal operating conditions, ideally no more than 3 to 5 hours per day, in a clean, relatively dust-free environment. Excessive dust can hinder cooling and reduce lamp life.
- **Cool Down Period:** Always allow the projector to cool down completely after use before unplugging or moving it. Abrupt power cuts can damage the lamp.
- **Eco Mode:** Utilize your projector's "Eco Mode" or "Power Saving Mode" if available. This mode typically reduces lamp brightness slightly but significantly extends its operational hours, often reaching 3,000-5,000 hours.
- **Clean Air Filters:** Regularly clean or replace your projector's air filters to ensure proper airflow and prevent overheating, which is a major cause of premature lamp failure.
- **Avoid Frequent On/Off Cycles:** Frequent turning on and off of the projector can stress the lamp. If you need to pause viewing for a short period, it's often better to leave the projector on.



Image: A powerful light beam emanating from a projector, illustrating the lamp's function. Proper maintenance helps sustain this brightness.

TROUBLESHOOTING

If you encounter issues after installing your Dekain projector lamp, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No image or very dim image	Lamp not installed correctly, lamp timer not reset, lamp reached end of life, projector issue.	Ensure the lamp module is fully seated and secured. Verify the lamp compartment cover is closed properly. Reset the lamp timer in the projector's menu. If the old lamp was dim, the new lamp should resolve this. If not, check projector settings.

Problem	Possible Cause	Solution
Projector displays "Lamp Warning" or "Replace Lamp" message	Lamp timer not reset after replacement.	Reset the lamp timer in the projector's menu. Refer to your projector's manual for specific steps.
Unusual noise from projector	Loose lamp module, fan obstruction, or other internal issue.	Ensure the lamp module is securely fastened. Check for any obstructions in the projector's fan vents. If the noise persists, consult a qualified technician.

SPECIFICATIONS

Key specifications for the Dekain Projector Lamp (Model BL-FU200D):

- **Brand:** Dekain
- **Model Number:** BL-FU200D
- **Light Type:** Metal Halide (Original Philips Bulb)
- **Wattage:** 203 watts
- **Bulb Shape Size:** MR20
- **Unit Count:** 1.0 Count
- **Item Weight:** Approximately 14.4 ounces
- **Package Dimensions:** Approximately 6 x 6 x 5 inches
- **UPC:** 770429102295

WARRANTY AND SUPPORT

Dekain OEM lamps typically come with a warranty, providing added protection and peace of mind. This warranty covers potential issues with the lamp, ensuring reliability and performance.

- **Warranty Coverage:** For specific warranty terms and duration, please refer to the documentation provided with your purchase or contact Dekain customer support.
- **Contact Support:** For technical assistance, warranty claims, or any questions regarding your Dekain projector lamp, please contact Dekain Enterprise directly.

Your browser does not support the video tag.

Video: This video from DEKAIN ENTERPRISE explains the benefits of using a genuine OEM original replacement projector lamp, highlighting quality, compatibility, reliability, and warranty.



Image: A visual comparison illustrating the difference in quality between a Dekain OEM lamp and a generic copy lamp, emphasizing the superior performance of OEM parts.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question