

manuals.plus /

› [MENEEA](#) /

› [Wireless Controller Keyboard for PS5/PS5 Pro Instruction Manual](#)

**MENEEA JYS-P5121**

# Wireless Controller Keyboard for PS5/PS5 Pro Instruction Manual

Model: JYS-P5121 | Brand: MENEEA

## INTRODUCTION

---

This manual provides comprehensive instructions for the setup, operation, and maintenance of your MENEEA Wireless Controller Keyboard for PS5/PS5 Pro. Designed to enhance your gaming communication, this compact keyboard seamlessly integrates with your PlayStation 5 or PlayStation 5 Pro controller, offering a full QWERTY layout for easy messaging and chat.



Image: The Wireless Controller Keyboard securely attached to a PlayStation 5 controller, showcasing its integrated design.

## PRODUCT SPECIFICATIONS

<b>Working Voltage</b>	Lithium battery 3.7V
<b>Working Current</b>	5mA
<b>Quiescent Current</b>	1.6mA
<b>Maximum Charging Current</b>	500mA, 5V
<b>Keyboard Battery Capacity</b>	500mA lithium battery
<b>Bluetooth Version</b>	Bluetooth 3.0
<b>Charging Time</b>	1-2 hours
<b>Full Power Usage Time</b>	Approximately 100 hours
<b>Item Model Number</b>	JYS-P5121
<b>Package Dimensions</b>	20.4 x 8.2 x 5.5 cm
<b>Item Weight</b>	130 g

# Space-saving design

Small size does not affect the controller experience



Charging  
Red Light

Fully Charged  
Lights out

Image: A diagram illustrating the compact dimensions of the keyboard (128mm length, 60mm width, 49mm height) and indicating that a red light signifies charging, with the light turning off when fully charged. It also notes compatibility with PS5/PS5 Pro controllers, but not the PS5 Edge Controller.

## SETUP AND CONNECTION

Follow these steps to connect your wireless keyboard to your PlayStation 5 or PlayStation 5 Pro controller:

1. **Physical Connection:** Plug the keyboard's 3.5mm audio jack into the corresponding port on your PS5 controller. Ensure it is securely seated.
2. **Power On:** Turn on your PS5 console and your PS5 controller. Then, turn on the switch on the keyboard. A

blue indicator light will illuminate, signifying it is powered on.


3. **Initiate Pairing:** Press and hold the pairing button on the keyboard for three seconds to enter pairing mode.
4. **PS5 Settings:** On your PS5 console, navigate to [\[Settings\]](#) > [\[Peripherals\]](#) > [\[Bluetooth Accessories\]](#).
5. **Select Device:** Locate and select the Bluetooth device named [\[JYS Bluetooth Keyboard\]](#) from the list to initiate pairing.
6. **Enter Passkey:** The PS5 console will display a passkey. Enter this passkey using the wireless keyboard and then confirm your entry within 30 seconds.
7. **Connection Confirmation:** If the connection is successful, the indicator light on the keyboard will turn green.

# Easy to Install and Perfect Fit

Easily attaches to your controller  
and fits the contours of the controller perfectly



## Flexible 3.5 mm Audio Jack




1. Adjust the 3.5mm audio jack.
2. Plug into the controller's 3.5 mm port.
3. Fix the keyboard and turn on the power of the keyboard, the device lights up the blue light that the connection is successful.

Image: A visual guide demonstrating the easy attachment of the keyboard to the PS5 controller, highlighting the 3.5mm audio jack connection and the blue light indicator for successful connection.

# How to Connect


Tips: Please read the manual for detailed connection steps.

Settings - Accessories - General - Bluetooth Accessories -  
Choose "JYS Bluetooth keyboard".  
Enter the password on the keypad and press "Enter" to pair,  
if the connection is successful, the indicator light will turn green.



Connection Succeeded

After successful connection, the keyboard can be automatic paired next time.  
If the keypad is not recognized, reboot the keypad or delete the last pairing information to re-pair.



Reboot the keyboard or delete pairing information

Image: Screenshots illustrating the "How to Connect" process on the PS5 console, showing the Bluetooth Accessories menu, entering the passkey, and the successful connection indicator.

## OPERATION AND FEATURES

The MENEAA Wireless Controller Keyboard offers several features designed for convenient in-game communication and navigation.

### Keyboard Layout and Keys

The keyboard features a full QWERTY layout with 47 keys, including alphanumeric keys, special characters, and

directional keys for easy text input.



Image: A detailed diagram highlighting the various components and keys of the keyboard, including Caps Lock, Functional Key, Delete Key, Space Key, Directional Keys, On/Off Switch, Pairing Key, 3.5mm Audio Output Jack, Type-C Charging Port, and Indicator Light.

## Built-in Speaker

The keyboard includes a built-in speaker, allowing you to hear chat audio directly from the keyboard. This feature can be disabled via the PS5/PS5 Pro settings menu if you prefer to use an external headset.

- To use the keyboard's speaker for chat audio, ensure your PS5 audio output is not set to HDMI (TV).
- If using a microphone function in-game, select sound output to HDIM to avoid conflicts.

# Keyboard Built-in Speakers

Switchable game sound out mode for easy in-game voice communication.

When using a keyboard or TV speakers in a game with a Microphone function, please choose sound output to HDMI.



HDMI output mode will turn off the speaker sound



Image: A visual representation of the keyboard's built-in speaker, demonstrating how to switch game sound output for in-game voice communication and noting that HDMI output mode will turn off the speaker sound.

## Convenient Design

The keyboard is designed for ease of use, making typing faster and more efficient for in-game chat and searching. Its small size and lightweight nature ensure portability and do not interfere with the controller's ergonomics.

# Convenient and Useful Design

The keyboard makes typing easier and faster, perfect for searching and chatting in games.



47-Key  
Keyboard



Built-in  
Speaker



Light  
And Small



Built-in  
Battery



Image: A user actively playing a game with the keyboard attached to their PS5 controller, illustrating the practical application and convenience of the device for in-game communication.

## MAINTENANCE AND CHARGING

To ensure optimal performance and longevity of your keyboard, follow these maintenance guidelines:

- **Charging:** Connect the keyboard to a power source using its Type-C charging port. The indicator light will show red during charging and will turn off when fully charged.
- **Charging Note:** The controller and the keyboard cannot be charged simultaneously. Only the keyboard will

charge when connected.

- **Cleaning:** Use a soft, dry cloth to clean the surface of the keyboard. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the keyboard in a cool, dry place away from direct sunlight and extreme temperatures when not in use.

## TROUBLESHOOTING

---


If you encounter issues with your wireless keyboard, refer to the following common solutions:

- **Keyboard Not Working After Connection:** Ensure the keyboard is powered on and successfully paired. If the keyboard is not powered, it will not function.
- **Pairing Failure:** If the initial pairing attempt fails, try the following:
  - Restart the keyboard by turning it off and then on again.
  - On your PS5 console, navigate to [\[Settings\]](#) > [\[Peripherals\]](#) > [\[Bluetooth Accessories\]](#), find [\[JYS Bluetooth Keyboard\]](#), and select "Delete" or "Disconnect" to remove previous pairing information. Then, attempt the pairing process again from step 4 of the "Setup and Connection" section.
- **Automatic Reconnection Issues:** After a successful initial connection, the keyboard should pair automatically when powered on. If it does not, reboot the keyboard or delete the pairing information on the PS5 and re-pair manually.
- **No Audio from Built-in Speaker:** Check your PS5 audio output settings. Ensure that the output is not set to HDMI (TV) if you wish to use the keyboard's speaker.

# How to Connect


Tips: Please read the manual for detailed connection steps.

Settings - Accessories - General - Bluetooth Accessories - Choose "JYS Bluetooth keyboard".  
Enter the password on the keypad and press "Enter" to pair, if the connection is successful, the indicator light will turn green.



Connection Succeeded

After successful connection, the keyboard can be automatic paired next time.  
If the keypad is not recognized, reboot the keypad or delete the last pairing information to re-pair.



Reboot the keyboard or delete pairing information

Image: A visual guide demonstrating how to delete existing Bluetooth pairing information for the keyboard on the PS5 console, which can resolve connection issues.

## WARRANTY AND SUPPORT

Specific warranty details for this product are typically provided at the point of purchase or within the product packaging. Please refer to your purchase receipt or the product's retail box for precise warranty terms and conditions.

For technical support, troubleshooting assistance beyond this manual, or inquiries regarding product defects, please contact the manufacturer, MENEAA, or your retailer. Contact information can usually be found on the product

packaging or the seller's official website.

For general inquiries or to explore other products from MENEAA, you may visit their brand page on Amazon:

[MENEAA Brand Store](#).