

[Manuals.plus](#) /

› [NEBO](#) /

› NEBO Redline Torchy 2K Flashlight Instruction Manual

NEBO Torchy 2K

NEBO Redline Torchy 2K Flashlight Instruction Manual

Brand: NEBO

Model: Torchy 2K (NEB-FLT-1006)

1. INTRODUCTION

The NEBO Redline Torchy 2K is a powerful, compact, and rechargeable LED flashlight designed for versatility and durability. With 2000 lumens of bright light, multiple light modes, and a robust aluminum body, it's an ideal tool for various activities including camping, hunting, hiking, and everyday use. Its smart features like Power Memory Recall and a magnetic base enhance user convenience.



Image: The NEBO Redline Torchy 2K Flashlight, showcasing its compact design and durable construction.

2. SAFETY INFORMATION

- Do not look directly into the light beam. High lumen output can cause temporary vision impairment.
- Keep out of reach of children.

- Do not disassemble the flashlight or attempt to modify the battery.
- Avoid exposing the flashlight to extreme temperatures or direct flame.
- Ensure the charging port is clean and dry before charging.

3. PACKAGE CONTENTS

- 1 x NEBO Redline Torchy 2K Flashlight
- 1 x USB Charging MagCable
- 1 x 2200 mAh (3.7V) Lithium-ion rechargeable battery (pre-installed)

4. SETUP

First Use

Before initial use, ensure the battery is fully charged. The flashlight comes with a pre-installed rechargeable Lithium-ion battery. Remove any protective plastic film from the battery if present.

Charging the Battery

Connect the included USB Charging MagCable to a USB power source (e.g., wall adapter, computer USB port) and attach the magnetic end to the flashlight's charging port. The charging indicator light will illuminate to show charging status. A full charge typically takes 3-5 hours.

RECHARGEABLE

Recharge with the included Magdock.



Image: The NEBO Torchy 2K Flashlight connected to its magnetic charging cable on a workbench.

5. OPERATING INSTRUCTIONS

Power On/Off

Press the power button located on the side of the flashlight to turn it on or off.

Light Modes

The Torchy 2K features 5 light modes: Turbo, High, Medium, Low, and Strobe. Cycle through these modes by pressing the power button repeatedly while the flashlight is on.

- **Turbo (2000 Lumens):** Double-press the power button from any mode to activate Turbo mode. Press again to return to the previous mode.
- **High:** Provides optimal visibility.

- **Medium:** Offers balanced output for general use.
- **Low (35 Lumens):** Extends battery life for up to 30 hours.
- **Strobe:** Triple-press the power button from any mode to activate Strobe mode for emergency signaling. Press again to return to the previous mode.

Power Memory Recall

The flashlight remembers the last used light mode (excluding Turbo and Strobe) and will activate in that mode when turned on again.

Smart Power Control

This feature allows for smooth transitions between light modes, helping to extend battery life.

Magnetic Base

Utilize the powerful magnetic base to attach the flashlight to metal surfaces for convenient, hands-free lighting.



MAGNETIC BASE

For hands-free lighting.

Image: The NEBO Torchy 2K Flashlight demonstrating its magnetic base by attaching to a metal shelf, providing hands-free illumination.

Removable Clip

The integrated clip allows for secure attachment to pockets, belts, or gear, enhancing portability and accessibility.



COMPACT

Small, but powerful, the Torchy 2K fits in even the most cluttered spaces

Image: A close-up of the NEBO Torchy 2K Flashlight, highlighting its compact form factor and the integrated clip for easy carrying.

6. MAINTENANCE

Cleaning

Wipe the flashlight with a soft, damp cloth. Do not use abrasive cleaners, solvents, or harsh chemicals, as these may damage the finish or internal components.

Battery Care

To prolong battery life, avoid fully discharging the battery frequently. Recharge the flashlight regularly, especially if it will be stored for an extended period (e.g., every 3-6 months). Use only the provided MagCable for charging.

Storage

Store the flashlight in a cool, dry place away from direct sunlight and extreme temperatures. If storing for a long time, ensure the battery has a partial charge (around 50%) to maintain its health.



Image: The NEBO Torchy 2K Flashlight resting on a pile of screws, emphasizing its robust and impact-resistant design.

7. TROUBLESHOOTING

- **Flashlight not turning on:** Ensure the battery is properly installed and fully charged. Check for any protective film on the battery terminals that might prevent contact.
- **Dim light or short runtime:** Recharge the battery fully. If the issue persists after a full charge, the battery may be nearing the end of its lifespan and require replacement.
- **Charging issues:** Ensure the magnetic cable is securely connected to both the flashlight and the USB power source. Try a different USB port or power adapter. Clean the charging contacts on both the flashlight and the cable if necessary.
- **Difficulty cycling through modes:** Ensure the power button is pressed firmly and deliberately. If issues persist, try a

full charge cycle or consult the support section.

8. SPECIFICATIONS

Feature	Detail
Model Name	Torchy 2K
Lumens (Turbo)	2000 Lumens
Lumens (Low)	35 Lumens
Dimensions (L x D)	4.28" x 0.99" (approx. 10.87 cm x 2.51 cm)
Weight	0.25 lbs (approx. 115 grams)
Battery	2200 mAh (3.7V) Lithium-ion rechargeable
Light Source Type	LED
Material	Anodized Aluminum
Water Resistance	IPX6 (Water Resistant)
Light Path Distance	Up to 200 Meters
Runtime (Low)	Up to 30 hours
Charging Time	3-5 hours

9. WARRANTY

The NEBO Redline Torchy 2K comes with a 1-year limited warranty from the manufacturer. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims. For detailed warranty terms and conditions, or to initiate a warranty claim, please visit the official NEBO website or contact their customer support directly.

10. SUPPORT

For product support, technical assistance, or any inquiries not covered in this manual, please utilize the following resources:

- **Official NEBO Website:** Refer to the manufacturer's website for the most up-to-date information, FAQs, and contact details.
- **NEBO Store on Amazon:** You can find additional product information and support by visiting the official NEBO store page on Amazon: [Visit the NEBO Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question