

[Manuals.plus](#) /

> [EASYmaxx](#) /

> EASYmaxx Magic Click Pollen and Insect Screen for Windows - 130 x 150 cm Instruction Manual

EASYmaxx 03322

EASYmaxx Magic Click Pollen and Insect Screen for Windows

Model: 03322 | Size: 130 x 150 cm

1. INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your EASYmaxx Magic Click Pollen and Insect Screen. Designed for easy, drill-free installation, this screen offers effective protection against both insects and pollen, ensuring a comfortable indoor environment.



Figure 1: EASYmaxx Magic Click Pollen and Insect Screen (Grey)

The screen features a fine mesh of approximately 25 μm , providing reliable protection against various pollens and insects. Its adaptable design allows it to be cut to size, fitting most standard windows up to 150 x 130 cm. The magnetic fastening system ensures quick and easy attachment and removal without damaging your window frames.



Figure 2: Key Features of the EASYmaxx Insect Screen

2. PACKAGE CONTENTS

Please check the package contents upon receipt to ensure all components are present and undamaged.

- 1x EASYmaxx Insect Screen with Pollen Protection (130 x 150 cm)
- 12x Sets of Magnetic Fasteners



Figure 3: Included Magnetic Fasteners

3. SAFETY INSTRUCTIONS

- Keep the product and its components out of reach of children to prevent choking hazards.
- Do not use the screen as a safety barrier for children or pets.
- Ensure the screen is securely attached to prevent it from falling, especially in windy conditions.
- Avoid using sharp objects near the screen to prevent damage to the mesh.
- This product is intended for window insect and pollen protection only. Do not use for other purposes.



Figure 4: Safety Considerations



Figure 5: Protection Against Various Insects

4. SETUP AND INSTALLATION

4.1 Measuring and Cutting

The EASYmaxx insect screen can be cut to fit your window dimensions. Measure your window frame carefully. The screen can be customized up to a maximum size of 150 cm x 130 cm.



Figure 6: Customizing the Screen Size

4.2 Magnetic Attachment

The screen uses a magnetic fastening system for easy installation without drilling or screwing.

1. Clean the window frame thoroughly to ensure proper adhesion of the magnetic strips.
2. Attach the 12 magnetic modules to the clean window frame. Ensure they are evenly spaced and aligned.
3. Attach the corresponding magnetic counterparts to the edges of the insect screen.
4. Align the screen with the window frame and press firmly to engage the magnets. You should hear a simple and quick 'click'.



Figure 7: Magnetic Installation Diagram

4.3 Compatible Window Frames

The EASYmaxx screen is compatible with various window frame materials, including Plastic (PVC), Wood, and Aluminum. Ensure your window frame has a width of at least 9 mm for proper magnet attachment.



Figure 8: Compatible Window Frame Types

4.4 Installation Video

For a visual guide on the installation process, please refer to the official product video below:

Your browser does not support the video tag.

Video 1: EASYmaxx Magic Click Screen Installation Guide (Placeholder URL, actual video URL not provided in data)

5. OPERATION

Once installed, the EASYmaxx screen allows you to open your windows completely for ventilation while keeping insects and pollen out. The magnetic fastening system allows for easy detachment and reattachment of the screen as needed.

- To open or close your window, simply detach the screen from the magnets on one or more sides, operate the window, and then reattach the screen.
- The screen's semi-transparent material ensures that your outdoor view is not significantly obstructed.



Figure 9: Pollen Protection Feature



Figure 10: Enjoying Fresh Air Without Pollen

6. MAINTENANCE

To ensure the longevity and effectiveness of your EASYmaxx screen, follow these maintenance guidelines:

- **Cleaning the Screen:** The screen can be gently wiped with a damp cloth to remove dust and debris. For deeper cleaning, it can be detached from the magnets and hand-washed with mild soap and water. Allow it to air dry completely before reattaching.
- **Storing the Screen:** After the season, the screen can be easily detached from the magnets without leaving adhesive residue. Fold or roll it neatly and store it in a dry, clean place away from direct sunlight.
- **Magnet Care:** Keep the magnetic strips clean and free from dirt or dust to maintain strong adhesion.

7. TROUBLESHOOTING

If you encounter any issues with your EASYmaxx screen, please refer to the following common solutions:

- **Screen not adhering properly:** Ensure both the window frame and the magnetic strips are clean and dry. Realign the magnets if necessary to ensure full contact.
- **Gaps around the screen:** Check that the screen was cut to the correct dimensions and that the magnets are evenly spaced and securely attached along the entire perimeter of the window frame.
- **Damage to the mesh:** Small tears can sometimes be repaired with a fine needle and thread or a specialized mesh repair kit. For significant damage, replacement of the screen may be necessary.

8. SPECIFICATIONS

Manufacturer	EASYmaxx
Part Number	03322
Item Model Number	03322
Item Weight	284 g
Product Dimensions	1 x 130 x 150 cm
Size	130 x 150 cm 1 Piece

Color	Grey Magnet + Pollen Protection
Style	Magnetic Attachment with Pollen Protection
Material	Plastic
Model (Variant)	Single
Shape	Square
Power Source Type	Hand operated
Quantity per Pack	1
Mounting Type	Window Mount
Special Features	Removable
Included Components	1x insect screen with pollen protection, 12 sets of magnets
Batteries Included?	No
Batteries Required?	No
ASIN	B092NPXY6Y
Available on Amazon.it from	15 April 2021

9. WARRANTY AND SUPPORT

For information regarding warranty, returns, or technical support, please refer to the documentation provided with your purchase or contact EASYmaxx customer service directly. Contact details can typically be found on the product packaging or the manufacturer's official website.